AD-A221 969



Research Product 90-10a

Task Analysis of the CH–47D Mission and Decision Rules for Developing a CH–47D Workload Prediction Model

Volume I: Summary Report

Carl R. Bierbaum and Theodore B. Aldrich Anacapa Sciences, Inc.



February 1990

Aviation R & D Activity at Fort Rucker, Alabama Systems Research Laboratory

U.S. Army Research Institute for the Behavioral and Social Sciences

Approved for public release; distribution is unlimited.

90 05 21 061

SECURITY CLASSIFICATION OF THIS PAGE

		l	REPORT D	OCUMENTATIO	N PAGE			Form Approved OMB No. 0704-0188
1a. REPORT S Unclassi	CURITY CLASS	IFICATI	ON		1b. RESTRICTIVE	MARKINGS		
2a. SECURITY	CLASSIFICATIO	N AUT	HORITY			AVAILABILITY OF public rel		
2b. DECLASSIF	ICATION / DOW	VNGRA	DING SCHEDU	LE		on is unlimit	-	·
	G ORGANIZAT	ION RE	PORT NUMBE	R(S)		ORGANIZATION RE		MBER(S)
AS1690-3						ch Product 90		
	PERFORMING Sciences,			6b. OFFICE SYMBOL (If applicable) ——	U.S. Army H	ONITORING ORGAN Research Inst nd Developmer	itute	
6c. ADDRESS	- '	d ZIP C	ode)			ty, State, and ZIP Co	ode)	
P.O. Box Fort Ruc	489 ker, AL 30	6362-	5000		ATTN: PERI	r, AL 36362-5	354	
8a. NAME OF ORGANIZA Institute	FUNDING/SPO	NSOR!!	NG Research	8b. OFFICE SYMBOL (If applicable)	9. PROCUREMEN	T INSTRUMENT IDE	TIFICATI	ON NUMBER
and Socia	1 Sciences	<u> </u>		PERI-I	MDA903-87-0			
8c. ADDRESS (•				10. SOURCE OF F	PROJECT	TASK	WORK UNIT
	enhower Av ia, VA 221				ELEMENT NO. 63007	NO. A793	NO. 1210	ACCESSION NO.
11. TITLE (Incl	ude Security Co	lassifica	tion)	ssion and Decisi		<u>. </u>		
	-			Summary Report	on kules lo	Developing	a Cn-	WOIRIOAU
12. PERSONAL Bierbaum		. and	Aldrich.	Theodore B. (A	nacapa Scier	nces)		
13a. TYPE OF		, une	13b. TIME CO	OVERED	4. DATE OF REPO	RT (Year, Month, D	ay) 15.	PAGE COUNT
Interim					1990, Febru			1 10 0 1
A. Gaine		U.S.	Army Res	rch on this proj search Institute				
17.	COSATI	CODES		18. SUBJECT TERMS (C	ontinue on revers	e if necessary and	identify b	by block number)
FIELD 05	GROUP 08	SU	B-GROUP	Mission analys Task analysis		Aviator Modeling		oad, (ICR)
				Man-machine in	terface			
operation tasks for fied. To cognitive task	ission scons. The arthe mission he crewmente, and psyctimes also mission/CH-47D co	enari analy sion. mber ychom so we task/ rewme	o was used Sis used Nine ph performinator work ere derive workload	analysis data w The model used a	comprehensive coach to identified with the tareer used to bottom-up a	ntify the phations, and 15 and estimate asks were derection a compression to be	ises, in the second of the sec	functions, and ks were identi- the sensory,
procedur model pe	e for com rmitted a	binin n ana	ng the tas	sks into functio total workload d concurrent tas	ns and the sexperienced ks.	functions int	o segr	ments. The
_	ION / AVAILABI					CURITY CLASSIFICA	TION	
22a. NAME O		INDIV	SAME AS R		22b. TELEPHONE (Include Area Code)		
Charle	s A. Gain	E I			(205) 255-4	+404	L	ERI-IR

U.S. ARMY RESEARCH INSTITUTE FOR THE BEHAVIORAL AND SOCIAL SCIENCES

A Field Operating Agency Under the Jurisdiction of the Deputy Chief of Staff for Personnel

EDGAR M. JOHNSON Technical Director

JON W. BLADES COL, IN Commanding

Research accomplished under contract for the Department of the Army

Anacapa Sciences, Inc.

Technical review by

Charles A. Gainer Gabriel P. Intano Thomas R. Metzler Raymond C. Sidorsky Paul J. Tremont

Accession For	
NTIS GRA&I	
DTIC TAB	
Unannounced	
Justification	
Distributions/ Availability Codes	
Pict Spr. C.1	
A-1	

NOTICES

DISTRIBUTION: Primary distribution of this report has been made by ARI. Please address correspondence concerning distribution of reports to: U.S. Army Research Institute for the Behavioral and Social Sciences, ATTN: PERI-POX, 5001 Eisenhower Ave., Alexandria, Virginia 22333-5600.

FINAL DISPOSITION: This report may be destroyed when it is no longer needed. Please do not return it to the U.S. Army Research Institute for the Behavioral and Social Sciences.

NOTE: The findings in this report are not to be construed as an official Department of the Army position, unless so designated by other authorized documents.

Task Analysis of the CH-47D Mission and Decision Rules for Developing a CH-47D Workload Prediction Model

Volume I: Summary Report

Carl L. Bierbaum and Theodore B. Aldrich Anacapa Sciences, Inc.

Aviation R & D Activity at Fort Rucker, Alabama Charles A. Gainer, Chief

Systems Research Laboratory Robin L. Keesee Director

U.S. Army Research Institute for the Behavioral and Social Sciences 5001 Eisenhower Avenue, Alexandria, Virginia 22333-5600

Office, Deputy Chief of Staff for Personnel
Department of the Army

February 1990

Army Project Number 2Q263007A793

Human Factors in Training and Operational Effectiveness The Army Research Institute Aviation Research and Development Activity (ARIARDA) at Fort Rucker, Alabama, is an operational unit of the Training Research Laboratory and provides research support in aircrew training to the U.S. Army Aviation Center (USAAVNC). Research is conducted inhouse and is augmented by onsite contract support. This report documents contract work performed by ARIARDA in support of the Special Operations Aircraft (SOA) Program Manager (PM) Office at the Army Aviation Systems Command (AVSCOM).

The potential impact that advanced technology will have on manpower and personnel requirements must be considered during the early stages of planning for system modifications. One critical consideration is the impact that advanced technology will have on the workload of the system operator(s). Since operator overload can result in a dramatic decrease in system effectiveness, it is imperative that operator workload be considered throughout the system modification process.

This report describes the methods used to conduct a comprehensive task analysis of the CH-47D mission. Information provided by the CH-47D mission/task/workload analysis was used to establish a database for developing a computer model that predicts workload for the CH-47D pilot and copilot. Assessments of workload produced by the model provide a baseline for evaluating the workload impact of any high technology modifications or product improvements.

The report consists of two volumes. Volume I describes the methods for conducting the research and contains Appendixes A through E. Volume II contains function and segment summary worksheets and decision rules, Appendixes F through I.

Appendixes A through E, presented in Volume I, summarize the results of the CH-47D baseline mission/task/workload analysis. The following specific information is presented in each of these appendixes:

- Appendix A summarizes the segments in each mission phase;
- Appendix B presents an alphabetical list of the unique mission functions;
- Appendix C summarizes the functions in each mission segment;
- Appendix D presents an alphabetical list of the unique tasks; and

• Appendix E presents Function Analysis Worksheets that summarize the workload data derived for each unique function.

The information presented in Volume I comprises a comprehensive task database for developing the CH-47D workload prediction model.

Volume II of the report contains Appendixes F through I. The following information is presented in each of the appendixes:

- Appendix F presents the Function Summary Worksheets,
- Appendix G presents the Function Decision Rules,
- Appendix H presents the Segment Summary Worksheets, and
- Appendix I presents the Segment Decision Rules.

The Function Decision Rules provide directions for building functions from the tasks identified in the analysis and the Segment Decision Rules provide directions for building mission segments from the functions.

Comments or questions about the research should be directed to Mr. Charles A. Gainer at the following address:

Chief

ARI Aviation Research and Development Activity ATTN: PERI-IR (Mr. Charles A. Gainer)

Fort Rucker, Alabama 36362-5354

EDGAR M. JOHNSON Technical Director

recimical birector

The authors wish to express their appreciation to the following individuals for their contributions to this research effort.

Chief Warrant Officer, W4 Marty L. Anderson, Flight Standardization Division, Directorate of Evaluation and Standardization, and Chief Warrant Officer, W4 Ronald E. Newsome, Cargo Utility Systems Branch, Aviation Division, Department of Gunnery and Flight Systems, served as subject matter experts (SMEs) for the review of the mission task analysis. The baseline task analysis required in-depth knowledge of the cockpit configuration for both crewmembers of the CH-47D aircraft. SMEs' knowledge of the specific tasks performed by the pilot and copilot in the conduct of their mission contributed greatly to the success of the task analysis. Ms. Cassandra Hocutt, Anacapa Sciences, Inc., spent many hours developing the task analysis/ workload (TAWL) software system to provide for easy entering and management of the mission/task/workload database and the CH-47D workload prediction model. The authors especially thank Ms. Nadine McCollim for the speed and accuracy in typing the numerous revisions of the task analysis. Her work significantly enhanced the quality of the final product.

TASK ANALYSIS OF THE CH-47D MISSION AND DECISION RULES FOR DEVELOPING A CH-47D WORKLOAD PREDICTION MODEL. VOLUME I: SUMMARY REPORT

CONTENT	'S
---------	----

							Page
INTRODUCTION		•	•	•	•	•	1
Objectives		•		•	•	•	3
METHOD	, .		•	•	•	•	5
Conduct of the Mission/Task/Workload Analysis Develop a Mission Scenario	ses ts.	•	•	•	•	•	5 8 9 10
Development of the Baseline Workload Predict:	ion	M	od	el	•	•	18
Generation of Workload Model for MH-47E Crewn	nem)	be	rs	•	•	•	28
CONCLUSION		•	•	•	•	•	29
REFERENCES		•	•	•		•	31
APPENDIX A. SUMMARY OF CH-47D MISSION PHASES AN SEGMENTS	1D	•	•	•	•	•	A-1
B. ALPHABETICAL LIST OF CH-47D UNIQUE FUNCTIONS		•	•	•	•	•	B-1
C. OUTLINE OF CH-47D MISSION SEGMENTS FUNCTIONS	AN	D.	•	•	•	•	C-1
D. ALPHABETICAL LIST OF CH-47D UNIQUE	TA	SK	s.	•	•	•	D-1
E. CH-47D FUNCTION ANALYSIS WORKSHEETS	3.	•	•	•	•	•	E-1
LIST OF TABLES							
Table 1. List of CH-47D subsystems		•	•	•	•	•	13
2. Workload component scales		•	•	•	•		15

CONTENTS (Continued)

	I I CM OF PICUDES	Page
	LIST OF FIGURES	
Figure 1.	Task-flow diagram of the "top-down" approach used to conduct the CH-47D mission/task/workload analysis	6
2.	Depiction of the CH-47D mission scenario	7
3.	Example of a CH-47D Function Analysis Worksheet	11
4.	Bottom-up flow diagram outlining the technical steps to be performed in developing the CH-47D workload prediction model	19
5.	Example of a CH-47D Function Summary Worksheet	21
6.	Example of a CH-47D Function Decision Rules Worksheet	22
7.	Example of a CH-47D Segment Summary Worksheet	23
8.	Example of a CH-47D Segment Decision Rules Worksheet	24

GLOSSARY OF ACRONYMS AND ABBREVIATIONS

AA - Assembly Area

ARIARDA - Army Research Institute Aviation Research and

Development Activity

ARTEP - Army Training and Evaluation Program

AVSCOM - Army Aviation Systems Command

FARP - Forward Area Arming and Refueling Point

LHX - Light Helicopter Family

LZ - Landing Zone

NOE - Nap-of-the-Earth

NVG - Night Vision Goggles

PZ - Pick-up Zone

SME - Subject Matter Expert

SOF - Special Operations Forces

TAWL - Task Analysis/Workload

TASK ANALYSIS OF THE CH-47D MISSION AND DECISION RULES FOR DEVELOPING A CH-47D WORKLOAD PREDICTION MODEL

VOLUME I: SUMMARY REPORT

INTRODUCTION

Advanced technology currently being proposed for the next generation of Army helicopters is designed to reduce the heavy workload operators are likely to encounter in the high-threat environment of the Air/Land Battle 2000 scenario. However, in some instances, technological improvements may result in greater crewmember monitoring and decision-making responsibilities. Excessive demands on mental resources may degrade the quality of crewrembers' performance. Since the operator's performance is critical to mission effectiveness, it is essential that operator workload be considered throughout the system design process (Shingledecker & Crabtree, 1982).

One reason that system designers have failed to consider operator workload when proposing advanced technology for new Army aircraft is that there has been no methodology for estimating operator workload prior to and during the system development process. However, Anacapa Sciences, Inc. researchers, under contract to the U.S. Army Research Institute Aviation Research and Development Activity (ARIARDA), developed a methodology for predicting operator workload during the conceptual phase of the system development process for the Army's Light Helicopter Family (LHX) aircraft (Aldrich, Craddock, & McCracken, 1984; Aldrich, Szabo, & Craddock, 1986; McCracken & Aldrich, 1984). The methodology was used to generate workload predictions for one- and two-crewmember configurations during LHX system trade-off studies and analyses.

The LHX methodology employs a generic workload prediction model that can be tailored for use in making critical design decisions about any emerging weapon system. For example, the LHX methodology has been refined and used to develop baseline models for predicting workload encountered by the operators of the AH-64A aircraft (Szabo & Bierbaum, 1986) and UH-60A aircraft (Bierbaum, Szabo, & Aldrich, 1987). In contrast to the LHX model, which is based on an analysis of a proposed system, the AH-64A and UH-60A baseline models are based on existing aircraft. Consequently, the AH-64A and UH-60A workload analyses were conducted at a high level of task specificity.

One of the features of the workload prediction methodology is that it can be used to predict the effect that (a) proposed modifications have to an aircraft and (b) alternative crew complements may have on operator workload. For example, Aldrich, Szabo, and Craddock (1986) report predictions of operator workload for 42 different configurations of automation options proposed for both a one- and two-crewmember LHX design. The AH-64A workload prediction model was exercised to predict the effect on operator workload for a proposed Airborne Target Handover System modification to the AH-64A (Szabo, Bierbaum, & Aldrich, 1987).

Recently the Special Operations Forces (SOF) Program Management Office at the Army Aviation Systems Command (AVSCOM) was tasked to modify the UH-60A and CH-47D aircraft with new technology for SOF missions. The aircraft, designated the MH-60K and the MH-47E, respectively, will be modified by replacing present instrumentation with fully integrated cockpits featuring four multifunction displays. The SOF Program Manager requested that the ARIARDA's AVSCOM Element support the development of the MH-60K and MH-47E aircraft. Accordingly, ARIARDA tasked Anacapa Sciences to apply the workload prediction methodology in support of the SOF modifications.

This report presents the results of a comprehensive task analysis of the CH-47D mission and the development of a baseline workload prediction model for estimating operator workload for the current CH-47D aircraft. Subsequently, a comprehensive task analysis of the SOF mission, as performed in the MH-47E aircraft, will be performed and an MH-47E workload prediction model will be developed. The baseline CH-47D workload prediction model will be exercised to produce estimates of workload experienced by operators in the performance of their current mission. The MH-47E model will be exercised to produce predictions of crew workload during performance of the SOF mission. Workload predictions yielded by the CH-47D workload prediction model will be compared with workload predictions yielded by the MH-47E workload prediction model. The MH-47E workload prediction model also will be exercised for various advanced technology configurations proposed for the MH-47E aircraft. Workload predictions for the various configurations will be compared to identify the optimum advanced technology configuration for reducing operator workload.

Objectives

The research described in this report has three general objectives:

- conduct a detailed analysis of the tasks that must be performed to accomplish the CH-47D combat mission;
- estimate the workload associated with the performance of the CH-47D mission tasks; and
- develop a computer model to predict CH-47D operator workload.

To accomplish the general objectives, the following specific objectives were established:

- identify the phases, segments, functions, and tasks required to perform the CH-47D combat mission;
- identify the crewmember(s) performing each task;
- estimate the workload associated with the sensory, cognitive, and psychomotor components of each task;
- define the temporal sequence of the tasks and estimate the duration of each task;
- identify the subsystem(s) representing the man-machine interface for each task;
- develop decision rules for combining the tasks to form each mission function; and
- develop decision rules for combining the functions to form each mission segment.

The research tasks that were performed to meet these objectives are described in the sections that follow.

METHOD

Conduct of the Mission/Task/Workload Analysis

This section describes the research steps that were performed to conduct the mission/task/workload analysis for the existing CH-47D aircraft. The analysis addressed the mission tasks and concomitant workload for both the pilot and copilot. The CH-47D crew also requires a flight engineer, but the analysis does not include the flight engineer functions and tasks. The research steps are listed below in the order in which they were performed:

- develop a composite mission scenario,
- divide the composite mission scenario into mission phases,
- · divide the mission phases into mission segments,
- identify the mission functions in each mission segment,
- identify the crewmember tasks in each unique mission function,
- · identify the crewmember(s) performing each task,
- identify the subsystem(s) representing the man-machine interface for each crewmember task,
- estimate the workload associated with the sensory, cognitive, and psychomotor components of each crewmember task, and
- define the temporal sequence and estimate the duration of each task.

A task-flow diagram depicting these research tasks is presented in Figure 1. Each of the research tasks is described in detail in succeeding paragraphs of this report; products resulting from the performance of the research tasks are presented in the appendixes to the report.

Develop a Mission Scenario

The first step in conducting the CH-47D mission/task/workload analysis was to develop a mission scenario for the CH-47D. The scenario was developed from information derived from three primary sources: (a) review of the CH-47D Operator's Manual (Department of the Army, 1982), (b) review of the Army Training and Evaluation Program (ARTEP) Manual for Transportation Helicopter Battalion (Department of the Army, 1983), and (c) interviews with CH-47D subject-matter





Figure 1. Task-flow diagram of the "top-down" approach used to conduct the CH-47D mission/task/workload analysis.

experts (SMEs). The scenario that was developed from these sources is graphically depicted in Figure 2. A fundamental assumption underlying this scenario is that the basic mission for the CH-47D aircraft is to provide air transportation of personnel and cargo in support of combat operations. The scenario further assumes that the CH-47D combat support operations can be conducted under either day or night conditions and may include the transportation of both internal loads and external sling loads.

As shown in Figure 1, the CH-47D mission begins in an assembly area (AA) where preflight and departure operations are performed. The pilot then flies contour flight from the AA to a pick-up zone (PZ), where cargo and/or troops are assembled for pick-up. After completing the loading operations, the pilot flies nap-of-the-earth (NOE) to the landing zone (LZ) to insert the combat troops or deliver the cargo.



After completing the troop and/or cargo delivery, the pilot flies NOE back to the PZ for another load. This pattern of activity is continued until the aircraft requires refueling. The pilot then flies NOE from the LZ to the forward area arming and refueling point (FARP), where refueling operations are conducted. Upon completion of the FARP operations, the crew returns to the PZ for continuation of the mission. When the mission is complete, the pilot flies contour back to the AA where postflight activities are conducted. It is assumed that, during the conduct of these mission operations, the pilot's primary role is to fly the aircraft, while the copilot's primary role is to assist the pilot and perform navigation functions; furthermore, it is assumed that the mission is flown under optimal performance conditions (i.e., daylight or full moon at night with no degradations due to weather or emergencies).

While the authors are aware that the activities and conditions encountered on any given mission may differ from those described above, the adoption of a mission scenario encompassing a standard set of assumptions is an essential step in conducting the mission analysis. First, the scenario provides a basis for conducting a comprehensive analysis of all possible mission segments. Second, the scenario provides a standard against which the effect of proposed changes in the mission and/or the aircraft configuration can be compared. Finally, by assuming optimal conditions for performance of the mission, the most conservative estimates of workload are produced. If excessive workload is predicted to occur during optimal conditions, almost certainly excessive workload will occur during degraded conditions.

Divide the Mission Scenario Into Mission Phases

The mission scenario described above was subsequently divided into nine mission phases. At the request of AVSCOM, preflight and postflight operations were excluded from the analysis; consequently, the research begins with departure from the assembly area and ends with return to the assembly The nine phases included in the analysis are listed below in the order of their occurrence within the mission; the phases are also shown in Figure 2.

- Phase 1: Departure (AA),
- Phase 2: Enroute (AA-PZ),
- Phase 3: Departure (PZ),
- Phase 4: Enroute (PZ-LZ),
- Phase 5: Departure (LZ),
 Phase 6: Enroute (LZ-PZ) or (LZ-FARP),
- Phase 7: FARP Operations,

- Phase 8: Enroute (FARP-PZ), and
- Phase 9: Enroute (PZ-AA).

Divide the Mission Phases Into Segments

The nine mission phases selected for analysis were subsequently divided into mission segments. A mission segment is defined as a major sequence of events that has a definite start and end point during a mission phase. An example of a segment performed during the Departure (Assembly Area) phase of the CH-47D mission is Before Takeoff (Assembly Area).

A total of 71 segments were identified for the nine mission phases selected for analysis. Thirty-seven segments are unique (i.e., segments that are distinctly different from any other segment); the remaining 34 segments are duplicates of the 37 unique segments. The total number of segments identified in each of the nine mission phases is presented below.1

- Phase 1: Departure (AA) 4 segments,
- Phase 2: Enroute (AA-PZ) 10 segments,
- Phase 3: Departure (PZ) 7 segments,
- Phase 4: Enroute (PZ-LZ) 12 segments, Phase 5: Departure (LZ) 3 segments,
- Phase 6: Enroute (LZ-PZ) or (LZ-FARP) 10 segments,
- Phase 7: FARP Operations 5 segments,
- Phase 8: Enroute (FARP-PZ) 10 segments, and
- Phase 9: Enroute (PZ-AA) 10 segments.

The specific mission segments that must be performed to accomplish each of the nine mission phases under day and night conditions are listed in Appendix A.2 The two-digit number assigned to each segment in Appendix A is based on the ordinal position of the segment within the mission scenario described above. Segments occurring more than once during the mission are identified by the ordinal position of their initial occurrence, and thus, retain the same numerical identifier throughout the scenario.

The reported total for each mission phase includes all the segments that are performed during both day and night conditions for that phase--not just the number of unique segments in that phase.

² As previously noted, the segments listed for each phase in Figure 2 include only those segments performed under day conditions. Additional segments identified in Appendix A for each mission phase are those segments that are performed with night vision goggles.

Identify the Functions in the Mission Segments

Each of the 37 unique mission segments was further divided into functions. A function is defined as a set of activities that must be performed either by an operator or by equipment in order to complete a portion of the mission segment. An example of a mission function performed during the previously presented segment, Before Takeoff (Assembly Area), is Perform Hover.

A total of 66 unique functions were identified for the 37 mission segments. The unique functions were ordered in an alphabetical list, and a number (1-66) was assigned corresponding to the ordinal position of each function within the list. The number assigned serves as an identifier for the function within the computer model data base.

The alphabetical list of functions and their respective numerical identifiers are presented in Appendix B. A list of the functions that must be performed to accomplish each of the 71 mission segments is presented in Appendix C.

Identify the Tasks for Each Unique Function

Each of the 66 unique functions was further divided into tasks. Each task defines a specific crew activity that is essential to the successful performance of the selected function. The task description consists of a verb and an object; the verb describes the action by the crewmember, and the object describes the recipient of the action. Examples of tasks performed during the function, Perform Hover, include Check Obstacle Clearance, Control Altitude, and Control Drift. The tasks are the basic units of the analysis.

A total of 154 unique tasks were identified for the 66 unique functions in the mission/task/workload analysis. The unique tasks were alphabetized by object and verb and assigned a numerical identifier ranging from 1 through 154. Appendix D presents the alphabetical list of the tasks and their respective numerical identifiers.

Each task was analyzed to produce the task descriptive data required to develop the workload prediction model. As the analyses were performed, the task descriptive data were entered on Function Analysis Worksheets. An example of a Function Analysis Worksheet is presented in Figure 3. Specifically, Figure 3 presents the task descriptive data for each of the tasks identified in the mission function, Perform

FUNCTION 29 Perform Hover

	TASKS	TASK	SUBSYSTEM(S)	WORKLO	OADCOMPONE	м - х - х	SWITCH	DURATION
VERB	OBJECT		-	SENSORY	COGNITIVE	PSYCHOMOTOR		DISCRETE/ CONTINUOUS
Control	Altitude	P019	Fight Control External Visual Field (FC/VEX)	Flight Control External Visual Field Visually Detect Aircraft (FC/VEX) K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		w.
Control	Attitude	P026	Flight Control/ External Visual Field (FC/VEX)	Flight Control Feel Control Movements/ External Visual Field Visually Detect Aircraft (FC/VEX) Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P.2.6		w.
Control	Heading	P081	Flight Control/ External Visual Field (FC/VEX)	Flight Control Feel Control Movements/ External Visual Field Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		w.
Control	Drift	P062	P062 Flight Control/ External Visual Fleid (FC/VEX)	Fight Control Feel Control Movements/ External Visual Field Visually Detect Aircraft (FC/VEX) Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		ń
Maintain	Obstacle Clearance	P115	Flight Control/ External Visual Fleid (FC/VEX)	Flight Control Feel Control Movements/ External Visual Field Visually Orlent Aircraft (FC/VEX) K-4/V-3.7	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P.2.6		w.
Check	Obstacle Clearance	C114	External Visual Field (VEX)	C114 External Visual Field Visually Register Obstacles (VEX)	Make Conditioned Association (Aircraft Clear) C-1			-

*Since some of the tasks are performed randomly, the total time for the function is greater than the sum of the length of the individual tasks.

Figure 3. Example of a CH-47D Function Analysis Worksheet.

Hover. The task descriptive data developed for all of the tasks in each of the 66 unique functions are shown on the Function Analysis Worksheets presented in Appendix E.

The function, Perform Hover, will be used as an example throughout the remainder of this report. Therefore, the reader should refer to Figure 3 while reading the next sections that describe how the task descriptive data were derived during the conduct of the mission/task/workload analysis, and the subsequent section that describes the procedures used to develop the workload prediction model.

The verbs and objects defining the tasks are presented in columns one and two, respectively, of the Function Analysis Worksheets. The numerical identifiers for the respective tasks are presented in column three. The remaining columns present descriptive data that were produced for each task by performing the following analyses:

- identify the appropriate crewmember(s) for each task,
- identify the subsystem(s) associated with each task,
- · estimate the workload associated with each task, and
- estimate the time required to perform each task.

Procedures followed in performing the above analyses are described in the next sections of this report.

Identify the Appropriate Crewmember(s) for the Task

Once the tasks were identified for each function, it was necessary to identify the crewmember(s) performing each task. Specifically, it was necessary to determine whether the pilot, copilot, or both crewmembers performed the task within a given function. Information derived from reviews of the operator's and ARTEP manuals and from interviews of CH-47D SMEs provided the basis for assigning the tasks to a given crewmember. In general, all flight control tasks were assigned to the pilot, and all navigation and support tasks were assigned to the copilot.

On the Function Analysis Worksheets, tasks performed by the pilot are indicated by the letter "P" preceding the numerical identifier in the third column; similarly, tasks performed by the copilot are indicated by the letter "C." For example, the data presented in Figure 3 indicate that the task, Check Obstacle Clearance, is performed by the copilot, while the tasks, Control Drift and Maintain Obstacle Clearance, are performed by the pilot.

Identify the Subsystem(s) Associated With Each Task

The next step in the analysis was to identify the subsystem(s) representing the man-machine interface for each task. As shown in Figure 3, the subsystems identified for the CH-47D tasks are listed in the fourth column of the Function Analysis Worksheets. The tasks presented as examples interface with a variety of subsystems. Specifically, the task, Check Obstacle Clearance, is associated with the External Visual Field subsystem only, while the task, Control Altitude, is associated with the Flight Control and the External Visual Field subsystems.

A total of 17 subsystems from 5 major categories were identified for the unique CH-47D mission tasks. Table 1 lists these subsystems with their respective codes assigned to identify them in the computerized data base.

Table 1
List of CH-47D Subsystems

Co	de	Subsystem
E	EF EIN EI	Engine Subsystem Fuel Engine Instruments Ignition
F	FB FC FI FG	Flight Control Subsystem Brakes Flight Controls Flight Instruments Gear
N	NM NC ND	Navigation Subsystem Maps Navigation Controls Navigation Displays
ŭ	UAD UC UL US UCA	Utility Subsystem Advisory Communications Lighting Survivability Cargo
V	VEX VG	Visual Subsystem External Visual Field Night Vision Goggles

Estimate the Workload Associated With Each Task

Workload, as the term is used in this research, is defined as the total attentional demand (i.e., mental workload) placed on the operators as they perform the mission tasks. Consistent with Wickens' theory that workload is a multidimensional construct, the research methodology addresses three different components of workload: sensory, cognitive, and psychomotor (Wickens, 1984). The sensory component refers to the complexity of the visual-unaided (V), visual-aided (G) auditory (A), and/or kinesthetic (K) stimuli to which an operator must attend; the cognitive (C) component refers to the level of information processing required from the operator; the psychomotor (P) component refers to the complexity of the operator's behavioral responses.

To determine the workload for each task, the specific components (i.e., visual-unaided, visual-aided, auditory, kinesthetic, cognitive, and psychomotor) that apply to the task were identified. Then, a short verbal descriptor of the specific workload associated with each of the components was written. The verbal descriptors for each of the tasks performed during the function, Perform Hover, are presented in columns five, six, and seven of the Function Analysis Worksheet presented in Figure 3.

The verbal descriptors of workload were subsequently compared with the verbal anchors on the corresponding workload component scale (see Table 2). The purpose of the comparison was to identify the verbal anchor that represents the "best match" with the verbal descriptor. The rating scale value associated with the verbal anchor identified as the "best match" was assigned to represent the level of workload for that particular component of the task.

For each task, two analysts reached consensus in selecting the verbal anchor that best matched the short verbal descriptor of workload. The consensual matches were subsequently reviewed by CH-47D SMEs. The numerical ratings of the sensory, cognitive, and psychomotor workload associated with the tasks shown in Figure 3 are presented immediately below the corresponding verbal descriptors of workload. For example, the numerical rating of the visual workload associated with the task, Control Drift, is 1; the numerical rating of the kinesthetic workload associated with the task is 4;

Table 2
Workload Component Scales

Scale Value	Verbal Descriptors
value	
	Visual-Unaided (Naked Eye)
1.0	Visually Register/Detect (Detect Occurrence of Image)
3.7	Visually Discriminate (Detect Visual Differences)
4.0	Visually Inspect/Check (Discrete Inspection/Static Condition)
5.0	Visually Locate/Align (Selective Orientation)
5.4	Visually Track/Follow (Maintain Orientation)
5.9	Visually Read (Symbol)
7.0	Visually Scan/Search/Monitor (Continuous/Serial Inspection, Multiple Conditions)
	Visual-Aided (Night Vision Goggles [NVG])
1.0	Visually Register/Detect (Detect Occurrence of Image) with NVG
4.8	Visually Inspect/Check (Discrete Inspection/Static Condition) with NVG
5.0	Visually Discriminate (Detect Visual Differences) with NVG
5.6	Visually Locate/Align (Selective Orientation) with NVG
6.4	Visually Track/Follow (Maintain Orientation) with NVG
7.0	Visually Scan/Search/Monitor (Continuous/Serial Inspection, Multiple Conditions) with NVG
	Auditory
1.0	Detect/Register Sound (Detect Occurrence of Sound)
2.0	Orient to Sound (General Orientation/Attention)
4.2	Orient to Sound (Selective Orientation/Attention)
4.3	Verify Auditory Feedback (Detect Occurrence of Anticipated Sound)
4.9	Interpret Semantic Content (Speech)
6.6	Discriminate Sound Characteristics (Detect Auditory Differences)
7.0	Interpret Sound Patterns (Pulse Rates, Etc.)
	on next page.

Table 2: Workload Component Scales (Continued)

Scale Value	Verbal Descriptors
	Kinesthetic
1.0	Detect Discrete Activation of Switch (Toggle, Trigger, Button)
4.0	Detect Preset Position or Status of Object
4.8	Detect Discrete Adjustment of Switch (Discrete Rotary or Discrete Lever Position)
5.5	Detect Serial Movements (Keyboard Entries)
6.1	Detect Kinesthetic Cues Conflicting with Visual Cues
6.7	Detect Continuous Adjustment of Switches (Rotary Rheostat, Thumbwheel)
7.0	Detect Continuous Adjustment of Controls
	Cognitive
1.0	Automatic (Simple Association)
1.2	Alternative Selection
3.7	Sign/Signal Recognition
4.6	Evaluation/Judgment (Consider Single Aspect)
5.3	Encoding/Decoding, Recall
6.8	Evaluation/Judgment (Consider Several Aspects)
7.0	Estimation, Calculation, Conversion
	Psychomotor
1.0	Speech
2.2	Discrete Actuation (Button, Toggle, Trigger)
2.6	Continuous Adjustive (Flight Control, Sensor Control)
4.6	Manipulative
5.8	Discrete Adjustive (Rotary, Vertical Thumbwheel, Lever Position)
6.5	Symbolic Production (Writing)
7.0	Serial Discrete Manipulation (Keyboard Entries)

the numerical rating of the cognitive workload associated with the task is 1; and the numerical rating of the psychomotor workload associated with the task is $2.6.^3$

Estimate the Time Required to Perform Each Task

The final step in conducting the mission/task/workload analysis was to estimate the amount of time required to perform each task. To derive the time estimates, each task was first identified as a discrete fixed, discrete random, or continuous task. These three categories of tasks are defined as follows:

- discrete fixed tasks that have a definite start and end point within the function (e.g., Set Swivel Switch),
- discrete random discrete tasks that occur intermittently and/or randomly during a portion of the function (e.g., Check Fuel Quantity Indicator), and
- continuous tasks that occur continuously throughout the function or a portion of the function (e.g., Monitor Audio).

Once the tasks were categorized as discrete fixed, discrete random, or continuous, the time required to perform each task was estimated to the nearest half-second. The estimates were derived from interviews with CH-47D SMEs. As shown in Figure 3, the estimated duration of the discrete random tasks (e.g., Control Altitude = .5 second) is presented in the ninth column of the Function Analysis Worksheets. No discrete fixed or continuous tasks are depicted in the Figure 3 example. For functions with discrete fixed tasks, the standard duration of the tasks are also entered in the ninth column. For functions with continuous tasks, the estimated duration is entered in the tenth column together with the letter "c" designating the task as continuous.

The total time required to perform all the tasks in a given function is presented in the upper right corner of most Function Analysis Worksheets. Most of the functions identified in the analysis consist of discrete fixed tasks only; the total time for these functions is derived by summing the time required to perform all discrete fixed tasks and adding

The type of switch that is associated with a specific task is a correlate of workload. Consequently, for each task involving a switch, the type of switch is presented in the eighth column of the Function Analysis Worksheets. None of the tasks depicted in Figure 3 involve a switch.

a half-second transition time between each consecutive task. However, certain functions, including the referent function, Perform Hover, have discrete random tasks that are performed repeatedly for a specified period of time; the total time for these functions is affected by both the length of the discrete random tasks and the total number of times the discrete random tasks occur. The Function Analysis Worksheets for functions with discrete random tasks include a footnote to explain the derivation of the total time. functions contain continuous tasks that occur continuously throughout the function or some portion of the function. duration of these functions generally depends upon the specific segment in which the functions occur. For these functions, the word "continuous" instead of a total time is presented in the upper right corner of the Function Analysis Worksheets.

Development of the Baseline Workload Prediction Model

The mission/task/workload analysis, described in the preceding sections, used a top-down approach to identify the tasks that must be performed to meet the objectives of the CH-47D mission. That is, the analysis started with the mission and proceeded, top-down, through the phases, segments, and functions to the task level. The tasks represent the basic units of analysis for which estimates of workload and time were derived. These data, in turn, constitute a data base that was used to develop a model that predicts workload experienced by CH-47D crewmembers as they perform their mission.

In developing the CH-47D workload prediction model, a "bottom-up" approach was used. The bottom-up approach starts with the basic elements produced by the analysis (i.e., the tasks) and builds upward to the segment level. First, the tasks identified for a specific function are combined to rebuild the functions from which the tasks were originally derived. Then, the functions identified for a specific segment are combined to rebuild the segments from which the functions were originally derived. The technical steps that must be performed to develop the model and to produce estimates of workload are listed below and are graphically depicted in Figure 4:

- · write decision rules,
- · develop the workload prediction model, and
- exercise the model to produce estimates of workload.

Each of these technical steps is described in detail below.




Figure 4. Bottom-up flow diagram outlining the technical steps to be performed in developing the CH-47D workload prediction model.

Write Decision Rules

The first step in developing the workload prediction model was to develop decision rules for building the mission segments from the task data base. First, function decision rules were developed for combining the tasks into functions. Then, segment decision rules were developed to combine the functions into segments. The function and segment decision rules reconstruct the mission to simulate the behavior of each crewmember at each point on the mission timeline. the mission timeline has been reconstructed through the implementation of the decision rules, estimates of total workload associated with concurrent tasks can be derived. Specifically, estimates of total workload for each crewmember can be produced for each workload component at half-second intervals throughout the segment. The procedures used to develop the decision rules and to compute the workload totals are described in the following subsections.

Develop function decision rules. Function decision rules were developed for each of the 66 unique functions identified in the mission/task/workload analysis. The decision rules were developed in two stages. First, the tasks performed by each crewmember were identified and listed on worksheets referred to as Function Summary Worksheets. Then, the decision rules for combining the tasks listed on the summary sheets were developed and reported on Function Decision Rules Worksheets. The Function Summary and Decision Rules Worksheets for the function, Perform Hover, are presented in Figures 5 and 6, respectively.

As shown in Figure 5, the Function Summary Worksheets list, by name and code number, all of the tasks performed during a given function. The left half of each summary sheet lists the tasks performed by the pilot, while the right half lists the tasks performed by the copilot. For each crewmember, separate columns identify discrete fixed, discrete random, and continuous tasks performed during the function. The spatial arrangement of the tasks on the worksheets corresponds roughly to the temporal sequence of the tasks. For example, the information presented in column two of Figure 5 indicates that the tasks, Control Altitude and Control Drift, are discrete random tasks performed by the pilot during the function. The information presented in column five of Figure 5 indicates that the copilot will be performing the discrete random task, Check Obstacle Clearance, while the pilot is performing his tasks.

Once the summary worksheets were completed for each function, decision rules were written to describe how the tasks must be combined to form the function. Decision rules for discrete fixed tasks (e.g., Set Swivel Switch) and continuous tasks (e.g., Monitor Flight Controls) simply state the start time and the duration of the tasks on the function timeline. In addition to duration, the decision rules for discrete random tasks (e.g., Control Altitude) state the probability and/or frequency of the random tasks' occurrence within the function (see column two of Figure 6). The Function Summary Worksheet for each unique function is presented in Appendix F; the corresponding Function Decision Rules Worksheets are presented in Appendix G.

Develop segment decision rules. The next step in the development of the model was to write the segment decision rules. The segment decision rules build the mission segments from the functions that were built in the previous step. The segments were developed in two stages: first by developing Segment Summary Worksheets and then by developing Segment Decision Rules Worksheets. Figures 7 and 8, respectively,

FUNCTION 29 Perform Hover

Figure 5. Example of a CH-47D Function Summary Worksheet.

FUNCTION 29 Perform Hover

	S	
	CONTINUOUS	
0.1	TE OM)	25 times during Function 29, randomly select Task 114. Task 114 lasts 1 second.
COPILOT	DISCRETE (RANDOM)	s during as during ask 11, resk 11, res
	D E	25 times during Function 29, randomly select Task 114. Task 114 lasts 1 second.
	IXED)	
	TE (F	
	DISCRETE (FIXED)	
	CONTINUOUS	
	NITNO	
	ŭ	
	∃ (s 019, and d d d d d d d d d d d d d d d d d d
PILOT	DISCRETE (RANDOM)	y select y) Task y) Task y) Task Seconting Conting ds. 5 seco
	DIS (R)	Randomly select (.20 probability) Tasks 019, 026, 062, 081, and 115 at .5-second intervals. Continue for 30 seconds. Standby .5 second
	ED)	Œ Φ Φ ← Έ Θ Ν
	(FIX	
	DISCRETE (FIXED)	
	DIS	

Figure 6. Example of a CH-47D Function Decision Rules Worksheet.

PHASE 1 Departu	Departure (Assembly Area)	•	SEGMENT 01 Before	Takeoff (Assembly	Area)
	PILOT			COPILOT	
DISCRETE (FIXED)	DISCRETE (RANDOM)	CONTINUOUS	DISCRETE (FIXED)	DISCRETE (RANDOM)	CONTINUOUS
Perform Before Taxi Check (24)		Monitor Audio (17)	Program Doppler (38)		Monitor Audio (17)
Perform Taxi (35)			(39)		
Perform Taxiing Check (37)	Perform Cockpit Communication (Pilot)		Perform Before Taxi Check (24)	Perform Cockpit Communication	
Perform Before Hover Check (20)	(29) Perform Cockpit		Perform Taxi (35)	(Copirot) (23) Perform Cocknii	
Establish Hover (63)	Communication (Copilot) (25)		Perform Taxiing Check (37)	Communication (Pilot) (26)	
Perform Hover (29)			Perform Before Hover Check (20)		
Perform Hover Check (30)			Perform Hover (29)		
			Perform Hover Check (30)		
			Perform External Communication (27)		

Figure 7. Example of a CH-47D Segment Summary Worksheet.

Area)	
(Assembly	
Takeoff	
Before 1	
SEGMENT 01	
Area)	
sembly i	
parture (A	

PHASE 1

	PILOT			COPILOT	
DISCRETE (FIXED)	DISCRETE (RANDOM)	CONTINUOUS	DISCRETE (FIXED)	DISCRETE (RANDOM)	CONTINUOUS
Start Function 24 when Function 39 ends. Function 39 ends. Function 24 lasts 23.5 seconds. Interrupt Function 25 or 26 occurs. Start Function 35 when Function 24 ends. Function 37 lasts 120.5 seconds. Start Function 37 concurrently with Function 35. Function 37 when Function 35 or 26 occurs. Start Function 20 when 50 or 26 occurs. Start Function 20 when Function 35 ends. Function 35 ends. Function 35 ends. Function 20 lasts	6 times during the segment, randomly select (.50) Function 25 or Functions 25 and 26 last 7 seconds each and cannot occur concurrently with Functions 20, 27, 30, or 63.	Start Segment 01 with Function 17. Function 17 lasts until end of segment.	Start Segment 01 with Function 39. Function 39 lasts 85 seconds. Interrupt Function 25 or 26 occurs. After 2.5 seconds, interrupt Function 38 and start Function 38 lasts 389.5 seconds. After Function 38 ends, finish Function 39. Interrupt Function 39. Interrupt Function 39. Start Function 24 lasts 23.5 seconds. Start Function 24 when Function 39 ends. Function 24 lasts 23.5 seconds. Start Function 24 lasts 23.5 seconds. Start Function 35 when Function 24 lasts 23.5 seconds.	Insert Function 25 each time the pilot performs Function 26 and Function 26. Functions 25 and 26 cannot occur concurrently with Functions 20, 27, 30, or 63.	Start Function 17 concurrently with Function 39. Function 17 lasts until the end of segment.
Continued			Continued		

Figure 8. Example of a CH-47D Segment Decision Rules Worksheet.

present the Segment Summary Worksheet and the Segment Decision Rules Worksheet for the segment, Before Takeoff (Assembly Area). The function, Perform Hover, used as the example throughout this report, occurs in this and several other segments.

As shown in Figure 7, the Segment Summary Worksheets list all of the functions performed by the pilot and the copilot during a mission segment. The Segment Summary Worksheets also identify the type of function (i.e., discrete fixed, discrete random, or continuous) performed by the two crewmembers and the approximate temporal arrangement of the functions within the segments. The Segment Decision Rules Worksheets contain the decision rules defining the temporal relationship between the sequence of functions performed by the pilot and the copilot and the times on the segment timeline when the functions begin and end. For example, the decision rule presented in column one of Figure 8 states that, in Segment 01, Before Takeoff (Assembly Area), the pilot begins Function 24, Perform Before Taxi Check, as soon as the copilot completes Function 39, Program Transponder. Thus, Function 24 begins at 474.5 seconds in Segment 01 (i.e., after the 389.5 seconds required for copilot Function 38 plus the 85 seconds required for copilot Function 39). Function 24 lasts 23.5 seconds; therefore, it ends 498 seconds after the segment begins (i.e., 474.5 seconds + 23.5 seconds). The Segment Summary Worksheets for the 37 unique segments are presented in Appendix H, and the Segment Decision Rules Worksheets for the 37 unique segments are presented in Appendix I.

Develop the Workload Prediction Model

The mission/task/workload analysis data entered in the Function Analysis Worksheets in Appendix E and the function and segment decision rules presented in Appendixes G and I were used to develop a computer model that will predict workload for crewmembers of the CH-47D aircraft. The analysis of workload for CH-47D crewmembers will serve two primary functions:

- identify CH-47D tasks and subsystems that are candidates for automation, and
- provide a baseline for comparing workload associated with proposed configurations of the MH-47E aircraft.

The steps that were implemented to develop the computer model consist of the following:

build task data files,

- enter decision rules into the Task Analysis/Workload (TAWL) software system, and
- generate predicted workload for the baseline CH-47D configuration.

These steps are depicted in the task-flow chart previously presented in Figure 4 and are described in detail below.

Build Task Data Files

The first step in developing the computer model was to build a series of data files from the information derived through the mission/task/workload analysis. The following specific files were established:

- · a list of unique mission segments,
- · a list of unique functions,
- a list of unique tasks,
- a list of subsystem identifiers,
- estimates of the sensory, cognitive, and psychomotor components of workload for each task, and
- · estimates of the duration of each task.

Information contained in the files serves as the data base for developing and exercising the CH-47D workload prediction model.

Enter Decision Rules into the Task Analysis/Workload Software System

The TAWL software system is the data base management system utilized for the CH-47D workload model. The task data from the Function Analysis Worksheets, the function decision rules, and the segment decision rules are entered into TAWL using the data entry routines of the system. The TAWL management system implements the conditions specified in the function decision rules to build functions from the tasks and conditions specified in the segment decision rules to build the segments from the reconstructed functions. TAWL simulates the behavior of both the pilot and the copilot during the segment and identifies all tasks performed by the two crewmembers on each half-second of the segment timeline. Instances in which two or more tasks are performed concurrently are also identified.

Generate Predicted Workload for the Baseline CH-47D Configuration

The ultimate objective of the workload prediction model is to identify instances when two or more concurrent tasks result in operator overload. In meeting this objective, the model produces estimates of total workload experienced by each crewmember at each half-second interval on the mission timeline. The model computes total workload by summing the ratings assigned during the task analysis to each workload component (i.e., visual-unaided, visual-aided, auditory, kinesthetic, cognitive, and psychomotor) of each concurrent task.

The estimates of total workload are used to identify times during the segment when the performance of concurrent tasks results in excessive workload, referred to hereafter as an "overload." Four specific indexes of overload, as defined by Aldrich, Craddock, and McCracken (1984) and Szabo and Bierbaum (1986), are employed in the model; these indexes are described in the following paragraphs.

Component overload. A total value of 8 for any given component of concurrent tasks is designated a component overload. Thus, as many as six component overloads (i.e., visual-unaided, visual-aided, auditory, kinesthetic, cognitive, and psychomotor) may occur for two or more concurrent tasks. The value 8 was chosen as the criterion for a component overload because it exceeds the maximum value on any of the workload component rating scales.

Overload condition. An overload condition exists whenever at least one component overload occurs when combining two or more concurrent tasks. In theory, as many as six component overloads may occur within a single overload condition. The concept of an overload condition is designed to identify the unique conditions within a mission segment that are associated with a component overload.

Overload density. Overload density refers to the percentage of time during a mission segment that a component overload is present. It is calculated by dividing the total number of half-second timelines with component overloads by the total number of half-second timelines in the segment. The number of timelines with component overloads is determined by counting the total number of half-second intervals with a value of 8 or more for at least one of the six workload components. Thus, if component overloads occur at 8 half-second intervals in a segment that lasts a total of 10

seconds (20 half seconds), the overload density is 40% (i.e., $8 \div 20$).

Subsystem overload. The term "subsystem overload" is used to describe the relationship between a component overload and a subsystem. To identify a subsystem overload, a tally of the component overloads associated with each subsystem is conducted for each of the mission segments. Information derived from the tallies of subsystem overloads is used to identify those subsystems that are associated with high workload.

The model was exercised for all 37 of the unique segments. Under the assumed optimal conditions, and with the pilot and copilot sharing task requirements, no overload conditions were predicted for either crewmember. Thus, the model confirms that under optimal conditions, operational crewmembers can perform the nominal CH-47D missions without encountering overload. The model provides baseline operator workload predictions during performance of the current CH-47D mission. The model can be utilized to predict workload differences resulting from modifications to the aircraft.

Generation of Workload Model for MH-47E Crewmembers

The methodology used to develop the CH-47D baseline workload model will be used to predict workload associated with proposed configurations for the MH-47E aircraft. For example, when advanced technology subsystems and automation options are proposed for the modified aircraft, new workload descriptors will be written for the affected mission tasks. Workload estimates for the new MH-47E tasks will then be generated by comparing the new workload descriptors to the verbal anchors on the workload component scales. Computer files containing the new estimates will be established, and the model will be exercised to predict the effect that the proposed automation options are likely to have on pilot and/or copilot workload. The effect of the automation options will be determined by using the four indexes of workload described The estimates of workload generated by the model for the MH-47E configuration will then be compared with those produced by the CH-47D baseline model to identify whether the proposed MH-47E system modifications are likely to increase or decrease operator workload.

CONCLUSION

The workload prediction methodology developed by ARIARDA provides a systematic means for estimating the impact that advanced technology being proposed for new aircraft and for modifications of existing aircraft may have on operator workload. Consequently, the methodology can provide information to assist engineers in making critical design decisions. The CH-47D model provides a valuable tool for making decisions so that costly changes to the MH-47E later in the system development process can be avoided.

In addition, the methodology provides information for identifying emerging manpower, personnel, and training requirements associated with the system modifications. By assisting in the identification of these requirements, the methodology provides a means for factoring total system costs into the system modification program during the early stages of development.

REFERENCES

- Aldrich, T. B., Craddock, W. P., & McCracken, J. H. (1984, October). A computer analysis to predict crew workload during LHX scout-attack missions (Technical Report ASI479-054-84, Vols I, II, and III). Fort Rucker, AL: Anacapa Sciences, Inc.
- Aldrich, T. B., Szabo, S. M., & Craddock, W. P. (1986, August). A computer analysis of LHX automation options and their effect on predicted crew workload (Technical Report ASI479-063-85). Fort Rucker, AL: Anacapa Sciences, Inc.
- Army training and evaluation program (ARTEP) for transportation helicopter battalion (ARTEP 55-167). (1983, May). Washington, DC: Department of the Army.
- Bierbaum, C. R., Szabo, S. M., & Aldrich, T. B. (1987, December). Task analysis of the UH-60 mission and decision rules for developing a UH-60 workload prediction model (Technical Report ASI690-302-87, Vols. I, II, III, and IV). Fort Rucker, AL: Anacapa Sciences, Inc.
- McCracken, J. H. & Aldrich, T. B. (1984, June). Analysis of selected LHX mission functions: Implications for operator workload and system automation goals (Technical Note ASI479-024-84). Fort Rucker, AL: Anacapa Sciences, Inc.
- Operator's manual for Army CH-47D helicopter (TM55-1520-240-10). (1982, November). Washington, DC: Department of the Army.
- Shingledecker, C. A., & Crabtree, M. S. (1982, September).

 Subsidiary radio communications tasks for workload
 assessment in R&D simulations: II. Task sensitivity
 evaluation (Technical Report). Wright-Patterson AFB,
 OH: Air Force Aerospace Medical Research Laboratory.
- Szabo, S. M., & Bierbaum, C. R. (1986, October). A comprehensive task analysis of the AH-64 mission with workload estimates and preliminary decision rules for developing an AH-64 workload prediction model (Technical Report ASI678-204-86, Vols I, II, III, and IV). Fort Rucker, AL: Anacapa Sciences, Inc.

- Szabo, S. M., Bierbaum, C. R., & Aldrich, T. B. (1987, July).

 A preliminary analysis of baseline and design goal
 timelines for AH-64 mission functions affected by ATHS
 integration (Technical Report ASI690-307-87[B]). Fort
 Rucker, AL: Anacapa Sciences, Inc.
- Wickens, C. D. (1984). <u>Engineering psychology and human</u> <u>performance</u>. Columbus, OH: Merrill.

APPENDIX A

SUMMARY OF CH-47D MISSION PHASES AND SEGMENTS

The CH-47D composite mission scenario was divided into 9 unique mission phases. Subsequently, the 9 mission phases were divided into segments. This appendix lists the 9 phases and the 71 mission segments that were derived during the CH-47D mission analysis.

```
DEPARTURE (AA) PHASE 1
     Segment 01:
                  Before Takeoff (Assembly Area)
     Segment 02:
                  Takeoff (Assembly Area)
     Segment 03:
                  Before Takeoff (Assembly Area) [NVG]
     Segment 04:
                  Takeoff (Assembly Area) [NVG]
ENROUTE (AA - PZ) PHASE 2
    *Segment 05:
                  Contour Flight
                  Contour Flight [NVG]
    *Segment 06:
                  Contour Flight (Threat)
    *Segment 07:
    *Segment 08:
                  Contour Flight (Threat) [NVG]
                  Contour Flight (Mission Change)
    *Segment 09:
    *Segment 10:
                  Contour Flight (Mission Change) [NVG]
    *Segment 11:
                  Approach
    *Segment 12:
                  Landing
    *Segment 13:
                  Approach [NVG]
    *Segment 14:
                  Landing [NVG]
DEPARTURE (PZ) PHASE 3
     Segment 15:
                  Before Takeoff (Internal Load)
    *Segment 16:
                  Takeoff
    *Segment 17:
                  Takeoff [NVG]
     Segment 18:
                  Before Takeoff (External Load)
     Segment 19:
                  Takeoff (External)
     Segment 20:
                  Before Takeoff (External Load) [NVG]
     Segment 21:
                  Takeoff (External) [NVG]
ENROUTE (PZ - LZ) PHASE 4
    *Segment 22:
                  NOE Flight
    *Segment 23:
                  NOE Flight [NVG]
    *Segment 24:
                  NOE Flight (Threat)
    *Segment 25:
                  NOE Flight (Threat) [NVG]
    *Segment 26:
                  NOE Flight (Mission Change)
    *Segment 27:
                  NOE Flight (Mission Change) [NVG]
     Segment 28:
                  Approach (LZ)
     Segment 29:
                  Landing (LZ, Internal Load)
     Segment 30:
                  Landing (LZ, External Load)
    Segment 31:
                  Approach (LZ) [NVG]
    Segment 32:
                  Landing (LZ, Internal Load) [NVG]
     Segment 33:
                  Landing (LZ, External Load) [NVG]
```

^{*}Denotes segment that occurs in more than one mission phase.

```
DEPARTURE (LZ) PHASE 5
     Segment 34:
                  Before Takeoff (LZ)
    *Segment 15:
                  Takeoff
    *Segment 17:
                  Takeoff [NVG]
ENROUTE (LZ - PZ) OR (LZ - FARP) PHASE 6
    *Segment 22:
                  NOE Flight
    *Segment 23:
                  NOE Flight [NVG]
    *Segment 24:
                  NOE Flight (Threat)
                  NOE Flight (Threat) [NVG]
    *Segment 25:
    *Segment 26:
                  NOE Flight (Mission Change)
                  NOE Flight (Mission Change) [NVG]
    *Segment 27:
    *Segment 11:
                  Approach
    *Segment 12:
                  Landing
    *Segment 13:
                  Approach [NVG]
    *Segment 14:
                  Landing [NVG]
FARP OPERATIONS PHASE 7
                  FARP Procedures
     Segment 35:
     Segment 36:
                  FARP Procedures [NVG]
     Segment 37:
                  Before Takeoff (FARP)
    *Segment 16:
                  Takeoff
    *Segment 17:
                  Takeoff [NVG]
ENROUTE (FARP - PZ) PHASE 8
    *Segment 22:
                  NOE Flight
                  NOE Flight [NVG]
    *Segment 23:
    *Segment 24:
                  NOE Flight (Threat)
                  NOE Flight (Threat) [NVG]
    *Segment 25:
                  NOE Flight (Mission Change)
    *Segment 26:
    *Segment 27:
                  NOE Flight (Mission Change) [NVG]
    *Segment 11:
                  Approach
    *Segment 12:
                  Landing
    *Segment 13:
                   Approach [NVG]
    *Segment 14:
                  Landing [NVG]
ENROUTE (PZ - AA) PHASE 9
    *Segment 05:
                  Contour Flight
    *Segment 06:
                  Contour Flight [NVG]
    *Segment 07:
                  Contour Flight (Threat)
                  Contour Flight (Threat) [NVG]
    *Segment 08:
                  Contour Flight (Mission Change)
    *Segment 09:
                   Contour Flight (Mission Change) [NVG]
    *Segment 10:
    *Segment 11:
                   Approach
    *Segment 12:
                   Landing
                   Approach [NVG]
    *Segment 13:
    *Segment 14:
                  Landing [NVG]
```

^{*}Denotes segment that occurs in more than one mission phase.

APPENDIX B

ALPHABETICAL LIST OF CH-47D UNIQUE FUNCTIONS

Each mission segment listed in Appendix A was divided into functions during the CH-47D mission analysis. Sixty-six unique functions were identified. Subsequently, the 66 unique functions were ordered in an alphabetical list and a number (1 - 66) was assigned corresponding to the ordinal position within the list. This appendix is an alphabetical list of the functions and the numerical identifiers for the functions.

NUMBER	FUNCTION		
01	Adjust Flight Parameters		
02	Adjust Flight Parameters [NVG]		
03	Check Aircraft Systems (Pilot)		
04	Compute Fuel Burn Rate		
05	Establish Approach		
06	Establish Approach [NVG]		
07	Establish Climb		
08	Establish Climb [NVG]		
09	Establish Level of Flight		
10	Establish Level of Flight [NVG]		
11	Land Aircraft		
12	Land Aircraft [NVG]		
13	Load Aircraft (Internal)		
14	Load Cargo (External)		
15	Load Cargo (External) [NVG]		
16	Mission Change		
17	Monitor Audio		
18	Monitor Threat (Pilot)		
19	Perform After Landing Check		
20	Perform Before Hover Check		
21	Perform Before Landing Check		
22	Perform Before Landing Check (LZ)		
23	Perform Before Takeoff Check		
24	Perform Before Taxi Check		
25	Perform Cockpit Communication (Copilot)		
26	Perform Cockpit Communication (Pilot)		
27	Perform External Communication		

NUMBER	FUNCTION		
28	Perform External Communication (Threat)		
29	Perform Hover		
30	Perform Hover Check		
31	Perform Hover Check [NVG]		
32	Perform Hover [NVG]		
33	Perform Navigation		
34	Perform Navigation [NVG]		
35	Perform Taxi		
36	Perform Taxi [NVG]		
37	Perform Taxiing Check		
38	Program Doppler		
39	Program Transponder		
40	Refuel Aircraft		
41	Respond to Threat		
42	Respond to Threat [NVG]		
43	Unload Aircraft (Internal)		
44	Unload Cargo (External)		
45	Update Doppler (Landmark)		
46	Update Doppler (Landmark) [NVG]		
47	Update Doppler (Mission Change)		
48	Update Doppler (PZ)		
49	Update Doppler (Stored Destination)		
50	Update Doppler (Stored Destination) [NVG]		
51	Adjust Approach Parameters		
52	Adjust Approach Parameters [NVG]		
53	Adjust Climb Parameters		
54	Adjust Climb Parameters [NVG]		
55	Adjust Level of Flight Parameters		
56	Adjust Level of Flight Parameters [NVG]		

NUMBER	FUNCTION	
57	Check Aircraft Systems (Copilot)	
58	Check Approach Parameters	
59	Check Climb Parameters	
60	Check Flight Parameters	
61	Check Fuel Consumption Parameters	
62	Check Level of Flight Parameters	
63	Establish Hover	
64	Establish Hover [NVG]	
65	Monitor Threat (Copilot)	
66	Monitor Flight Controls	

Note. Certain functions were added after the preliminary analysis was conducted. These functions appear at the end of the function list and, consequently, are not in alphabetical order within the list.

APPENDIX C

OUTLINE OF CH-47D MISSION SEGMENTS AND FUNCTIONS

A composite mission scenario was developed as the first step in the CH-47D mission/task/workload analysis. Subsequently, the CH-47D composite mission scenario was divided into nine unique mission phases. The nine mission phases subsequently were divided into segments and functions. This appendix is an outline of all the segments and functions as they occur in each of the nine mission phases throughout the entire mission scenario.

1. DEPARTURE (ASSEMBLY AREA)

- 1.1 Before Takeoff (Assembly Area)
 - 1.1.1 Program Doppler
 - 1.1.2 Program Transponder
 - 1.1.3 Perform Before Taxi Check
 - 1.1.4 Perform Cockpit Communication (Copilot)
 - 1.1.5 Perform Cockpit Communication (Pilot)
 - 1.1.6 Perform Taxi
 - 1.1.7 Perform Taxiing Check
 - 1.1.8 Monitor Audio
 - 1.1.9 Perform Before Hover Check
 - 1.1.10 Establish Hover
 - 1.1.11 Perform Hover
 - 1.1.12 Perform Hover Check
 - 1.1.13 Perform Before Takeoff Check
 - 1.1.14 Perform External Communication

1.2 Takeoff (Assembly Area)

- 1.2.1 Establish Climb
- 1.2.2 Adjust Climb Parameters
- 1.2.3 Check Climb Parameters
- 1.2.4 Establish Level of Flight
- 1.2.5 Adjust Level of Flight Parameters
- 1.2.6 Check Level of Flight Parameters
- 1.2.7 Check Fuel Consumption Parameters
- 1.2.8 Monitor Audio
- 1.2.9 Perform Cockpit Communication (Copilot)
- 1.2.10 Perform Cockpit Communication (Pilot)
- 1.2.11 Check Aircraft Systems (Pilot)
- 1.2.12 Check Aircraft Systems (Copilot)
- 1.2.13 Monitor Threat (Pilot)
- 1.2.14 Monitor Threat (Copilot)

1.3 Before Takeoff (Assembly Area) [NVG]

- 1.3.1 Program Doppler
- 1.3.2 Program Transponder
- 1.3.3 Perform Before Taxi Check
- 1.3.4 Perform Cockpit Communication (Copilot)
- 1.3.5 Perform Cockpit Communication (Pilot)
- 1.3.6 Perform Taxi [NVG]
- 1.3.7 Perform Taxiing Check
- 1.3.8 Monitor Audio
- 1.3.9 Perform Before Hover Check
- 1.3.10 Establish Hover [NVG]
- 1.3.11 Perform Hover [NVG]
- 1.3.12 Perform Hover Check [NVG]
- 1.3.13 Perform Before Takeoff Check
- 1.3.14 Perform External Communication

1.4 Takeoff (Assembly Area) [NVG]

- 1.4.1 Establish Climb [NVG]
- 1.4.2 Adjust Climb Parameters [NVG]
- 1.4.3 Check Climb Parameters
- 1.4.4 Establish Level of Flight [NVG]
- 1.4.5 Adjust Level of Flight Parameters [NVG]
- 1.4.6 Check Level of Flight Parameters
- 1.4.7 Check Fuel Consumption Parameters
- 1.4.8 Monitor Audio
- 1.4.9 Perform Cockpit Communication (Copilot)
- 1.4.10 Perform Cockpit Communication (Pilot)
- 1.4.11 Check Aircraft Systems (Pilot)
- 1.4.12 Check Aircraft Systems (Copilot)
- 1.4.13 Monitor Threat (Pilot)
- 1.4.14 Monitor Threat (Copilot)

2. ENROUTE (AA-PZ)

2.1 Contour Flight

- 2.1.1 Adjust Flight Parameters
- 2.1.2 Check Flight Parameters
- 2.1.3 Perform Navigation
- 2.1.4 Monitor Threat (Pilot)
- 2.1.5 Monitor Threat (Copilot)
- 2.1.6 Check Aircraft Systems (Pilot)
- 2.1.7 Check Aircraft Systems (Copilot)
- 2.1.8 Update Doppler (Stored Destination)
- 2.1.9 Compute Fuel Burn Rate
- 2.1.10 Update Doppler (Landmark)
- 2.1.11 Monitor Audio
- 2.1.12 Perform Cockpit Communication (Copilot)
- 2.1.13 Perform Cockpit Communication (Pilot)

2.2 Contour Flight [NVG]

- 2.2.1 Adjust Flight Parameters [NVG]
- 2.2.2 Check Flight Parameters
- 2.2.3 Perform Navigation [NVG]
- 2.2.4 Monitor Threat (Pilot)
- 2.2.5 Monitor Threat (Copilot)
- 2.2.6 Check Aircraft Systems (Pilot)
- 2.2.7 Check Aircraft Systems (Copilot)
- 2.2.8 Compute Fuel Burn Rate
- 2.2.9 Update Doppler (Stored Destination) [NVG]
- 2.2.10 Update Doppler (Landmark) [NVG]
- 2.2.11 Monitor Audio
- 2.2.12 Perform Cockpit Communication (Copilot)
- 2.2.13 Perform Cockpit Communication (Pilot)

2.3 Contour Flight (Threat)

- 2.3.1 Adjust Flight Parameters
- 2.3.2 Check Flight Parameters
- 2.3.3 Perform Navigation
- 2.3.4 Monitor Threat (Pilot)
- 2.3.5 Monitor Threat (Copilot)
- 2.3.6 Check Aircraft Systems (Pilot)
- 2.3.7 Check Aircraft Systems (Copilot)
- 2.3.8 Update Doppler (Stored Destination)
- 2.3.9 Compute Fuel Burn Rate
- 2.3.10 Respond to Threat
- 2.3.11 Perform External Communication (Threat)
- 2.3.12 Update Doppler (Landmark)
- 2.3.13 Monitor Audio
- 2.3.14 Perform Cockpit Communication (Copilot)
- 2.3.15 Perform Cockpit Communication (Pilot)

2.4 Contour Flight (Threat) [NVG]

- 2.4.1 Adjust Flight Parameters [NVG]
- 2.4.2 Check Flight Parameters
- 2.4.3 Perform Navigation [NVG]
- 2.4.4 Monitor Threat (Pilot)
- 2.4.5 Monitor Threat (Copilot)
- 2.4.6 Check Aircraft Systems (Pilot)
- 2.4.7 Check Aircraft Systems (Copilot)
- 2.4.8 Update Doppler (Stored Destination) [NVG]
- 2.4.9 Compute Fuel Burn Rate
- 2.4.10 Respond to Threat [NVG]
- 2.4.11 Perform External Communication (Threat)
- 2.4.12 Update Doppler (Landmark) [NVG]
- 2.4.13 Monitor Audio
- 2.4.14 Perform Cockpit Communication (Copilot)
- 2.4.15 Perform Cockpit Communication (Pilot)

2.5 Contour Flight (Mission Change)

- 2.5.1 Adjust Flight Parameters
- 2.5.2 Check Flight Parameters
- 2.5.3 Perform Navigation
- 2.5.4 Monitor Threat (Pilot)
- 2.5.5 Monitor Threat (Copilot)
- 2.5.6 Check Aircraft Systems (Pilot)
- 2.5.7 Check Aircraft Systems (Copilot)
- 2.5.8 Compute Fuel Burn Rate
- 2.5.9 Update Doppler (Landmark)
- 2.5.10 Mission Change
- 2.5.11 Update Doppler (Mission Change)
- 2.5.12 Monitor Audio
- 2.5.13 Perform Cockpit Communication (Copilot)
- 2.5.14 Perform Cockpit Communication (Pilot)

2.6 Contour Flight (Mission Change) [NVG]

- 2.6.1 Adjust Flight Parameters [NVG]
- 2.6.2 Check Flight Parameters
- 2.6.3 Perform Navigation [NVG]
- 2.6.4 Monitor Threat (Pilot)
- 2.6.5 Monitor Threat (Copilot)
- 2.6.6 Check Aircraft Systems (Pilot)
- 2.6.7 Check Aircraft Systems (Copilot)
- 2.6.8 Compute Fuel Burn Rate
- 2.6.9 Update Doppler (Landmark) [NVG]
- 2.6.10 Mission Change
- 2.6.11 Update Doppler (Mission Change)
- 2.6.12 Monitor Audio
- 2.6.13 Perform Cockpit Communication (Copilot)
- 2.6.14 Perform Cockpit Communication (Pilot)

2.7 Approach

- 2.7.1 Perform External Communication
- 2.7.2 Perform Before Landing Check
- 2.7.3 Establish Approach
- 2.7.4 Adjust Approach Parameters
- 2.7.5 Check Approach Parameters
- 2.7.6 Monitor Audio
- 2.7.7 Perform Cockpit Communication (Copilot)
- 2.7.8 Perform Cockpit Communication (Pilot)
- 2.7.9 Monitor Threat (Pilot)
- 2.7.10 Monitor Threat (Copilot)
- 2.7.11 Check Aircraft Systems (Pilot)
- 2.7.12 Check Aircraft Systems (Copilot)

2.8 Landing

- 2.8.1 Establish Hover
- 2.8.2 Perform Hover
- 2.8.3 Land Aircraft
- 2.8.4 Perform After Landing Check
- 2.8.5 Perform External Communication
- 2.8.6 Monitor Audio
- 2.8.7 Perform Cockpit Communication (Copilot)
- 2.8.8 Perform Cockpit Communication (Pilot)

2.9 Approach [NVG]

- 2.9.1 Perform External Communication
- 2.9.2 Perform Before Landing Check
- 2.9.3 Establish Approach [NVG]
- 2.9.4 Adjust Approach Parameters [NVG]
- 2.9.5 Check Approach Parameters
- 2.9.6 Monitor Audio
- 2.9.7 Perform Cockpit Communication (Copilot)
- 2.9.8 Perform Cockpit Communication (Pilot)

2.9 Approach [NVG] [Continued]

- 2.9.9 Monitor Threat (Pilot)
- 2.9.10 Monitor Threat (Copilot)
- 2.9.11 Check Aircraft Systems (Pilot)
- 2.9.12 Check Aircraft Systems (Copilot)

2.10 Landing [NVG]

- 2.10.1 Establish Hover [NVG]
- 2.10.2 Perform Hover [NVG]
- 2.10.3 Land Aircraft [NVG]
- 2.10.4 Perform After Landing Check
- 2.10.5 Perform External Communication
- 2.10.6 Monitor Audio
- 2.10.7 Perform Cockpit Communication (Copilot)
- 2.10.8 Perform Cockpit Communication (Pilot)

3. DEPARTURE (PZ)

3.1 Before Takeoff (Internal Load)

- 3.1.1 Update Doppler (PZ)
- 3.1.2 Load Aircraft (Internal)
- 3.1.3 Perform Cockpit Communication (Copilot)
- 3.1.4 Perform Cockpit Communication (Pilot)
- 3.1.5 Monitor Audio
- 3.1.6 Perform External Communication
- 3.1.7 Perform Before Takeoff Check

3.2 Takeoff

- 3.2.1 Establish Hover
- 3.2.2 Perform Hover
- 3.2.3 Establish Climb
- 3.2.4 Adjust Climb Parameters
- 3.2.5 Check Climb Parameters
- 3.2.6 Establish Level of Flight
- 3.2.7 Adjust Level of Flight Parameters
- 3.2.8 Check Level of Flight Parameters
- 3.2.9 Check Fuel Consumption Parameters
- 3.2.10 Monitor Audio
- 3.2.11 Perform Cockpit Communication (Copilot)
- 3.2.12 Perform Cockpit Communication (Pilot)
- 3.2.13 Check Aircraft Systems (Pilot)
- 3.2.14 Check Aircraft Systems (Copilot)
- 3.2.15 Monitor Threat (Pilot)
- 3.2.16 Monitor Threat (Copilot)

3.3 Takeoff [NVG] 3.3.1 Establish Hover [NVG] 3.3.2 Perform Hover [NVG] 3.3.3 Establish Climb [NVG] 3.3.4 Adjust Climb Parameters [NVG] 3.3.5 Check Climb Parameters 3.3.6 Establish Level of Flight [NVG] 3.3.7 Adjust Level of Flight Parameters [NVG] 3.3.8 Check Level of Flight Parameters 3.3.9 Check Fuel Consumption Parameters 3.3.10 Monitor Audio 3.3.11 Perform Cockpit Communication (Copilot) 3.3.12 Perform Cockpit Communication (Pilot) 3.3.13 Check Aircraft Systems (Pilot) 3.3.14 Check Aircraft Systems (Copilot) 3.3.15 Monitor Threat (Pilot) 3.3.16 Monitor Threat (Copilot) 3.4 Before Takeoff (External Load) 3.4.1 Update Doppler (PZ) 3.4.2 Load Aircraft (Internal) 3.4.3 Load Cargo (External) 3.4.4 Perform Cockpit Communication (Copilot) 3.4.5 Perform Cockpit Communication (Pilot)

3.5 Takeoff (External)

3.4.6

3.4.7

- 3.5.1 Establish Climb
- 3.5.2 Adjust Climb Parameters

Monitor Audio

- 3.5.3 Check Climb Parameters
- 3.5.4 Establish Level of Flight
- 3.5.5 Adjust Level of Flight Parameters
- 3.5.6 Check Level of Flight Parameters
- 3.5.7 Check Fuel Consumption Parameters
- 3.5.8 Monitor Audio
- 3.5.9 Perform Cockpit Communication (Copilot)

Perform External Communication

Perform Before Takeoff Check

- 3.5.10 Perform Cockpit Communication (Pilot)
- 3.5.11 Check Aircraft Systems (Pilot)
- 3.5.12 Check Aircraft Systems (Copilot)
- 3.5.13 Monitor Threat (Pilot)
- 3.5.14 Monitor Threat (Copilot)
- 3.6 Before Takeoff (External Load) [NVG]
 - 3.6.1 Update Doppler (PZ)
 - 3.6.2 Load Aircraft (Internal)
 - 3.6.3 Load Cargo (External) [NVG]
 - 3.6.4 Perform Cockpit Communication (Copilot)

- 3.6 Before Takeoff (External Load) [NVG] [Continued]
 - 3.6.5 Perform Cockpit Communication (Pilot)
 - 3.6.6 Monitor Audio
 - 3.6.7 Perform External Communication
 - 3.6.8 Perform Before Takeoff Check
- 3.7 Takeoff (External) [NVG]
 - 3.7.1 Establish Climb [NVG]
 - 3.7.2 Adjust Climb Parameters [NVG]
 - 3.7.3 Check Climb Parameters
 - 3.7.4 Establish Level of Flight [NVG]
 - 3.7.5 Adjust Level of Flight Parameters [NVG]
 - 3.7.6 Check Level of Flight Parameters
 - 3.7.7 Check Fuel Consumption Parameters
 - 3.7.8 Monitor Audio
 - 3.7.9 Perform Cockpit Communication (Copilot)
 - 3.7.10 Perform Cockpit Communication (Pilot)
 - 3.7.11 Check Aircraft Systems (Pilot)
 - 3.7.12 Check Aircraft Systems (Copilot)
 - 3.7.13 Monitor Threat (Pilot)
 - 3.7.14 Monitor Threat (Copilot)

4. ENROUTE (PZ-LZ)

- 4.1 NOE Flight
 - 4.1.1 Adjust Flight Parameters
 - 4.1.2 Check Flight Parameters
 - 4.1.3 Perform Navigation
 - 4.1.4 Monitor Threat (Pilot)
 - 4.1.5 Monitor Threat (Copilot)
 - 4.1.6 Check Aircraft Systems (Pilot)
 - 4.1.7 Check Aircraft Systems (Copilot)
 - 4.1.8 Compute Fuel Burn Rate
 - 4.1.9 Monitor Audio
 - 4.1.10 Perform Cockpit Communication (Copilot)
 - 4.1.11 Perform Cockpit Communication (Pilot)
- 4.2 NOE Flight [NVG]
 - 4.2.1 Adjust Flight Parameters [NVG]
 - 4.2.2 Check Flight Parameters
 - 4.2.3 Perform Navigation [NVG]
 - 4.2.4 Monitor Threat (Pilot)
 - 4.2.5 Monitor Threat (Copilot)
 - 4.2.6 Check Aircraft Systems (Pilot)
 - 4.2.7 Check Aircraft Systems (Copilot)
 - 4.2.8 Compute Fuel Burn Rate
 - 4.2.9 Monitor Audio
 - 4.2.10 Perform Cockpit Communication (Copilot)
 - 4.2.11 Perform Cockpit Communication (Pilot)

- 4.3 NOE Flight (Threat)
 - 4.3.1 Adjust Flight Parameters
 - 4.3.2 Check Flight Parameters
 - 4.3.3 Perform Navigation
 - 4.3.4 Monitor Threat (Pilot)
 - 4.3.5 Monitor Threat (Copilot)
 - 4.3.6 Check Aircraft Systems (Pilot)
 - 4.3.7 Check Aircraft Systems (Copilot)
 - 4.3.8 Compute Fuel Burn Rate
 - 4.3.9 Respond to Threat
 - 4.3.10 Monitor Audio
 - 4.3.11 Perform External Communication (Threat)
 - 4.3.12 Perform Cockpit Communication (Copilot)
 - 4.3.13 Perform Cockpit Communication (Pilot)
- 4.4 NOE Flight (Threat) [NVG]
 - 4.4.1 Adjust Flight Parameters [NVG]
 - 4.4.2 Check Flight Parameters
 - 4.4.3 Perform Navigation [NVG]
 - 4.4.4 Monitor Threat (Pilot)
 - 4.4.5 Monitor Threat (Copilot)
 - 4.4.6 Check Aircraft Systems (Pilot)
 - 4.4.7 Check Aircraft Systems (Copilot)
 - 4.4.8 Compute Fuel Burn Rate
 - 4.4.9 Respond to Threat [NVG]
 - 4.4.10 Monitor Audio
 - 4.4.11 Perform External Communication (Threat)
 - 4.4.12 Perform Cockpit Communication (Copilot)
 - 4.4.13 Perform Cockpit Communication (Pilot)
- 4.5 NOE Flight (Mission Change)
 - 4.5.1 Adjust Flight Parameters
 - 4.5.2 Check Flight Parameters
 - 4.5.3 Perform Navigation
 - 4.5.4 Monitor Threat (Pilot)
 - 4.5.5 Monitor Threat (Copilot)
 - 4.5.6 Check Aircraft Systems (Pilot)
 - 4.5.7 Check Aircraft Systems (Copilot)
 - 4.5.8 Compute Fuel Burn Rate
 - 4.5.9 Mission Change
 - 4.5.10 Update Doppler (Mission Change)
 - 4.5.11 Monitor Audio
 - 4.5.12 Perform Cockpit Communication (Copilot)
 - 4.5.13 Perform Cockpit Communication (Pilot)

- 4.6 NOE Flight (Mission Change) [NVG]
 - 4.6.1 Adjust Flight Parameters [NVG]
 - 4.6.2 Check Flight Parameters
 - 4.6.3 Perform Navigation [NVG]
 - 4.6.4 Monitor Threat (Pilot)
 - 4.6.5 Monitor Threat (Copilot)
 - 4.6.6 Check Aircraft Systems (Pilot)
 - 4.6.7 Check Aircraft Systems (Copilot)
 - 4.6.8 Compute Fuel Burn Rate
 - 4.6.9 Mission Change
 - 4.6.10 Update Doppler (Mission Change)
 - 4.6.11 Monitor Audio
 - 4.6.12 Perform Cockpit Communication (Copilot)
 - 4.6.13 Perform Cockpit Communication (Pilot)
- 4.7 Approach (LZ)
 - 4.7.1 Perform Before Landing Check (LZ)
 - 4.7.2 Establish Approach
 - 4.7.3 Adjust Approach Parameters
 - 4.7.4 Check Approach Parameters
 - 4.7.5 Monitor Audio
 - 4.7.6 Perform Cockpit Communication (Copilot)
 - 4.7.7 Perform Cockpit Communication (Pilot)
 - 4.7.8 Monitor Threat (Pilot)
 - 4.7.9 Monitor Threat (Copilot)
 - 4.7.10 Check Aircraft Systems (Pilot)
 - 4.7.11 Check Aircraft Systems (Copilot)
- 4.8 Landing (LZ Internal Load)
 - 4.8.1 Establish Hover
 - 4.8.2 Perform Hover
 - 4.8.3 Land Aircraft
 - 4.8.4 Monitor Audio
 - 4.8.5 Unload Aircraft (Internal)
 - 4.8.6 Perform Cockpit Communication (Copilot)
 - 4.8.7 Perform Cockpit Communication (Pilot)
- 4.9 Landing (LZ External Load)
 - 4.9.1 Establish Hover
 - 4.9.2 Perform Hover
 - 4.9.3 Monitor Audio
 - 4.9.4 Unload Cargo (External)
 - 4.9.5 Land Aircraft
 - 4.9.6 Unload Aircraft (Internal)
 - 4.9.7 Perform Cockpit Communication (Copilot)
 - 4.9.8 Perform Cockpit Communication (Pilot)

4.10 Approach (LZ) [NVG]

- 4.10.1 Perform Before Landing Check (LZ)
- 4.10.2 Establish Approach [NVG]
- 4.10.3 Adjust Approach Parameters [NVG]
- 4.10.4 Check Approach Parameters
- 4.10.5 Monitor Audio
- 4.10.6 Perform Cockpit Communication (Copilot)
- 4.10.7 Perform Cockpit Communication (Pilot)
- 4.10.8 Monitor Threat (Pilot)
- 4.10.9 Monitor Threat (Copilot)
- 4.10.10 Check Aircraft Systems (Pilot)
- 4.10.11 Check Aircraft Systems (Copilot)

4.11 Landing (LZ Internal Load) [NVG]

- 4.11.1 Establish Hover [NVG]
- 4.11.2 Perform Hover [NVG]
- 4.11.3 Land Aircraft [NVG]
- 4.11.4 Monitor Audio
- 4.11.5 Unload Aircraft (Internal)
- 4.11.6 Perform Cockpit Communication (Copilot)
- 4.11.7 Perform Cockpit Communication (Pilot)

4.12 Landing (LZ External Load) [NVG]

- 4.12.1 Establish Hover [NVG]
- 4.12.2 Perform Hover [NVG]
- 4.12.3 Monitor Audio
- 4.12.4 Unload Cargo (External)
- 4.12.5 Land Aircraft [NVG] 4.12.6 Unload Aircraft (Internal)
- 4.12.7 Perform Cockpit Communication (Copilot)
- 4.12.8 Perform Cockpit Communication (Pilot)

5. DEPARTURE (LZ)

5.1 Before Takeoff (LZ)

- 5.1.1 Perform Cockpit Communication (Copilot)
- 5.1.2 Perform Cockpit Communication (Pilot)
- Monitor Audio 5.1.3
- 5.1.4 Update Doppler (PZ)
- Perform Before Takeoff Check 5.1.5

5.2 Takeoff

- 5.2.1 Establish Hover
- 5.2.2 Perform Hover
- 5.2.3 Establish Climb
- 5.2.4 Adjust Climb Parameters
- 5.2.5 Check Climb Parameters
- 5.2.6 Establish Level of Flight

5.2 Takeoff [Continued]

- 5.2.7 Adjust Level of Flight Parameters
- 5.2.8 Check Level of Flight Parameters
- 5.2.9 Check Fuel Consumption Parameters
- 5.2.10 Monitor Audio
- 5.2.11 Perform Cockpit Communication (Copilot)
- 5.2.12 Perform Cockpit Communication (Pilot)
- 5.2.13 Check Aircraft Systems (Pilot)
- 5.2.14 Check Aircraft Systems (Copilot)
- 5.2.15 Monitor Threat (Pilot)
- 5.2.16 Monitor Threat (Copilot)

5.3 Takeoff [NVG]

- 5.3.1 Establish Hover [NVG]
- 5.3.2 Perform Hover [NVG]
- 5.3.3 Establish Climb [NVG]
- 5.3.4 Adjust Climb Parameters [NVG]
- 5.3.5 Check Climb Parameters
- 5.3.6 Establish Level of Flight [NVG]
- 5.3.7 Adjust Level of Flight Parameters [NVG]
- 5.3.8 Check Level of Flight Parameters
- 5.3.9 Check Fuel Consumption Parameters
- 5.3.10 Monitor Audio
- 5.3.11 Perform Cockpit Communication (Copilot)
- 5.3.12 Perform Cockpit Communication (Pilot)
- 5.3.13 Check Aircraft Systems (Pilot)
- 5.3.14 Check Aircraft Systems (Copilot)
- 5.3.15 Monitor Threat (Pilot)
- 5.3.16 Monitor Threat (Copilot)

6. ENROUTE (LZ-PZ) or (LZ-FARP)

6.1 NOE Flight

- 6.1.1 Adjust Flight Parameters
- 6.1.2 Check Flight Parameters
- 6.1.3 Perform Navigation
- 6.1.4 Monitor Threat (Pilot)
- 6.1.5 Monitor Threat (Copilot)
- 6.1.6 Check Aircraft Systems (Pilot)
- 6.1.7 Check Aircraft Systems (Copilot)
- 6.1.8 Compute Fuel Burn Rate
- 6.1.9 Monitor Audio
- 6.1.10 Perform Cockpit Communication (Copilot)
- 6.1.11 Perform Cockpit Communication (Pilot)

6.2 NOE Flight [NVG]

- 6.2.1 Adjust Flight Parameters [NVG]
- 6.2.2 Check Flight Parameters
- 6.2.3 Perform Navigation [NVG]
- 6.2.4 Monitor Threat (Pilot)
- 6.2.5 Monitor Threat (Copilot)
- 6.2.6 Check Aircraft Systems (Pilot)
- 6.2.7 Check Aircraft Systems (Copilot)
- 6.2.8 Compute Fuel Burn Rate
- 6.2.9 Monitor Audio
- 6.2.10 Perform Cockpit Communication (Copilot)
- 6.2.11 Perform Cockpit Communication (Pilot)

6.3 NOE Flight (Threat)

- 6.3.1 Adjust Flight Parameters
- 6.3.2 Check Flight Parameters
- 6.3.3 Perform Navigation
- 6.3.4 Monitor Threat (Pilot)
- 6.3.5 Monitor Threat (Copilot)
- 6.3.6 Check Aircraft Systems (Pilot)
- 6.3.7 Check Aircraft Systems (Copilot)
- 6.3.8 Compute Fuel Burn Rate
- 6.3.9 Respond to Threat
- 6.3.10 Monitor Audio
- 6.3.11 Perform External Communication (Threat)
- 6.3.12 Perform Cockpit Communication (Copilot)
- 6.3.13 Perform Cockpit Communication (Pilot)

6.4 NOE Flight (Threat) [NVG]

- 6.4.1 Adjust Flight Parameters [NVG]
- 6.4.2 Check Flight Parameters
- 6.4.3 Perform Navigation [NVG]
- 6.4.4 Monitor Threat (Pilot)
- 6.4.5 Monitor Threat (Copilot)
- 6.4.6 Check Aircraft Systems (Pilot)
- 6.4.7 Check Aircraft Systems (Copilot)
- 6.4.8 Compute Fuel Burn Rate
- 6.4.9 Respond to Threat [NVG]
- 6.4.10 Monitor Audio
- 6.4.11 Perform External Communication (Threat)
- 6.4.12 Perform Cockpit Communication (Copilot)
- 6.4.13 Perform Cockpit Communication (Pilot)

6.5 NOE Flight (Mission Change)

- 6.5.1 Adjust Flight Parameters
- 6.5.2 Check Flight Parameters
- 6.5.3 Perform Navigation
- 6.5.4 Monitor Threat (Pilot)
- 6.5.5 Monitor Threat (Copilot)

- 6.5 NOE Flight (Mission Change) [Continued]
 - 6.5.6 Check Aircraft Systems (Pilot)
 - 6.5.7 Check Aircraft Systems (Copilot)
 - 6.5.8 Compute Fuel Burn Rate
 - 6.5.9 Mission Change
 - 6.5.10 Update Doppler (Mission Change)
 - 6.5.11 Monitor Audio
 - 6.5.12 Perform Cockpit Communication (Copilot)
 - 6.5.13 Perform Cockpit Communication (Pilot)
- 6.6 NOE Flight (Mission Change) [NVG]
 - 6.6.1 Adjust Flight Parameters [NVG]
 - 6.6.2 Check Flight Parameters
 - 6.6.3 Perform Navigation [NVG]
 - 6.6.4 Monitor Threat (Pilot)
 - 6.6.5 Monitor Threat (Copilot)
 - 6.6.6 Check Aircraft Systems (Pilot)
 - 6.6.7 Check Aircraft Systems (Copilot)
 - 6.6.8 Compute Fuel Burn Rate
 - 6.6.9 Mission Change
 - 6.6.10 Update Doppler (Mission Change)
 - 6.6.11 Monitor Audio
 - 6.6.12 Perform Cockpit Communication (Copilot)
 - 6.6.13 Perform Cockpit Communication (Pilot)
- 6.7 Approach
 - 6.7.1 Perform External Communication
 - 6.7.2 Perform Before Landing Check
 - 6.7.3 Establish Approach
 - 6.7.4 Adjust Approach Parameters
 - 6.7.5 Check Approach Parameters
 - 6.7.6 Monitor Audio
 - 6.7.7 Perform Cockpit Communication (Copilot)
 - 6.7.8 Perform Cockpit Communication (Pilot)
 - 6.7.9 Monitor Threat (Pilot)
 - 6.7.10 Monitor Threat (Copilot)
 - 6.7.11 Check Aircraft Systems (Pilot)
 - 6.7.12 Check Aircraft Systems (Copilot)
- 6.8 Landing
 - 6.8.1 Establish Hover
 - 6.8.2 Perform Hover
 - 6.8.3 Land Aircraft
 - 6.8.4 Perform After Landing Check
 - 6.8.5 Perform External Communication
 - 6.8.6 Monitor Audio
 - 6.8.7 Perform Cockpit Communication (Copilot)
 - 6.8.8 Perform Cockpit Communication (Pilot)

- 6.9 Approach [NVG]
 - 6.9.1 Perform External Communication
 - 6.9.2 Perform Before Landing Check
 - 6.9.3 Establish Approach [NVG]
 - 6.9.4 Adjust Approach Parameters [NVG]
 - 6.9.5 Check Approach Parameters
 - 6.9.6 Monitor Audio
 - 6.9.7 Perform Cockpit Communication (Copilot)
 - 6.9.8 Perform Cockpit Communication (Pilot)
 - 6.9.9 Monitor Threat (Pilot)
 - 6.9.10 Monitor Threat (Copilot)
 - 6.9.11 Check Aircraft Systems (Pilot)
 - 6.9.12 Check Aircraft Systems (Copilot)
- 6.10 Landing [NVG]
 - 6.10.1 Establish Hover [NVG]
 - 6.10.2 Perform Hover [NVG]
 - 6.10.3 Land Aircraft [NVG]
 - 6.10.4 Perform After Landing Check
 - 6.10.5 Perform External Communication
 - 6.10.6 Monitor Audio
 - 6.10.7 Perform Cockpit Communication (Copilot)
 - 6.10.8 Perform Cockpit Communication (Pilot)
- 7. FORWARD AREA ARMING AND REFUELING POINT (FARP) OPERATION
 - 7.1 FARP Procedures
 - 7.1.1 Perform Taxi
 - 7.1.2 Refuel Aircraft
 - 7.1.3 Perform Before Taxi Check
 - 7.1.4 Perform Taxi
 - 7.1.5 Monitor Audio
 - 7.1.0 Perform Cockpit Communication (Copilot)
 - 7.1.7 Perform Cockpit Communication (Pilot)
 - 7.2 FARP Procedures [NVG]
 - 7.2.1 Perform Taxi [NVG]
 - 7.2.2 Refuel Aircraft
 - 7.2.3 Perform Before Taxi Check
 - 7.2.4 Perform Taxi [NVG]
 - 7.2.5 Monitor Audio
 - 7.2.6 Perform Cockpit Communication (Copilot)
 - 7.2.7 Perform Cockpit Communication (Pilot)

7.3 Before Takeoff (FARP)

- 7.3.1 Perform External Communication
- 7.3.2 Update Doppler (PZ)
- 7.3.3 Perform Before Takeoff Check
- 7.3.4 Perform Cockpit Communication (Copilot)
- 7.3.5 Perform Cockpit Communication (Pilot)
- 7.3.6 Monitor Audio

7.4 Takeoff

- 7.4.1 Establish Hover
- 7.4.2 Perform Hover
- 7.4.3 Establish Climb
- 7.4.4 Adjust Climb Parameters
- 7.4.5 Check Climb Parameters
- 7.4.6 Establish Level of Flight
- 7.4.7 Adjust Level of Flight Parameters
- 7.4.8 Check Level of Flight Parameters
- 7.4.9 Check Fuel Consumption Parameters
- 7.4.10 Monitor Audio
- 7.4.11 Perform Cockpit Communication (Copilot)
- 7.4.12 Perform Cockpit Communication (Pilot)
- 7.4.13 Check Aircraft Systems (Pilot)
- 7.4.14 Check Aircraft Systems (Copilot)
- 7.4.15 Monitor Threat (Pilot)
- 7.4.16 Monitor Threat (Copilot)

7.5 Takeoff [NVG]

- 7.5.1 Establish Hover [NVG]
- 7.5.2 Perform Hover [NVG]
- 7.5.3 Establish Climb [NVG]
- 7.5.4 Adjust Climb Parameters [NVG]
- 7.5.5 Check Climb Parameters
- 7.5.6 Establish Level of Flight [NVG]
- 7.5.7 Adjust Level of Flight Parameters [NVG]
- 7.5.8 Check Level of Flight Parameters
- 7.5.9 Check Fuel Consumption Parameters
- 7.5.10 Monitor Audio
- 7.5.11 Perform Cockpit Communication (Copilot)
- 7.5.12 Perform Cockpit Communication (Pilot)
- 7.5.13 Check Aircraft Systems (Pilot)
- 7.5.14 Check Aircraft Systems (Copilot)
- 7.5.15 Monitor Threat (Pilot)
- 7.5.16 Monitor Threat (Copilot)

8. ENROUTE (FARP-PZ)

- 8.1 NOE Flight
 - 8.1.1 Adjust Flight Parameters
 - 8.1.2 Check Flight Parameters
 - 8.1.3 Perform Navigation
 - 8.1.4 Monitor Threat (Pilot)
 - 8.1.5 Monitor Threat (Copilot)
 - 8.1.6 Check Aircraft Systems (Pilot)
 - 8.1.7 Check Aircraft Systems (Copilot)
 - 8.1.8 Compute Fuel Burn Rate
 - 8.1.9 Monitor Audio
 - 8.1.10 Perform Cockpit Communication (Copilot)
 - 8.1.11 Perform Cockpit Communication (Pilot)

8.2 NOE Flight [NVG]

- 8.2.1 Adjust Flight Parameters [NVG]
- 8.2.2 Check Flight Parameters
- 8.2.3 Perform Navigation [NVG]
- 8.2.4 Monitor Threat (Pilot)
- 8.2.5 Monitor Threat (Copilot)
- 8.2.6 Check Aircraft Systems (Pilot)
- 8.2.7 Check Aircraft Systems (Copilot)
- 8.2.8 Compute Fuel Burn Rate
- 8.2.9 Monitor Audio
- 8.2.10 Perform Cockpit Communication (Copilot)
- 8.2.11 Perform Cockpit Communication (Pilot)

8.3 NOE Flight (Threat)

- 8.3.1 Adjust Flight Parameters
- 8.3.2 Check Flight Parameters
- 8.3.3 Perform Navigation
- 8.3.4 Monitor Threat (Pilot)
- 8.3.5 Monitor Threat (Copilot)
- 8.3.6 Check Aircraft Systems (Pilot)
- 8.3.7 Check Aircraft Systems (Copilot)
- 8.3.8 Compute Fuel Burn Rate
- 8.3.9 Respond to Threat
- 8.3.10 Monitor Audio
- 8.3.11 Perform External Communication (Threat)
- 8.3.12 Perform Cockpit Communication (Copilot)
- 8.3.13 Perform Cockpit Communication (Pilot)

8.4 NOE Flight (Threat) [NVG]

- 8.4.1 Adjust Flight Parameters [NVG]
- 8.4.2 Check Flight Parameters
- 8.4.3 Perform Navigation [NVG]
- 8.4.4 Monitor Threat (Pilot)
- 8.4.5 Monitor Threat (Copilot)
- 8.4.6 Check Aircraft Systems (Pilot)

- 8.4 NOE Flight (Threat) [NVG] [Continued]
 - 8.4.7 Check Aircraft Systems (Copilot)
 - 8.4.8 Compute Fuel Burn Rate
 - 8.4.9 Respond to Threat [NVG]
 - 8.4.10 Monitor Audio
 - 8.4.11 Perform External Communication (Threat)
 - 8.4.12 Perform Cockpit Communication (Copilot)
 - 8.4.13 Perform Cockpit Communication (Pilot)
- 8.5 NOE Flight (Mission Change)
 - 8.5.1 Adjust Flight Parameters
 - 8.5.2 Check Flight Parameters
 - 8.5.3 Perform Navigation
 - 8.5.4 Monitor Threat (Pilot)
 - 8.5.5 Monitor Threat (Copilot)
 - 8.5.6 Check Aircraft Systems (Pilot)
 - 8.5.7 Check Aircraft Systems (Copilot)
 - 8.5.8 Compute Fuel Burn Rate
 - 8.5.9 Mission Change
 - 8.5.10 Update Doppler (Mission Change)
 - 8.5.11 Monitor Audio
 - 8.5.12 Perform Cockpit Communication (Copilot)
 - 8.5.13 Perform Cockpit Communication (Pilot)
- 8.6 NOE Flight (Mission Change) [NVG]
 - 8.6.1 Adjust Flight Parameters [NVG]
 - 8.6.2 Check Flight Parameters
 - 8.6.3 Perform Navigation [NVG]
 - 8.6.4 Monitor Threat (Pilot)
 - 8.6.5 Monitor Threat (Copilot)
 - 8.6.6 Check Aircraft Systems (Pilot)
 - 8.6.7 Check Aircraft Systems (Copilot)
 - 8.6.8 Compute Fuel Burn Rate
 - 8.6.9 Mission Change
 - 8.6.10 Update Doppler (Mission Change)
 - 8.6.11 Monitor Audio
 - 8.6.12 Perform Cockpit Communication (Copilot)
 - 8.6.13 Perform Cockpit Communication (Pilot)
- 8.7 Approach
 - 8.7.1 Perform External Communication
 - 8.7.2 Perform Before Landing Check
 - 8.7.3 Establish Approach
 - 8.7.4 Adjust Approach Parameters
 - 8.7.5 Check Approach Parameters
 - 8.7.6 Monitor Audio
 - 8.7.7 Perform Cockpit Communication (Copilot)
 - 8.7.8 Perform Cockpit Communication (Pilot)
 - 8.7.9 Monitor Threat (Pilot)

8.7 Approach [Continued]

- 8.7.10 Monitor Threat (Copilot)
- 8.7.11 Check Aircraft Systems (Pilot)
- 8.7.12 Check Aircraft Systems (Copilot)

8.8 Landing

- 8.8.1 Establish Hover
- 8.8.2 Perform Hover
- 8.8.3 Land Aircraft
- 8.8.4 Perform After Landing Check
- 8.8.5 Perform External Communication
- 8.8.6 Monitor Audio
- 8.8.7 Perform Cockpit Communication (Copilot)
- 8.8.8 Perform Cockpit Communication (Pilot)

8.9 Approach [NVG]

- 8.9.1 Perform External Communication
- 8.9.2 Perform Before Landing Check
- 8.9.3 Establish Approach [NVG]
- 8.9.4 Adjust Approach Parameters [NVG]
- 8.9.5 Check Approach Parameters
- 8.9.6 Monitor Audio
- 8.9.7 Perform Cockpit Communication (Copilot)
- 8.9.8 Perform Cockpit Communication (Pilot)
- 8.9.9 Monitor Threat (Pilot)
- 8.9.10 Monitor Threat (Copilot)
- 8.9.11 Check Aircraft Systems (Pilot)
- 8.9.12 Check Aircraft Systems (Copilot)

8.10 Landing [NVG]

- 8.10.1 Establish Hover [NVG]
- 8.10.2 Perform Hover [NVG]
- 8.10.3 Land Aircraft [NVG]
- 8.10.4 Perform After Landing Check
- 8.10.5 Perform External Communication
- 8.10.6 Monitor Audio
- 8.10.7 Perform Cockpit Communication (Copilot)
- 8.10.8 Perform Cockpit Communication (Pilot)

9. ENROUTE (PZ-AA)

9.1 Contour Flight

- 9.1.1 Adjust Flight Parameters
- 9.1.2 Check Flight Parameters
- 9.1.3 Perform Navigation
- 9.1.4 Monitor Threat (Pilot)
- 9.1.5 Monitor Threat (Copilot)
- 9.1.6 Check Aircraft Systems (Pilot)

9.1 Contour Flight [Continued]

- 9.1.7 Check Aircraft Systems (Copilot)
- 9.1.8 Update Doppler (Stored Destination)
- 9.1.9 Compute Fuel Burn Rate
- 9.1.10 Update Doppler (Landmark)
- 9.1.11 Monitor Audio
- 9.1.12 Perform Cockpit Communication (Copilot)
- 9.1.13 Perform Cockpit Communication (Pilot)

9.2 Contour Flight [NVG]

- 9.2.1 Adjust Flight Parameters [NVG]
- 9.2.2 Check Flight Parameters
- 9.2.3 Perform Navigation [NVG]
- 9.2.4 Monitor Threat (Pilot)
- 9.2.5 Monitor Threat (Copilot)
- 9.2.6 Check Aircraft Systems (Pilot)
- 9.2.7 Check Aircraft Systems (Copilot)
- 9.2.8 Compute Fuel Burn Rate
- 9.2.9 Update Doppler (Stored Destination) [NVG]
- 9.2.10 Update Doppler (Landmark) [NVG]
- 9.2.11 Monitor Audio
- 9.2.12 Perform Cockpit Communication (Copilot)
- 9.2.13 Perform Cockpit Communication (Pilot)

9.3 Contour Flight (Threat)

- 9.3.1 Adjust Flight Parameters
- 9.3.2 Check Flight Parameters
- 9.3.3 Perform Navigation
- 9.3.4 Monitor Threat (Pilot)
- 9.3.5 Monitor Threat (Copilot)
- 9.3.6 Check Aircraft Systems (Pilot)
- 9.3.7 Check Aircraft Systems (Copilot)
- 9.3.5 Update Doppler (Stored Destination)
- 9.3.6 Compute Fuel Burn Rate
- 9.3.7 Respond to Threat
- 9.3.8 Perform External Communication (Threat)
- 9.3.9 Update Doppler (Landmark)
- 9.3.10 Monitor Audio
- 9.3.11 Perform Cockpit Communication (Copilot)
- 9.3.12 Perform Cockpit Communication (Pilot)

9.4 Contour Flight (Threat) [NVG]

- 9.4.1 Adjust Flight Parameters [NVG]
- 9.4.2 Check Flight Parameters
- 9.4.3 Perform Navigation [NVG]
- 9.4.4 Monitor Threat (Pilot)
- 9.4.5 Monitor Threat (Copilot)
- 9.4.6 Check Aircraft Systems (Pilot)
- 9.4.7 Check Aircraft Systems (Copilot)

9.4 Contour Flight (Threat) [NVG] [Continued]

- 9.4.8 Update Doppler (Stored Destination) [NVG]
- 9.4.9 Compute Fuel Burn Rate
- 9.4.10 Respond to Threat [NVG]
- 9.4.11 Perform External Communication (Threat)
- 9.4.12 Update Doppler (Landmark) [NVG]
- 9.4.13 Monitor Audio
- 9.4.14 Perform Cockpit Communication (Copilot)
- 9.4.15 Perform Cockpit Communication (Pilot)

9.5 Contour Flight (Mission Change)

- 9.5.1 Adjust Flight Parameters
- 9.5.2 Check Flight Parameters
- 9.5.3 Perform Navigation
- 9.5.4 Monitor Threat (Pilot)
- 9.5.5 Monitor Threat (Copilot)
- 9.5.6 Check Aircraft Systems (Pilot)
- 9.5.7 Check Aircraft Systems (Copilot)
- 9.5.8 Compute Fuel Burn Rate
- 9.5.9 Update Doppler (Landmark)
- 9.5.10 Mission Change
- 9.5.11 Update Doppler (Mission Change)
- 9.5.12 Monitor Audio
- 9.5.13 Perform Cockpit Communication (Copilot)
- 9.5.14 Perform Cockpit Communication (Pilot)

9.6 Contour Flight (Mission Change) [NVG]

- 9.6.1 Adjust Flight Parameters [NVG]
- 9.6.2 Check Flight Parameters
- 9.6.3 Perform Navigation [NVG]
- 9.6.4 Monitor Threat (Pilot)
- 9.6.5 Monitor Threat (Copilot)
- 9.6.6 Check Aircraft Systems (Pilot)
- 9.6.7 Check Aircraft Systems (Copilot)
- 9.6.8 Compute Fuel Burn Rate
- 9.6.9 Update Doppler (Landmark) [NVG]
- 9.6.10 Mission Change
- 9.6.11 Update Doppler (Mission Change)
- 9.6.12 Monitor Audio
- 9.6.13 Perform Cockpit Communication (Copilot)
- 9.6.14 Perform Cockpit Communication (Pilot)

9.7 Approach

- 9.7.1 Perform External Communication
- 9.7.2 Perform Before Landing Check
- 9.7.3 Establish Approach
- 9.7.4 Adjust Approach Parameters
- 9.7.5 Check Approach Parameters
- 9.7.6 Monitor Audio

9.7 Approach [Continued]

- 9.7.7 Perform Cockpit Communication (Copilot)
- 9.7.8 Perform Cockpit Communication (Pilot)
- 9.7.9 Monitor Threat (Pilot)
- 9.7.10 Monitor Threat (Copilot)
- 9.7.11 Check Aircraft Systems (Pilot)
- 9.7.12 Check Aircraft Systems (Copilot)

9.8 Landing

- 9.8.1 Establish Hover
- 9.8.2 Perform Hover
- 9.8.3 Land Aircraft
- 9.8.4 Perform After Landing Check
- 9.8.5 Perform External Communication
- 9.8.6 Monitor Audio
- 9.8.7 Perform Cockpit Communication (Copilot)
- 9.8.8 Perform Cockpit Communication (Pilot)

9.9 Approach [NVG]

- 9.9.1 Perform External Communication
- 9.9.2 Perform Before Landing Check
- 9.9.3 Establish Approach [NVG]
- 9.9.4 Adjust Approach Parameters [NVG]
- 9.9.5 Check Approach Parameters
- 9.9.6 Monitor Audio
- 9.9.7 Perform Cockpit Communication (Copilot)
- 9.9.8 Perform Cockpit Communication (Pilot)
- 9.9.9 Monitor Threat (Pilot)
- 9.9.10 Monitor Threat (Copilot)
- 9.9.11 Check Aircraft Systems (Pilot)
- 9.9.12 Check Aircraft Systems (Copilot)

9.10 Landing [NVG]

- 9.10.1 Establish Hover [NVG]
- 9.10.2 Perform Hover [NVG]
- 9.10.3 Land Aircraft [NVG]
- 9.10.4 Perform After Landing Check
- 9.10.5 Perform External Communication
- 9.10.6 Monitor Audio
- 9.10.7 Perform Cockpit Communication (Copilot)
- 9.10.8 Perform Cockpit Communication (Pilot)

A P P E N D I X D ALPHABETICAL LIST OF CH-47D UNIQUE TASKS

During the CH-47D mission/task/workload analysis, each of the 66 functions was divided into tasks. A task defines a specific crew activity that is essential to the successful performance of the selected function. A total of 154 unique tasks was identified for the 66 functions. This appendix is an alphabetical list of the 154 tasks with assigned task numbers.

TASK NUMBER	VERB	OBJECT
001	Receive	Acknowledgment
002	Transmit	Acknowledgment
003	Set	AFCS ALT Switch
004	Perform	AFCS Check (Hover)
005	Perform	AFCS Check (Hover) [NVG]
006	Set	AFCS HDG Switch
007	Set	AFCS SEL Switch
008	Maneuver	Aircraft Across Landmark
009	Maneuver	Aircraft Across Landmark [NVG]
010	Verify	Aircraft Location
011	Verify	Aircraft Location [NVG]
012	Control	Airspeed
013	Check	Airspeed Indicator (Inflight)
014	Change	Airspeed Quickly
015	Change	Airspeed Quickly [NVG]
016	Control	Airspeed [NVG]
017	Check	Altimeter (Inflight)
018	Adjust	Altitude
019	Control	Altitude
020	Change	Altitude Sharply
021	Change	Altitude Sharply [NVG]
022	Adjust	Altitude [NVG]
023	Control	Altitude [NVG]
024	Set	ANT Switch
025	Adjust	Attitude
026	Control	Attitude

TASK NUMBER	VERB	OBJECT
027	Adjust	Attitude [NVG]
028	Control	Attitude [NVG]
029	Monitor	Audio
030	Check	Brakes (Copilot)
031	Check	Brakes (Pilot)
032	Compute	Burn Out
033	Set	Cargo Hook Master Switch
034	Press	Cargo Release Button
035	Receive	Communication (Copilot)
036	Transmit	Communication (Copilot)
037	Receive	Communication (Crew Chief)
038	Transmit	Communication (Crew Chief)
039	Receive	Communication (Pilot)
040	Transmit	Communication (Pilot)
041	Check	Coordinates
042	Сору	Coordinates
043	Set	Countermeasure Switch
044	Follow	Course
045	Follow	Course [NVG]
046	Check	Crew
047	Check	Cyclic Trim Indicator
048	Check	Cyclic Trim Switch
049	Set	DEST DISP Thumbwheel
050	Check	Direction Display
051	Press	Doppler Data Entry Key
052	Check	Doppler Dim Switch
053	Check	Doppler Display
054	Monitor	Doppler Display
055	Set	Doppler Display Selector Switch

TASK NUMBER	VERB	OBJECT
056	Press	Doppler KYBD Key
057	Enter	Doppler Magnetic Variation
058	Set	Doppler Mode Switch
059	Check	Doppler Panel Lights
060	Enter	Doppler Spheroid Data
061	Enter	Doppler Zone Data
062	Control	Drift
063	Control	Drift [NVG]
064	Check	Engine Instruments
065	Check	Engine Instruments (Hover)
066	Press	Flare Dispenser Switch
067	Set	Flare Dispenser Switch
068	Neutralize	Flight Controls
069	Check	Flight Controls (Hover)
070	Check	Flight Controls (Hover) [NVG]
071	Check	Flight Instruments (Hover)
072	Set	FLY-TO-DEST Switch
073	Control	Forward Motion (Taxi)
074	Control	Forward Motion (Taxi) [NVG]
075	C. eck	Fuel Flow Indicator
076	Check	Fuel Quantity Indicator
077	Monitor	Fuel Quantity Indicator
078	Perform	Hard Turns
079	Perform	Hard Turns [NVG]
080	Adjust	Heading
081	Control	Heading
082	Control	Heading (Taxi)
083	Control	Heading (Taxi) [NVG]
084	Check	Heading Indicator (Inflight)

TASK NUMBER	VERB	OBJECT
085	Adjust	Heading [NVG]
086	Control	Heading [NVG]
087	Perform	HIT Check
088	Check	Hook Open Light
089	Set	Hook Select Switch
090	Verify	Load Hookup
091	Verify	Load on Ground
092	Verify	Load Released
093	Check	Load Secure
094	Verify	Load Secure
095	Monitor	Loading
096	Set	M-1 Switch
097	Set	M-1 Test Switch
098	Set	M-2 Switch
099	Set	M-2 Test Switch
100	Set	M-3 Switch
101	Set	M-3 Test Switch
102	Set	M-C Switch
103	Set	M-C Test Switch
104	Read	Maps
105	Check	Master CAUTION/WARNING Panel
106	Set	Master Switch (Transponder)
107	Receive	Message
108	Transmit	Message
109	Transmit	Message (Brief)
110	Note	Message Alert
111	Set	Mode 1 Code
112	Set	Mode 3A Code
113	Set	Mode 4 Switch

TASK NUMBER	VERB	OBJECT
114	Check	Obstacle Clearance
115	Maintain	Obstacle Clearance
116	Check	Obstacle Clearance [NVG]
117	Maintain	Obstacle Clearance [NVG]
118	Check	Park Brake
119	Release	Park Brake
120	Set	Park Brake
121	Set	Park Brake Lever
122	Check	Park Brake Light
123	Adjust	Power
124	Perform	Power Check (Hover)
125	Check	Power Steering
126	Adjust	Power [NVG]
127	Check	Radios
128	Control	Rate of Climb
129	Control	Rate of Climb [NVG]
130	Control	Rate of Descent
131	Control	Rate of Descent [NVG]
132	Check	Refueling Complete
133	Check	Reply Light
134	Check	Rotor RPM
135	Check	Route
136	Check	Swivel Switch
137	Set	Swivel Switch
138	Set	Target Storage Switch
139	Check	Test Light
140	Check	Test/MON Light
141	Detect	Threat
142	Note	Time

TASK NUMBER	VERB	OBJECT
143	Perform	Touchdown
144	Perform	Touchdown [NVG]
145	Set	Transmitter Selector Switch
146	Adjust	Trim
147	Check	Trim Ball (Inflight)
148	Adjust	Trim [NVG]
149	Monitor	Unloading
150	Verify	Unloading Complete
151	Enter	UTM Coordinates
152	Check	Vertical Situation Indicator (Inflight)
153	Check	% TRQ Indicator (Inflight)
154	Monitor	Flight Controls

APPENDIX E

CH-47D FUNCTION ANALYSIS WORKSHEETS

During the CH-47D mission/task/workload analysis, descriptive information was compiled for each of the 154 unique tasks. The descriptive information for each task was compiled on a Function Analysis Worksheet using a standardized format. This appendix contains the Function Analysis Worksheet for each of the 66 unique functions. The Function Analysis Worksheets provide the following information:

- function name,
- function number,
- total time of function,
- · task identifiers with verb and object,
- task numbers,
- subsystems associated with each task,
- verbal descriptors of sensory components and workload ratings,
- verbal descriptors of cognitive components and workload ratings,
- verbal descriptors of psychomotor components and workload ratings,
- descriptions of switches if used to perform the tasks, and
- times required to perform the tasks.

Continuous*

TOTAL TIME (Approximate)

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 01 Adjust Flight Parameters

	TASKS			WORKLOAD	OAD COMPONENTS	s		DURATION	₹
VERB	OBJECT	TASK #	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH	DISCRETE	TE,
Control	Attitude	P026	Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		ro.	
Adjust	Altitude	P018	Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		ĸ.	
Control	Airspeed	P012	Fight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		κ	
Adjust	Рожег	P123	Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		ro.	
Adjust	Heading	P080	Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		ĸ,	
Adjust	Ting	P146	Flight Control (FC)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		ru.	
Maintain	Obstacle Clearance	P115	Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Orient Aircraft K-4/V-3.7	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		w.	

*The total time for the function will vary depending on the length of the segment.

FUNCTION 02 Adjust Flight Parameters [NVG]

Continuous*

	TASKS			WORKLOAD	OAD COMPONENTS	S		DURATION (SECONDS)	NOI NDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS	ETE/ Jous
Control	Attitude [NVG]	P028	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	
Adjust	Attitude [NVG]	P022	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	
Control	Airspeed [NVG]	P016	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	
F-3	Power [NVG]	P126	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P.2.6		-	
Adjust	Heading [NVG]	P085	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	
Adjust	Trim [NVG]	P148	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	
Maintain	Obstacle Clearance [NVG]	P117	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Orient Aircraft K-4/G-5	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	

*The total time for the function will vary depending on the length of the segment.

10.5 Seconds	DURATION (SECONDS)	DISCRETE/ CONTINUOUS	I O	-	-	m
TOTAL TIME (Approximate)		SWITCH DESCRIPTION				
TOTAL TIME		PSYCHOMOTOR				
	AD COMPONENTS	COGNITIVE	interpret Sensory and Symbolic Readouts and Verify Correct Status (Readouts Within Limits) C-3.7	Venify Correct Status (No Lights Illuminated) C-1.2		Interpret Symbolic Readout (Quantity) and Make Judgment (Enough Fuel) C-4.6
	WORKLOAD	SENSORY	Visually inspect instrument indications	Visually Inspect and Register Lights V-1		Visually Inspect Instrument Indication V-4
		SUBSYSTEM(S)	B064 Engine Instruments (EIN)	B105 Advisory (UAD)		
(Pilot)		TASK	B064	B105	_	8076 Fuel (EF)
03 Check Alrorat Systems (Pitot)	TASKS	OBJECT	Engine Instruments	Master CAUTION/WARNING Panel		Fuel Quantity Indicator
FUNCTION		VERB	Check	Check	_	Check

Compute Fuel Burn Rate

3

FUNCTION

45 Seconds

FUNCTION 05 Establish Approach

4.5 Seconds

	TASKS			WORKLOAD	OAD COMPONENTS	စ		DURATION
VERB	OBJECT	TASK *	SUBSYSTEN: 1)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Check	% TRO Indicator (inflight)	P153	Engine Instruments (EIN)	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verify Correct Status (Readout Within Limits C-3.7	Control Pressure P-2.6		-
Adjust	p-wer	P123	Fight Control External Visual Field V	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed)	Control Pressure P-2.6		-
E-6	% TRO Indicator (Inflight)	P153	Engine Instruments	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verity Correct Status (Readout Within Limits C-3.7	P-2.6		-

5.5 Seconds

TOTAL TIME (Approximate)

CH-47 FUNCTION ANALYSIS WORKSHEET

Establish Approach [NVG]

FUNCTION 06

DURATION (SECONDS)	DISCRETE/ CONTINUOUS			
SEC(DISCI	+	~	-
	SWITCH DESCRIPTION			
S	PSYCHOMOTOR	Control Pressure P-2.6	Control Pressure P-2.6	P-2.6
DAD COMPONENTS	COGNITIVE	Interpret Readout and Verify Correct Status (Readout Within Limits C-3.7	Make Conditioned Association (Adjustment Needed) C-1	Interpret Readout and Verify Correct Status (Readout Within Limits C-3.7
WORKLOAD	SENSORY	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Feel Control Movements/Visually Check Instrument Indications K-4/V-4
	SUBSYSTEM(S)	Engine Instruments (EIN)	Flight Control/Night Vision Goggles (FC/VG)	P153 (EIN)
	TASK	P153	P126	P153
TASKS	овлест	% TRQ Indicator (Inflight)	Power [NVG]	% TRO Indicator (Inflight)
	VERB	Check	Adjust	Chack

FUNCTION 07 Establish Climb

4.5 Seconds

	TASKS			WORKLOAD	LOAD COMPONENTS	118		DURATION (SECONDS)
VERB	овлест	TASK #	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Check	% TRQ Indicator (Inflight)	P153	Engine Instruments (E!N)	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verify Correct Status (Readout Within Limits C-3.7	Control Pressure P-2.6		-
Adjust	Power	P123	Flight Control/ External Visual Field (FC/VEX)	el Control Movements/ sually Detect Aircraft overnent	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-
Chack	% TRO Indicator (Inflight)	F 253	Engine Instruments	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verify Correct Status (Readout Within Limits C-3.7	P-2.6		_

FUNCTION 08 Establish Climb [NVG]

5.5 Seconds

	DURATION (SECONDS)	DISCRETE/ CONTINUOUS			
-			-	<u> </u>	
		SWITCH DESCRIPTION			
	SLI	PSYCHOMOTOR	Control Pressure P-2.6	Control Pressure P-2.6	P-2.6
	OAD COMPONEN	COGNITIVE	Interpret Readout and Verify Correct Status (Readout Within Limits C-3.7	Make Conditioned Association (Adjustment Needed) C-1	Interpret Readout and Verify Correct Status (Readout Within Limits C-3.7
	WORKLO	SENSORY	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Visually Check Instrument Indications K-4/V-4
		SUBSYSTEM(S)	Engine Instruments (EIN)	Flight Control/Night Vision Goggles (FC/VG)	P153 Engine Instruments (EIN)
		TASK	P153	P126	P153
	TASKS	OBJECT	% TRQ Indicator (Inflight)	Power [NVG]	% TRO Indicator (Inflight)
		VERB	Check	Adjust	СРФСК

FUNCTION 09 Establish Level of Flight

6 Seconds

	TASKS			WORKLOAD	LOAD COMPONENTS	ITS		DURATION (SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Adjust	Attitude	P025	Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-
Check	% TRQ Indicator (Inflight)	P153	Engine Instruments (EIN)	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verify Correct Status (Readout Within Limits) C-3.7	Control Pressure P-2.6		-
Adjust	Power	P123	Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-
Check	% TRO Indicator (Inflight)	P153	Engine Instruments (EIN)	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verify Correct Status (Readout Within Limits) C-3.7	Control Pressure P.2.6		·
								

7 Seconds

of Flight (NVG)
Establish Level
9
FUNCTION

DURATION (SECONDS)	DISCRETE/ CONTINUOUS	-		8	-
	SWITCH DESCRIPTION CO				
S	PSYCHOMOTOR	Control Pressure P-2.6	Control Pressure P-2.6	Control Pressure P-2.6	P-2.6
OAD COMPONENT	COGNITIVE	Make Conditioned Co Association (Adjustment P-2 Needed)	Interpret Readout and Contro Verity Correct Status P-2.6 (Readout Within Limits)	Make Conditioned Association (Adjustment P-2 Needed) C-1	Interpret Readout and Co Verify Correct Status P-2 (Readout Within Limits) C-3.7
WORKL	SENSORY	Feel Control Movements/ N Visually Detect Aircraft A Movement N K-4/G-1	Feel Control h. vements/ In Visually Check Instrument Vindications K-4/V-4	Feel Control Movements/ Nisually Detect Aircraft A Movement K-4/G-1	Feel Control Movements/ In Visually Check Instrument Vindications K-4/V-4
	SUBSYSTEM(S)	Flight Control/Night Vision Goggles (FC/VG)	Engine Instruments (EIN)	Flight Control/Night Vision Goggles (FC/VG)	(EIN)
TASK **		P027	P153	P126	P153
TASKS	OBJECT	Attitude [NVG]	% TRQ Indicator (Inflight)	Power [NVG]	% TRO Indicator (Inflight)
	VERB	Adjust	Check	Adjust	₹ 5 E-11

TOTAL TIME (Approximate) 13.5 Seconds*

面
Ŧ
ឆ
¥
Œ
0
Ž
~
SIS WOF
ທ
7,
₹
Ž
⋖
Z
ō
CTION ANALYS!
CH-47 FUNCTIC
ž
5
ū
$\overline{}$
4
I
ပ

FUNCTION 11 Land Alteraft

	TASKS			WORKLOA	D COMPONENT	တ		DURATION (SECONDS)	N (SO
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS	TE/ OUS
Maintain	Obstacle Clearance	P115	Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Orient Aircraft K-4/V-3.7	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		ιν.	
Adjust	Power	P123	Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		ιν	
Control	Attitude	P026	Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		rv.	
E-12	Heading	P081	Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		ν.	
Control	Drift.	P062	Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		ις.	
Perform	Touchdown	P143	Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Orient Aircraft K-4/V-3.7	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		m	
Check	Obstacle Clearance	41:0	(VEX)	Visually Register Obstacles Make Conditioned Association (Aircraf C-1	Make Conditioned Association (Aircraft Clear) C-1			-	

*Since some of the tasks are performed randomly, the total time for the function is greater than the sum of the length of the individual tasks.

44 Seconds*

TOTAL TIME (Approximate)

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 12 Land Alicanti (NVG)

	TASKS			WORKLOAD	SAD COMPONENTS	S		DURATION	7
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH	(SECONDS) DISCRETE/ CONTINUOUS	6 22 S
Maintain	Obstacle Clearance [NVG]	P117	Flight Control/ Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Orient Aircraft K-4/G-5	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	
Adjust	Power [NVG]	P126	Flight Control/ Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement and Monitor Instrument Indications K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	
E-1	Attitude [NVG]	P028	Flight Control/ Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement and Monitor Instrument Indications K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	
Control	Heading [NVG]	P086	Flight Control/ Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement and Monitor Instrument Indications K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	
Control	Drift [NVG]	P063	Flight Control/ Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	
Perform	Touchdown [NVG]	P144	Flight Control/ Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Orient Aircraft K-4/G-5	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		ဟ	
Check	Obstade Clearance [NVG]	C116	C116 Night Vision Goggles (VG)	Visually Register Obstacles Make Conditioned G-1 C-1	Make Conditioned Association (Aircraft Clear) C-1			n	

*Since some of the tasks are performed randomly, the total time for the function is greater than the sum of the length of the individual tasks.

FUNCTION 13 Load At smit (intermet)

73 Seconds

NO F	ETE/ UOUS				
DURATION	(SECONDS) DISCRETE/ CONTINUOUS	09	'n	က	Ф.
	SWITCH DESCRIPTION			Springloaded Toggle - 3 Positions	
S	PSYCHOMOTOR	Move Head P-2.6		Press Switch and Speak P-2.2	
AD COMPONENTS	COGNITIVE	Verify Correct Procedure C-1.2	Decode Message (C-5.3	Encode Message (Ramp/ Door Check) C-5.3	Decode Message C-5.3
WORKLOAD	SENSORY	Visually Scan Cargo Compartment V-7	Receive Auditory Message A-4.9	Receive Speech Feedback Encode Message (Ramp/ A-4.3 C-5.3 C-5.3	Receive Auditory Message A-4.9
	SUBSYSTEM(S)	Cargo (UCA)	C094 Communication (UC)	B038 Communication (UC)	B037 Communication (UC)
	TASK	C095	C094		
TASKS	OBJECT	Loading	Load Secure	Communication (Crewchief)	Communication (Crewchief)
	VERB	Monitor	Verify	Transmit	Receive

CH-47 FUNCTION ANALYSIS WORKSHEET

e) 250 Seconds	DURATION (SECONDS)		ns snc	2	-	-		-	t.	. v. v.
TOTAL TIME (Approximate)		SWITCH	Toggle - 2 Positions (T-2)	Rotary - 5 Positions (R-5)						
TOTAL	ø	PSYCHOMOTOR	Move Switch P-2.2	Turn Switch P-5.8	Control Pressure P-2.6	Control Pressure P-2.6		Control Pressure P-2.6	Control Pressure P-2.6 Control Pressure P-2.6	Control Pressure P-2.6 Control Pressure P-2.6 Control Pressure P-2.6
	SAD COMPONENTS	COGNITIVE	Decide Correct Position (ARM) C-1.2	Decide Correct Position C-1.2	Interpret Readout and Verify Correct Status (Readout Within Limits C-3.7	Make Conditioned Association (Adjustment Needed) C-1		Interpret Readout and Verify Correct Status (Readout Within Limits C-3.7	Interpret Readout and Verify Correct Status (Readout Within Limits C-3.7 Make Conditioned Association (Adjustment Needed)	Interpret Readout and Verify Correct Status (Readout Within Limits C-3.7 Make Conditioned Association (Adjustment Needed) C-1 Make Conditioned Association (Adjustment Needed)
	WORKLOAD	SENSORY	Visually Check Switch Position and Placement of Switch V-4	Visually Check Switch Position and Placement of Switch V-4	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1		Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4 Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4 Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1 Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1
		SUBSYSTEM(S)	Cargo (UCA)	C089 Cargo (UCA)	Engine Instruments (EIN)	Flight Control/ External Visual Field (FC/VEX)		Engine Instruments (EIN)	Engine Instruments (EIN) Flight Control/ External Visual Field (FC/VEX)	Engine Instruments (EIN) Flight Control/ External Visual Field (FC/VEX) Flight Control/ External Visual Field (FC/VEX)
		TASK *	C033	6800	P153	P123	_	P153	P153	P019 P026 P026
14 Load Cargo (External)	TASKS	OBJECT	Cargo Hook Master Switch	Hook Select Switch	% TRO Indicator (Inflight)	Power		% I HQ indicator (inflight)	% I HQ Indicator (Inflight) Altitude	% THO indicator (inflight) Altitude Attitude
FUNCTION		VERB	Set	Set	Check	Adjust		Check		

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 14 Load Cargo (External) [Continued]

NO.	TE/ Jous		<u> </u>	
DURATION (SECONDS)	DISCRETE/ CONTINUOUS	ĸ.	<u> </u>	თ
	SWITCH DESCRIPTION			
_ω	PSYCHOMOTOR	Control Pressure P-2.6		
AD COMPONENTS	COGNITIVE	Make Conditioned Association (Adjustment Needed) C-1	Decode Message C-5.3	Decode Message and Veniy Correct Status (Hook Light Extinguished) C-3.7
WORKLOAD	SENSORY	eel Control Movements/ fisually Detect Aircraft Movement (-4/V-1	Receive Auditory Message I	A-4.9
	SUBSYSTEM(S)	Flight Control/ External Visual Field (FC/VEX)	B037 Communication (UC)	(UC)
	TASK #	P062	B037	9600 9600
TASKS	OBJECT	Drift	Communication (Crewchief)	Load Hookup
	VERB	Control	Receive	Venity

350 Seconds

TOTAL TIME (Approximate)

FUNCTION 15 Load Cargo (Externet) [NVG]

	TASKS			WORKLOAD	OAD COMPONENTS	w		DURATION	DURATION (SECONDS)
VERB	OBJECT	TASK #	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWTCH DESCRIPTION	DISCRETE/ CONTINUOUS	ETE/ IUOUS
Set	Cargo Hook Master Switch	C033	Cargo (UCA)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (ARM) C-1.2	Move Switch P-2.2	Toggle - 2 Positions (T-2)		
Set	Hook Select Switch	C089	Cargo (UCA)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position C-1.2	Tum Switch P-5.8	Rotary - 5 Positions (R-5)	4	
Check	% TRQ In Jicator (Inflight)	P153	Engine Instruments (EIN)	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verify Correct Status (Readout Within Limits C-3.7	Control Pressure P-2.6		-	
Adjust	Power [NVG]	P126	P126 Flight Control/Night Vision Goggles (FC/NG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		N	
Check	% TRO Indicator (Inflight)	P153	P153 Engine Instruments (EIN)	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verify Correct Status (Readout Within Limits C-3.7	Control Pressure P-2.6		-	
Control	Altitude [NVG]	P023	P023 Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	
Control	Attitude [NVG]	P028	P028 Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	
Control	Heading [NVG]	P086	P086 Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Veeded) (-1	Control Pressure P-2.6		-	

FUNCTION 15 Load Cargo (External) [NVG] [Continued]

DURATION (SECONDS)	DISCRETE/ CONTINUOUS		© 	
DUR	DISC	-		m
	SWITCH DESCRIPTION			
S	PSYCHOMOTOR	Control Pressure P-2.6		
DAD COMPONENTS	COGNITIVE	Make Conditioned Association (Adjustment Needed) C-1	Decode Message C-5.3	Decode Message and Verify Correct Status (Hook Light Extinguished) C-3.7
WORKLOAD	SENSORY	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Receive Auditory Message A-4.9	Receive Auditory Message
	SUBSYSTEM(S)	Flight Control/Night Vision Goggles (FC/VG)	B037 Communication (UC)	C090 Communication (UC)
	TASK	P063		06 C)
TASKS	OBJECT	Drin (NVG)	Communication (Crewchief)	Load Hookup
	VERB	Control	Receive	4 eui

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION	16 Mission Change					TOTAL TII	TOTAL TIME (Approximete)	74.5 Seconds
	TASKS			WORKLOA	D COMPONEN	1.8		DURATION (SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
No N	Message Alert	C110	C110 Communication (UC)	Attend to Sound A-4.2	Decode Message C-5,3			2
Sø t	Transmitter Selector Switch	C145	C145 Communication (UC)	Visually Check Switch Position and Monitor Placement of Switch V-4	Evaluate Position Options Turn & and Decide Desired Position P-5.8 C-4.6	Switch	Rotary - 7 Positions (R-7)	-
Transmit	Acknowledgment	C002	C002 Communication (UC)	Receive Speech Feedback Encode Message A-4.3		Press Switch and Speak P-2.2	Springloaded Toggle - 3 Positions (SPT-3)	ო
% 00 00 00	Coordinates	C042	C042 Communication (UC)	Receive Auditory Message A-4.9	Decode Message C-5.3	Write Information P-6.5		12
Transmit	Acknowledgment	C002	C002 Communication (UC)	Receive Speech Feedback Encode Message A-4.3		Press Switch and Speak P-2.2	Springloaded Toggle - 3 Positions (SPT-3)	Ф.
Check	Coordinates	C041	C041 Navigation Control (NC)	Read Map Symbols V-5.9	Interpret Map Symbols and II Make Judgment (Location Correct) C-6.8	Handle Maps P-4.6		10
Check	Route	C135	Navigation Control (NC)	Read Map Symbols V-5.9	Interpret Map Symbols and I Make Judgment (Best Route) C-6.8	Handle Maps P-4.6		0

NO.	TE	©
DURAT (SECOI	DISCRECONTINE	
478	PSYCHOMOTOR	
	COGNITIVE	Recognize Auditory Signal C-1
WORKI	SENSORY	Register Sound
		Communication/ Survivability (UC/US)
	TASK	B029
TASKS	OBJECT	Audio
	VERB	Monitor E-50
	WORKLOAD COMPONENTS	TASKS WORKLOAD COMPONEN TASK SUBSYSTEM(S) SENSORY COGNITIVE

*The total time for this function varies with the segment in which the function occurs.

CH-47 FUNCTION ANALYSIS WORKSHEET

spu	zΰ	US US		©				 	-	
3.5 Seconds	DURATION (SECONDS)	CRETI								
6	DOI:	DISCRETE/ CONTINUOUS	б							
ete)										
roxim		SWITCH DESCRIPTION								
(App		S DESC								
TOTAL TIME (Approximate)	-									
TOTA		m.		_						
		PSYCHOMOTOR		Control Pressure P-2.6						
		УСНО		atrol P.						
	13	PS		8 %				 		
	COMPONENTS		Recognize Visual Signal (Threat Present) C-3.7	_						
ļ	P O		Visual sent)	Make Conditioned Association C-1						
		COGNITIVE	gnize at Pre	S Cond						
	0 A C	90	Hecc (Thre	Make Asso C-1		***				
	WORKLOAD									;
	>		Detect Visual Image V-1	peuo						
		ОВУ	Visual	Conditi						
		SENSORY	Detect V-1	Make Conditioned Association K-1						
		(S)								
		'STEM	bility	ontro						
		SUBSYSTEM(S)	Surviva (US)	Flight Control (FC)						
Ī		TASK	B050 Survivability (US)	P154		•		 		
<u>ş</u>										
Monitor Threat (Pilot)										
f of			Display	trols						
	TASKS	OBJECT	Direction Display	Flight Controls						
=	-	Ö	iā	<u>. Ĕ</u>		· · · · · · · · · · · · · · · · · · ·		 		
FUNCTION		۾	¥	Monitor						
2		VERB	Check	M M	F-2			 		

TOTAL TIME (Approximate)

FUNCTION 19 Perform After Landing Check

	TION SNDS)	TETE/					
	DURATION (SECONDS)	DISCRETE/ CONTINUOUS	S	N	-	8	-
		SWITCH DESCRIPTION		Rotary - 5 Positions (R-5)	Toggle - 3 Positions (T-3)	Rotary - 4 Positions (R-4)	
	Ø	PSYCHOMOTOR	Control Pressure P-2.6	Turn Switch P-5.8	Move Switch P-2.2	Tum Switch P-5.8	
***************************************	SAD COMPONENTS	COGNITIVE	Make Conditioned Association (Controls Neutralized) C-1.2	Decide Correct Position and Verify Correct Status C-1.2	Decide Correct Position and Verify Correct Status C-1.2	Decide Correct Position and Verify Correct Status C-1.2	Decide Correct Position and Verify Correct Status (GND) C-1.2
	WORKLOAD	SENSORY	Feel Control Movements K-4	Visually Check Switch Positions and Placement of Switch V-4	Visually Check Switch Positions and Placement of Switch	Visually Check Switch Position and Placement of Switch	Visually Check Switch Positions and Placement of Switch V-4
		SUBSYSTEM(S)	Flight Control (FC)	Flight Control (FC)		C106 Survivability (US)	(FC)
		TASK	P068	C007	C137 Gear (FG)	C106	C047
	TASKS	OBJECT	Flight Controls	AFCS SEL Switch	Swivel Switch	Master Switch (Transponder)	Cyclic Trim Indicator
		VER8	Neutralize	Set	Sat	Sət	Check

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 21 Perform Before Landing Check

39 Seconds

DURATION (SECONDS)	DISCRETE/ CONTINUOUS								
DUR (SEC	DISC	5	S	ო	-	N	^	-	-
	SWITCH DESCRIPTION							Toggle - 2 Positions (T-2)	Safety Toggle - 2 Positions (ST-2)
an and an	PSYCHOMOTOR							Move Switch P-2.2	Move Switch P-2.2
DAD COMPONENTS	COGNITIVE	Interpret Sensory and Symbolic Readouts and Verify Correct Status (100%)	Interpret Sensory and Symbolic Readouts and Verify Correct Status (Readouts Within Limits) C-3.7	Interpret Symbolic Readout (Quantity) and Make Judgment (Enough Fuel) C-6.8	Verify Correct Status (All Lights Extinguished) C-1.2	Interpret Symbolic Readouts and Verify Correct C-5.3	Verify Current Position Correct (Unlocked) C-2	Decide Correct Position (Off) and Verify Correct Status (Light Extinguished) C-1.2	Decide Correct Position (SAFE) and Verify Correct Status (Light Extinguished) C-1.2
WORKLOAD	SENSORY	Visually inspect instrument Indications V-4	Visually Inspect Instrument Indications V-4	Visually Inspect Instrument Indications V-4	Visually Scan and Register ghts	Visually Scan Dial Indications V-7	Visually Inspect Handle Position V-4	Visually Check Switch Positions and Placement of Switch V-4	Visually Check Switch Positions, Placement of Switch, and Light V-4
	SUBSYSTEM(S)	Engine Instruments (EIN)	Engine Instruments (EIN)	Fuel (EF)	B105 Advisory (UAD)	C127 Communication (UC)	C118 Brakes (FB)	C043 Survivability (US)	Survivability (US)
	TASK #	B134	B064	B076	B105	C127	C118	C043	2902
TASKS	OBJECT	Rotor RPM	Engine Instruments	Fuel Quantity Indicator	Master CAUTION/WARNING Panel	Radios	Park Brake	Countermeasure Switch	Flare Dispenser Switch
	VERB	Check	Check	Check	Check	Check	Check	Set	Set

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 21 Perform Before Landing Check [Continued]

	SWITCH DISCRETE/ DESCRIPTION CONTINUOUS		Springloaded Press 1 (SP)	Springloaded Press 1 (SP) Springloaded Press 1 (SP)	loaded Press 1	loaded Press 1	loaded Press 1 1 1 3 3 3			
		Springloaded (SP)		Springloaded (SP)	Springloaded (SP)	Springloaded (SP)				
S .	PSYCHOMOTOR	Press Switch P-2.2		Press Switch P-2.2	Press Switch P-2.2	Press Switch P-2.2	Press Switch P-2.2 Press Switch and Speak P-2.2	Press Switch and Press Switch and P-2.2	Press Switch and Press Switch and P-2.2	Press Switch and P-2.2
OAD COMPONENTS	COGNITIVE	Decide Correct Position (Disengaged) and Verify Correct Status (Light Extinguished) C-1.2		Decide Correct Position (Disengaged) and Verify Correct Status (Light Extinguished) C-1.2	Decide Correct Position (Disengaged) and Verify Correct Status (Light Extinguished) C-1.2 Verify Correct Status (AUTO) C-1.2	Decide Correct Position (Disengaged) and Verify Correct Status (Light Extinguished) C-1.2 Verify Correct Status (AUTO) C-1.2 Verify Correct Status (LOCK) C-1.2	Decide Correct Position (Disengaged) and Verify Correct Status (Light Extinguished) C-1.2 Verify Correct Status (LOCK) C-1.2 Encode Message C-5.3	Decide Correct Position (Disengaged) and Verify Correct Status (Light Extinguished) C-1.2 Verify Correct Status (AUTO) C-1.2 Verify Correct Status (LOCK) C-1.2 Encode Message C-5.3 Decode Message (Crew Secure) C-5.3	Decide Correct Position (Disengaged) and Verify Correct Status (Light Extinguished) C-1.2 Verify Correct Status (AUTO) C-1.2 Verify Correct Status (LOCK) C-1.2 Encode Message C-5.3 Decode Message (Crew Secure) C-5.3	Decide Correct Position (Disengaged) and Verify Correct Status (Light Extinguished) C-1.2 Verify Correct Status (AUTO) C-1.2 Encode Message C-5.3 Decode Message (Crew Secure) C-5.3
WORKLOAD	SENSORY	Visually Check Switch Positions, Placement of Switch, and Light		ally Check Switch itions, Placement of ich, and Light		Sheck Switch , Placement of nd Light nspect Switch nspect Switch	Speech Feedback	Speech Switch nspect Switch nspect Switch Speech Feedback	Speech Switch nspect Switch nspect Switch Speech Feedback Auditory Message	Speech Switch nspect Switch spect Switch Speech Feedback Auditory Message
	SUBSYSTEM(S) SEI	Flight Control (FC)		(FC) Swii		Control	Control	(FC) (FC) Communication (UC) Communication (UC)	(FC) Flight Control (FC) Communication (UC) Communication (UC)	(FC) (FC) Communication (UC) Communication (UC)
	TASK *	9000	C003		C048	C048 Flight (FC)	C048	C048	C046 C046 B037	C046 C046 B037
TASKS	OBJECT	AFCS HDG Switch	AFCS ALT Switch		Cyclic Trim Switch	Cyclic Trim Switch Swivel Switch	Cyclic Trim Switch Swivel Switch	Cyclic Trim Switch Swivel Switch Crew Communication (Crewchief)	Cyclic Trim Switch Swivel Switch Crew Communication (Crewchief)	Cyclic Trim Switch Swivel Switch Crew Communication (Crewchief)
-	VERB	Set	Set		Check			a	a	a

Perform Before Landing Check (LZ)

FUNCTION 22

26 Seconds

	TASKS			WORKLOAD	DAD COMPONENTS			DURATION (SECONDS)	ξΩ
VERB	OBJECT	TASK #	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS	ĞE,
Check	Rotor RPM	B134	Engine Instruments (EIN)	Visually Inspect Instrument Indications V-4	Interpret Sensory and Symbolic Readouts and Verify Correct Status (100%)			8	
Check	Engine Instruments	B064	B064 Engine Instruments (EIN)	Visually Inspect Instrument Indications V-4	Interpret Sensory and Symbolic Readouts and Verify Correct Status (Readouts Within Limits) C-3.7			vo	
Check	Fuel Quantity Indicator	B076	Fuel (EF)	Visually Inspect Instrument Indications V-4	Interpret Symbolic Readout Move Head (Quantity) and Make P-2.6 Judgment (Enough Fuel) C-6.8	Move Head P-2.6		Ф.	
Check	Master CAUTION/WARNING Panel	B105	B105 Advisory (UAD)	Visually Scan and Register Lights V-1	Verify Correct Status (All Lights Extinguished) C-1.2			-	
Check	Radios	C127	C127 Communication (UC)	Visually Scan Dial Indications V-7	Interpret Symbolic Readouts and Verify Correct C-5.3			N	
Check	Park Brake	C118	Brakes (FB)	Visually inspect Handle Position V-4	Verify Current Position Correct (Unlocked) C-2				
Set .	Countermeasure Switch	C043	C043 Survivability (US)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position (Off) and Verify Correct Status (Light Extinguished) C-1.2	Move Switch P-2.2	Toggle - 2 Positions (T-2)	-	
Set	Flare Dispenser Switch	C067	Survivability (US)	Visually Check Switch Positions, Placement of Switch, and Light V-4	Decide Correct Position (SAFE) and Verity Correct Status (Light Extinguished) C-1.2	Move Switch P-2.2	Safety Toggle - 2 Positions (ST-2)	—	

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 22 Perform Before Landing Check (LZ) [Continued]

	TASKS			WORKLOAD	SAD COMPONENTS	S		DURATION
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH	DISCRETE/ CONTINUOUS
Set	AFCS HDG Switch	9000	Flight Control (FC)	Visually Check Switch Positions, Placement of Switch, and Light V-4	Decide Correct Position (Disengaged) and Verify Correct Status (Light Extinguished)	Press Switch P-2.2	Springloaded Press (SP)	-
Set	AFCS ALT Switch	C003	C003 Flight Control (FC)	Visually Check Switch Positions, Placement of Switch, and Light V-4	Decide Correct Position (Disengaged) and Verify Correct Status (Light Extinguished)	Press Switch P-2.2	Springloaded Press (SP)	-
Check	Cyclic Trim Switch	C048	C048 Flight Control (FC)	Visually Inspect Switch Position V-4	Verity Correct Status (AUTO) C-1.2			<u>-</u>
Check	Swivel Switch	C136 Gear (FG)		Visually Inspect Switch Position V-4	Verify Correct Status (LOCK) C-1.2			-
Check	Load Secure	C003	Communication (UC)	Receive Speech Feedback Encode Message A-4.3	·	Press Switch and Speak P-2.2		m
Receive	Communication (Crewchief)	B037	B037 Communication (UC)	Receive Auditory Message 4-4.9	Decode Message (Load Secure) C-5.3			Ф.
								

FUNCTION	23 Perform Before Takeoff Check	II Check	.			TOTAL TIN	TOTAL TIME (Approximate)	35.5 S	35.5 Seconds
	TASKS			WORKLOAD	OAD COMPONENTS	TS		DURATION (SECONDS)	rion NDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS	ETE/ UOUS
Check	Engine Instruments	B064	Engine Instruments (EIN)	Visually Inspect Instrument Indications V-4	Interpret Sensory and Symbolic Readouts and Verify Correct Status (Readouts Within Limits) C-3.7			w	
Check	Fuel Quantity Indicator	B076 Fuel (EF)		Visually inspect Instrument Interpret Symbolic Readout Indication (Quantity) and Make Judgment (Enough Fuel) C-6.8	Interpret Symbolic Readout (Quantity) and Make Judgment (Enough Fuel) C-6.8			ო	
Check	Master CAUTION/WARNING B105 Advisory Panel (UAD)	B105		Visually Scan and Register Lights V-1	Verify Correct Status (All Lights Extinguished) C-1.2			-	
Set	Park Brake	C120	Brakes (FB)	Feet Brake Position/ Visually Inspect Handle Position K-1/V-4	Verify Current Position Correct (Unlocked) C-2	Push Toe Brakes P-2.2	Push-Pull Handle (PPH)	Q	
Set	AFCS SEL Switch	C007	Flight Control (FC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position and Verify Correct Status (Both)	7um Switch P-5.8	Rotary - 5 Positions (R-5)	8	
Set	Cyclic Trim Switch	C048	Flight Control (FC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position and Verify Correct Status (AUTO)	Move Switch P-2.2	Toggle - 2 Positions (T-2)	-	
Set	Swivel Switch	C137	Geer (FG)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position and Verity Correct Status (LOCK) C-1.2	Move Switch P-2.2	Toggle - 3 Positions (T-3)	-	
Set	Master Switch (Transponder)	2 8	Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Verify Current Position Correct (NORM) C-1.2	Tum Switch P-5.8	Rotary - 4 Positions R-4	N	
								1	

FUNCTION 23 Perform Before Takeoff Check [Continued]

	TASKS			WORKLOAD	LOAD COMPONENTS	8 L 7		DURATION (SECONDS)
VERB	овлест	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Set	Countermeasure Switch	C043	C043 Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (ON) C-1.2	Move Switch P-2.2	Toggle - 2 Positions (T-2)	-
Set	Flare Dispenser Switch	C067	C067 Survivability (US)	Visually Check Switch Position, Placement of Switch, and Light V-4	Decide Correct Position (ARM) and Verify Correct Status (Light Illuminated) C-1.2	Move Switch P-2.2	Toggle - 2 Positions (T-2)	-
Check	Crew	C046	C046 Communication (UC)	Receive Speech Feedback Encode Message A-4.3	Encode Message C-5.3	Press Switch and Speak P-2.2		ო
Receive	Communication (Crewchief)		B037 Communication (UC)	Receive Auditory Message A-4.9	Decode Message (Crew Secure) C-5.3			ი
Check	Radios	C127	C127 Communication (UC)	Visually Scan Dial Indications V-7	Interpret Symbolic Readouts and Verify Correct C-5.3			~

FUNCTION 24 Perform Before Taxl Check

23.5 Seconds

	TASKS			WORKL	OAD COMPONEN	±s		DURATION (SECONDS	NO (SQ
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS	TE
Set	Swivel Switch	C137	Geer (FG)	Visually Check Switch Positions and Placement of Switch V-4	Decide Desired Position 10	Move Switch P-2.2	Toggle - 3 Positions (T-3)	2	
	AFCS SEL Switch	C007	Flight Control (FC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Desired Position C-1.2	Tum Switch P-5.8	Rotary - 5 Positions (R-5)	8	
Check	Cyclic Trim Indicator	C047	C047 Flight Control (FC)	Visually Check Indicator's Position V-4	Verify Correct Position (GND) C-1.2			-	
Transmit	Communication (Crewchief)	B038	B038 Communication (UC)	Receive Speech Feedback	Encode Message (Ramp/ Door Check) C-5.3	Press Switch and Speak P-2.2	Springkoaded Toggle - 3 Positions (SPT-3)	ю	***************************************
Весеіvе	Communication (Crewchief)	B037	B037 Communication (UC)	Receive Auditory Message A-4.9	Decode Message C-5.3			რ	
Check	Crew	C046	C046 Communication (UC)	Receive Speech Feedback Encode Message A-4.3 (Crew Secure) C-5.3		Press Switch and Speak P-2.2	Springloaded Toggle - 3 Positions (SPT-3)	m	
Receive	Communication (Crewchief)	B037	Communicatio 1 (UC)	Receive Auditory Message A-4.9	Decode Message C-5.3			ю	
Release	Park Brake	C119	Brakes (FB)	Feel Brake Position K-1	Decide and Verify Correct Position (Unlocked)	Push Toe Brakes P-2.2		-	
Check	Park Brake Light	C122	Advisory (UAD)	Visually Register Light V-1	Verity Correct Status (Extinguished) C-1.2			-	

erform Cockpit Communication (Copilot)	TON 25 Perform Cockpt Communication (Copilot)	
erform Cockpit Communication (Copilot)	erform Cockph Com	
arform Cockplt Communication (C	erform Cockph Com	politoti
erform Cockph Cor	10N 25 Perform Cockplt Cor	nmunication (Co
	TON 25 P	erform Cockph Co

DURATIC N	DISCRETE					
DUR (SEC	DISCI	၈	ო	က	n	
	SWITCH	Springloaded Press - 2 Positions (SP-2)		Springloaded Trigger (SPTR)		
8	PSYCHOMOTOR	Press Switch and Speak P-2.2		Pull Trigger and Speak P. 2.2		
OAD COMPONENTS	COGNITIVE		Decode Message C-5.3		Decode Message C-5.3	
WORKLOAD	SENSORY	Receive Speech Feedback Encode Message A-4.3	Receive Auditory Message 18	Receive Speech Feedback Encode Message A-4.3	Receive Auditory Message 16 A-4.9	
	SUBSYSTEM(S)	C036 Communication (UC)	P039 Communication (UC)	P040 Communication (UC)	C035 Communication (UC)	
	TASK	9600	P039	P040	C035	
TASKS	OBJECT	Communication (Copilot)	Communication (Pilot)	Communication (Pilot)	Communication (Copilot)	
	VERB	Transmit	Receive	Transmit	Receive	

TOTAL TIME (Approximate)

Perform Cockpit Communication (Pilot)

FUNCTION 26

	TASKS			MORKL	LOAD COMPONENT	118		DUR (SECC	DURATION SECONDS)
VERB 0	ОВЛЕСТ	TASK #	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMO, LH	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS	DISCRETE/ CONTINUOUS
Transmit	Communication (Pilot)	P040	P040 Communication (UC)	Receive Speech Feedback A-4.3	Encode Message C-5.3	Press Switch and Speak P.2.2	Springloaded Toggle - 3 Positions (SPT-3)	ဇ	
Receive	Communication (Copilot)	C035	C035 Communication (UC)	Receive Auditory Message A-4.9	Decode Message C-5.3			က	
Transmit	Communication (Copilot)	9600	C036 Communication (UC)	Receive Speech Feedback Encode Message A-4.3	Encode Message C-5.3	Press Switch and Speak P-2.2	Springloaded Toggle - 3 Positions (SPT-3)	ю	
Receive	Communication (Pilot)	P039	P039 Communication (UC)	Receive Auditory Message A-4.9	Decode Message C-5.3			ю.	
								_	
									

13 Seconds

TOTAL TIME (Approximate)

Perform External Communication

27

FUNCTION

DURATION (SECONDS) DISCRETE/ CONTINUOUS ო S N Springloaded Torgle - 3 Positions (SPT-3) Springloaded Toggle - 3 Positions (SPT-3) Rotary - 6 Positions (R-6) SWITCH DESCRIPTION Press Switch and Speak P-2.2 Press Switch and Speak P-2.2 **PSYCHOMOTOR** Turn Switch P-5.8 COMPONENTS Evaluate Position Options and Decide Desired Position C-4.6 Receive Speech Feedback Encode Message A-4.3 Receive Speech Feedback Encode Message A-4.3 Receive Auditory Message Decode Message A-4.9 COGNITIVE WORKLOAD Visually Check Switch Positions and Placement of Switch V-4 SENSORY SUBSYSTEM(S) C107 Communication (UC) C002 Communication (UC) C145 Communication (UC) C109 Communication (UC) TASK Transmitter Selector Switch Acknowledgment Message (Brief) TASKS OBJECT Message Transmit **Ресе**іуе Transmit VERB Set

FUNCTION	28 Perform External Communication (Threet)	municat	ion (Threat)			TOTAL TII	TOTAL TIME (Approximate)	318	31 Seconds
	TASKS			WORKL	LOAD COMPONENTS	1.8		DURATION (SECONDS)	NOS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS	ETE/ UOUS
Set	Transmitter Selector Switch	C145	Communication (UC)	Visually Check Switch Positions and Placement of Switch V-4	Evaluate Position Options and Decide Desired Position C-4.6	Tum Switch P-5.8	Rotary - 6 Positions (R-6)	-	
Set	Doppler Display Selector Switch	C055	C055 Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position (DEST TGT)	Tum Switch P-5.8	Rotary - 7 Positions (R-7)	۸	
Set	DEST DISP Thumbwheel	C049	C049 Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position C-1.2	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	v	
Transmit	Message (Brief)	C109	C109 Communication (UC)	Receive Speech Feedback Encode Message A-4.3		Press Switch and Speak P-2.2	Springloaded Toggle - 3 Positions (SPT-3)	ო	
Receive	Acknowledgment	C001	C001 Communication (UC)	Receive Auditory Message A-4.9	Decode Message C-5.3			N	
Transmit	Message	C108	C108 Communication (UC)	Receive Speech Feedback Encode Message A-4.3		Press Switch and Speak P-2.2	Springloaded Toggle - 3 Positions (SPT-3)	10	
Receive	Acknowledgment	C001	C001 Communication (UC)	Receive Auditory Message A-4.9	Decode Message C-5.3			8	
Set	Doppler Display Selector Switch	C055	C055 Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position (DIST/BRG/TIME)	Tum Switch P-5.8	Rotary - 7 Positions (R-7)	8	

30 Seconds

Perform Hover	
29	
FUNCTION	

	3 3 3 7			2003	200				
	C 4 C 4 -			WORKLOA	LUAD COMPONEN	8		(SECONDS)	<u>~</u> કે છે
VERB	OBJECT	TASK *	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS	Č.S.
Control	Altitude	P019	Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		w.	}
Control	Attitude	P026	Flight Control External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		بن -	<u> </u>
Control	Heading	P081	Flight Control External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		ĸ,	
Control	Drift	P062	Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		رن 	
Maintain	Obstacle Clearance	P115	P115 Flight Control External Visual Field (FC/VEX)	Feel Control Movements/ Visually Orient Aircraft K-4/V-3.7	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		ĸ,	· · · · · · · · · · · · · · · · · · ·
Check	Obstacle Clearance	C114	External Visual Field (VEX)	C114 External Visual Field Visually Register Obstacles Make Conditioned (VEX) V-1 Association (Aircraft C-1	Make Conditioned Association (Aircraft Clear) C-1			-	

*Since some of the tasks are performed randomly, the total time for the function is greater than the sum of the length of the individual tasks.

42.5 Seconds

TOTAL TIME (Approximate)

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 30 Perform Hover Check

	TASKS			WORKLOAD	OAD COMPONENTS	် တ		DURATION
VERB	овлест	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE
Check	Flight Controls (Hover)	P069	Fight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Verify Correct Status (Contro (Correct Control Response) P-2.6 C-3.7	Control Pressure P-2.6		01
Check	Engine Instruments (Hover)	P065	Flight Control/ Engine Instruments (FC/EiN)	Visually Scan Instrument Indications V-7	Inspect Sensory and Symbolic Readouts and Verity Correct Status (Readouts Within Limits) C-3.7	Control Pressure P-2.6		м
Check	Flight Instruments (Hover)	P071	Flight Control/ Flight Instruments (FC/FI)	Visually Scan Instrument Indications V-7	Inspect Sensory and Symbolic Readouts and Verity Correct Status (Correct Response) C-3.7	Control Pressure P-2.6		0
Set	AFCS SEL Switch	P007	P007 Flight Control (FC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position and Verify Correct Status C-1.2	Turn Switch P-5.8	Rotary - 5 Positions (R-5)	• 2
Perform	AFCS Check (Hover)	P004	Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Verify Correct Status (No Abrupt Engagement Errors) C-3.7	Control Pressure P-2.6		0
Perform	Power Check (Hover)	P124	Flight Control/ Engine Instruments (FC/EIN)	Visually Check Instrument Indications V-4	Interpret Sensory and Symbolic Readouts (Note Torque and N1) C-3.7	Control Pressure P-2.6		ιo

*Time not included in total. The copilot will perform the task while the pilot performs other tasks.

42.5 Seconds

TOTAL TIME (Approximate)

FUNCTION 31 Perform Hover Check [NVG]

	TASKS			WORKLOAD	DAD COMPONENTS	s		DURATION
VERB	OBJECT	TASK *	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Check	Flight Controls (Hover) [NVG]	P070	P070 Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Verify Correct Status Contro (Correct Control Response) P-2.6 C-3.7	Control Pressure P-2.6	-	01
Check	Engine Instruments (Hover)	P065	Flight Control/ Engine Instruments (FC/EIN)	Visually Scan Instrument Indications V-7	Inspect Sensory and Symbolic Readouts and Verify Correct Status (Readouts Within Limits) C-3.7	Control Pressure P-2.6		ıo.
Check	Flight Instruments (Hover)	P071	Flight Control/ Flight Instruments (FC/FI)	Visually Scan Instrument Indications V-7	Inspect Sensory and Symbolic Readouts and Verify Correct Status (Correct Response) C-3.7	Control Pressure P-2.6		0
Set	AFCS SEL Switch	P007	P007 Flight Control (FC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position and Verify Correct Status C-1.2	Tum Switch P-5.8	Rotary - 5 Positions (R-5)	ċ
Perform	AFCS Check (Hover) [NVG]	P005	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Verify Correct Status (No Abrupt Engagement Errors) C-3.7	Control Pressure P-2.6		0
Perform	Power Check (Hover)	P124	Flight Control/ Engine Instruments (FC/EiN)	Visually Check Instrument Indications V-4	Interpret Sensory and Symbolic Readouts (Note Torque and N1) C-3.7	Control Pressure P-2.6		w

*Time not included in total. The copilot will perform the task while the pilot performs other tasks.

120 Seconds*

FUNCTION	32 Perform Hover [NVG]				
	TASKS			WORK	WORKLOAD COMPO
VERB	OBJECT	TASK	ASK \$ SUBSYSTEM(S)	SENSORY	COGNITIVE
Control	Altitude (NVG)	P023	Flight Control/Night Vision Goggles (FC/VG)	P023 Flight Control/Night Feel Control Movements/ Vision Goggles Visually Detect Aircraft (FC/VG) Movement (FC/VG)	Make Conditioned Association (Adjustme Needed) C-1
Control	Attitude [NVG]	P028	Flight Control/Night Vision Goggles (FC/VG)	P028 Flight Control/Night Feel Control Movements/ Vision Goggles Visually Detect Aircraft (FC/VG)	Make Conditioned Association (Adjustme Needed)

	TASKS			WORKLOAD	LOAD COMPONENTS	118		DURATION	NO.
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE	TE
Control	Altitude (NVG)	P023	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed)	Control Pressure P-2.6		-	
Control	Attitude [NVG]	P028	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	
Control	Heading [NVG]	P086	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	
Control	Drift [NVG]	P063	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	
Maintain	Obstacle Clearance [NVG]	P117	P117 Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Orient Aircraft K-4/G-5	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	
Check	Obstacle Clearance [NVG]	C116	C116 Night Vision Goggles (VG)	Visually Register Obstacles G-1	Make Conditioned Association (Aircraft Clear) C-1			ო	
									<u> </u>
									=

*Since some of the tasks are performed randomly, the total time for the function is greater than the sum of the length of the individual tasks.

Perform Nevgeton

FUNCTION 33

Continuous*

	TASKS			WORKLOAD	OAD COMPONENTS	6		DURA	DURATION
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS	TETE/
Monitor	Doppler Display	C054	C054 Navigation Display (ND)	Read Symbolic Display V-5.9	Interpret Symbolic Readout and Make Judgment (Location Correct) C-6.8			4	
Read	Maps	C104	C104 Navigation Control (NC)	Read Map Symbols V-5.9	Interpret Map Symbols C-6.8	Handle Maps P.4.6		ç	
Motto	Course	C044	C044 External Visual Field (VEX)	Visually Search External Field of View V-7	Interpret Sensory Feedback and Make Judgment (Adjustment Needed) C-6.8			4	
		-							

*The total time for this function varies with the segment in which the function occurs.

Continuous*

TOTAL TIME (Approximate)

FUNCTION 34 Perform Navigation [NVG]

*The total time for this function varies with the segment in which the function occurs.

TOTAL TIME (Approximate) 120.5 Seconds*

FUNCTION 35 Perform Text

	TASKS			WORKLOAD	LOAD COMPONENTS	81		DURATION
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Control	Forward Motion (Taxi)	P073	P073 Brakes/ External Visual Field (FB/VEX)	Brakes/ Feel Pedal Movements/ External Visual Field Visually Detect Aircraft (FB/VEX) Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Press Toe Brakes P.2.6		ro.
Control	Heading (Taxi)	P082 Gear/ Exterr (FGV	Gear/ External Visual Field (FGVEX)	Gear/ Feel Swivel Knob External Visual Field Movements/Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6	Springloaded Rotary (SPR)	ĸ,
Maintain	Obstacle Clearance	P115	Flight Control/ External Visual Field (FC/VEX)	Flight Control Feel Control Movements/ External Visual Field Visually Orient Aircraft (FC/VEX)	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		ιύ.
5 5 E-41	Obstacle Clearance	C114	External Visual Field (VEX)	C114 External Visual Field Visually Register Obstacles Make Conditioned (VEX) V-1 C-1	Make Conditioned Association (Aircraft Clear) C-1			-

*Since the tasks are performed randomly, the total time for the function is greater than the sum of the length of the individual tasks.

TOTAL TIME (Approximate) 180.5 Seconds*

FUNCTION 36 Perform Taxl (NVG)

DURATION		kņ.	ις.	ν	m		
	SWITCH DESCRIPTION		Springloaded Rotary (SPR)			 	
ENTS	PSYCHOMOTOR	Prets Toe Brakes P-2.6	Control Pressure P-2.6	Control Pressure P-2.6			
OAD COMPON	COGNITIVE	Make Conditioned Association (Adjustment Needed) C-1	Make Conditioned Association (Adjustment Needed) C-1	Make Conditioned Association (Adjustment Needed) C-1	Make Conditioned Association (Aircraft Clear) C-1		
WORKL	SENSORY	Feel Pedal Movements/ Visually Detect Aircraft Movement K-4/G-1	Feel Swivel Knob Movements/Visually Detect Aircraft Movement K-4/G-1	Feel Control Movements/ Visually Orient Aircraft K-4/G-5	Visually Register Obstacles Make Conditioned Association (Aircraf C-1		
	SUBSYSTEM(S)	P074 Brakes/Night Vision Goggles (FB/VG)	P083 Gear/Night Vision Goggles (FG/VG)	Flight Control/Night Vision Goggles (FC/VG)	C116 Night Vision Goggles (VG)		
	TASK		P083	P117	C116		
TASKS	OBJECT	Forward Motion (Taxi) [NVG]	Heading (Taxi) [NVG]	Obstacle Clearance [NVG]	Obstacle Clearance [NVG]		
	VERB	Control	Control	Maintain	Y E-42		

*Since the tasks are performed randomly, the total time for the function is greator than the sum of the length of the individual tasks.

FUNCTION	37 Perform Taxiing Check	ی		!		TOTAL TIN	TOTAL TIME (Approximate)	21.5 Seconds
	TASKS			WORKLOAD	LOAD COMPONENTS	S L S		DURATION
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Check	Brakes (Pilot)	P031	Brakes (FB)	Feel Brake Position K-1	Verify Correct Status C-1.2	Press Toe Brakes P-2.2		ro .
Check	Brakes (Copilot)	0030	C030 Brakes (FB)	Feel Brake Position K-1	Verify Correct Status C-1.2	Press Toe Brakes P-2.2		ω
Check	Power Steering	C125 Gear (FG)	Gear (FG)	Feel Knob Movement K-1	Verify Correct Status C-1.2	Control Pressure P-2.6	Springloaded Rotary (SPR)	0

FUNCTION	38 Program Doppler					TOTAL TIN	TOTAL TIME (Approximate)	389.5 Seconds	conds
	TASKS			WORKLOAD	OAD COMPONENT	1.5		DURATION (SECONDS)	NO. FIDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS	TE/ JOUS
Set	Doppler Mode Switch	8500	Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position (Lamp Test) C-1.2	Turn Switch P-5.8	Safety Rotary - 6 Positions (SR-6)	-	
Check	Doppler Panel Lights	6500	Navigation Control (NC)	Visually Register Lights V-1	Verify Correct Status (All Lights Illuminated) C-1.2			N	
Check	Doppler Dim Switch	C052	C052 Navigation Control (NC)	Visually Register Lights V-1	Verify Correct Status C-1.2	Tum Switch P-5.8	Rotary Rheostat (R-R)	w	
Set	Doppler Mode Switch	C058	C058 Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch V-4	Evaluate Position Options Turn S and Decide Correct Position P-5.8 (Test)	Switch	Safety Rotary - 6 Positions (SR-6)	+	
Check	Doppler Display	C053	Navigation Control (NC)	Read Symbolic Display V-5.9	Interpret Symbolic Readout and Verify No Malfunctions C-3.7			8	
Set	Doppler Mode Switch	C058	Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position (UTM) (C-1.2	Tum Switch P-5.8	Safety Rotary - 6 Positions (SR-6)	**	
Set	Doppler Display Selector Switch	C055	Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position (SPHVAR)	Tum Switch P-5.8	Rotary - 7 Positions (R-7)	N	
Set	DEST DISP Thumbwheel	C049	Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (H) C-1.2	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	ĸ	
Press	Doppler KYBD Key	C056	Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (TGT STR Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-	

FUNCTION 38 Program Doppler [Continued]

	TASKS			WORKL	LOAD COMPONENT	13		DURATION
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH	DISCRETE
Press	Doppler KYBD Key	9500	Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Left Display Blank) C-1.2	Press Key P.2.2	Springloaded Press (SP)	-
Enter	Doppler Spheroid Data	0900	C060 Navigation Control (NC)	Visually Locate Keys and Read Symbolic Display V-5.9	Encode and Verify Correct Entry (Spheroid Data) C-5.3	Type Entry P-7	Springloaded Press - Alphanumeric Functions (SP-AN)	0
Press	Doppler KYBD Key	202	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verily Correct Status (Right Display Blank) C-1 2	Press Key P.2.2	Springloaded Press (SP)	-
Enter	Doppler Magnetic Variat on	C057	C057 Navigation Control (NC)	Visually Locate Keys and Read Symbolic Display V-5.9	Encode and Verify Correct Entry (Magnetic Variation) C-5.3	Type Entry P.7	Springloaded Press - Alphanumeric Functions (SP-AN)	0
Press	Doppler Data Entry Key	C051	Navigation Control (NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verily Entry Correct (TGT STR Data) C-1.2	Press Key P-2.2	Springloaded Press (SP)	
Set	Doppler Display Selector Switch	C055	Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position (DEST/IGT) C-1.2	Tum Switch P-5.8	Rotary - 7 Positions (R-7)	~
Set	DEST DISP Thumbwheel	C049	Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (H) C-1.2	Tum Thumbwheel P.5.8	Vertical Thumbwheel - 9 Positions (VT-9)	ιo
Press	Doppler KYBD Key	9900	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (TGT STR Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 38 Program Doppler [Continued]

	TASKS			WORKLO	OAD COMPONENTS	1.8		DURATION (SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Press	Doppler KYBD Key	9500	Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Center Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Enter	Doppler Zone Data	C061	C061 Navigation Control (NC)	Visually Locate Keys and Read Symbolic Display V-5.9	Encode and Verify Correct Entry (Zone Data)	Туре Entry P7	Springloaded Press - Alpharumeric Functions (SP-AN)	ω
Press	Doppler KYBD Key	C056	Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Center Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Enter	UTM Coordinates	C151	C151 Navigation Control (NC)	Visually Locate Keys and Read Symbolic Display V-5.9	Encode and Verify Correct Entry (Coordinates) (C-5.3	Type Entry P-7	Springloaded Press - Alphanumeric Functions (SP-AN)	2
Press	Doppler Data Entry Key	C051	Navigation Control (NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (UTM Coordinates) C-3.7	Press Key P-2.2	Springloaded Press (SP)	-
Set T	Doppler Display Selector Switch	C055	C055 Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch	Decide Correct Position (SPH/VAR)	Tum Switch P-5.8	Rotary - 7 Positions (R-7)	8
Set	DEST DISP Thumbwheel	C049	Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (H)	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	ĸ
Press	Doppler KYBD Key	9500	Navigation Control (NC)	Visually Locate Key and Inspect Display Status V.5	Verify Correct Status (TGT STR Blank) C-1.2	Press Key P-2.2	Springlos Jed Press (SP)	-

FUNCTION 38 Program Doppler [Continued]

	TASKS			WORKLOAD	LOAD COMPONENTS	TS		DURATION (SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Set	DEST DISP Thumbwheel	C049	Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (1) C-1.2	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	ശ
Press	Doppler Data Entry Key	C051	C051 Navigation Control (NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (TGT STR Data) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Press	Doppler KYBD Key	0026	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (TGT STR Bank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Press	Doppler KYBD Key	9500	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Left Display Blank) C-1,2	Press Key P-2.2	Springloaded Press (SP)	•
Press	Doppler KYBD Key	2056	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Right Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Enter	Doppler Magnetic Variation	C057	Navigation Control (NC)	Visually Locate Keys and Read Symbolic Display V-5.9	Encode and Verity Correct Entry (Magnetic Variation) C-5.3	Type Entry P-7	Springloaded Press - Alphanumeric Functions (SP-AN)	0
Press	Doppler Data Entry Key	C051	C051 Navigation Control (NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (TGT STR Data) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Se €	Doppler Display Selector Switch	C055	C055 Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position (DEST/TGT) C-1.2	Tum Switch P-5.8	Rotary - 7 Positions (R-7)	8

FUNCTION 38 Program Doppler [Continued]

	TASKS			WORKLOAD	LOAD COMPONENTS	1.8		DURATION
VERB	OBJECT	TASK #	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/
Set	DEST DISP Thumbwheel	C049	C049 Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (H) C-1,2	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	w
Press	Doppler KYBD Key	C056	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (TGT STR Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
ž Š	DEST DISP Thumbwheel	C049	C049 Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (1) C-1.2	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	w
Press	Doppler Data Entry Key	C051	Navigation Control (NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (UTM Coordinates) C-3.7	Press Key P-2.2	Springloaded Press (SP)	-
Press	Doppler KYBD Key	C056	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (TGT STR Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Press	Doppler KYBD Key	C056	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Center Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Press	Doppler KYBD Key	C056	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Left and Right Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Enter	UTM Coordinates	C0151	C0151 Navigation Control (NC)	Visually Locate Keys and Read Symbolic Display V-5.9	Encode and Verity Correct Entry (Coordinates) C-5.3	Type Entry P-7	Springloaded Press - Alpharumeric Functions (SP-AN)	12

FUNCTION 38 Program Doppler [Continued]

	TASKS			WORKLOA	LOAD COMPONENTS	T S		DURATION (SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Press	Doppler Data Entry Key	C051	Navigation Control (NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (UTM Coordinates) G-3.7	Press Key P-2.2	Springloaded Press (SP)	-
Set	Doppler Display Selector Switch	C055	C055 Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position (SPH/VAR) C-1.2	Tum Switch P-5.8	Rotary - 7 Positions (R-7)	۸
Set .	DEST DISP Thumbwheel	C049	C049 Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (1) C-1.2	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	ь
Press	Doppler KYBD Key	202	Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (TGT STR Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Set	DEST DISP Thumbwheel	C049	C049 Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (2) C-1.2	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	ဟ
Press	Doppler Data Entry Key	C051	C051 Navigation Control (NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (TGT STR Data) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Press	Doppler KYBD Key	C056	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (TGT STR Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Press	Doppler KYBD Key	9502	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Left Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-

FUNCTION 38 Program Doppler [Continued]

ļ	TASKS			WORKLOAD	LOAD COMPONENT	118		DURATION (SECONDS)	TION NDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS	ETE/ UOUS
Press	Doppler KYBD Key	9900	Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Right Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-	
Enter	Doppler Magnetic Variation	C057	C057 Navigation Control (NC)	Visually Locate Keys and Read Symbolic Display V-5.9	Encode and Verify Correct Entry (Magnetic Variation) C-5.3	Type Entry P-7	Springloaded Press - Alphanumeric Functions (SP-AN)	0	
Press	Doppler Data Entry Key	C051	Navigation Control (NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (TGT STR Data) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-	
10 %	Doppler Display Selector Switch	C055	C055 Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position (DEST/TGT) C-1.2	Tum Switch P-5.8	Rotary - 7 Positions (R-7)	N	
Set	DEST DISP Thumbwheel	C049	C049 Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (1) C-1.2	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	က	
Press	Doppler KYBD Key	202	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (TGT STR Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-	
Set .	DEST DISP Thumbwheel	C049	C049 Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (2) C-1.2	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	ıs	
Press	Doppler Data Entry Key	C051	C051 Navigation Control (NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (UTM Coordinates) C-3.7	Press Key P-2.2	Springloaded Press (SP)	-	

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 38 Program Doppler [Continued]

	TASKS			WORKLOA	LOAD COMPONENTS	18		DURATION (SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Press	Doppler KYBD Key	9500	Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (TGT STR Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Press	Doppler KYBD Key	9500	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Center Display Blank) C-1.2	Press Kay P-2.2	Springloaded Press (SP)	-
Press	Doppler KYBD Key	9500	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Left and Right Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Enter	UTM Coordinates	C151	Navigation Control (NC)	Visually Locate Keys and Read Symbolic Display V-5.9	Encode and Verity Correct Entry (Coordinates) C-5.3	Type Entry P.7	Springloaded Press - Alphanumeric Functions (SP-AN)	12
Press	Doppler Data Entry Key	C051	C051 Navigation Control (NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (UTM Coordinates) C-3.7	Press Key P-2.2	Springloaded Press (SP)	-
Set	Doppler Display Selector Switch	C055	C055 Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position (SPH/VAR) C-1.2	Tum Switch P-5.8	Rotary - 7 Positions (R-7)	N
Set	DEST DISP Thumbwheel	C049	C049 Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (2) C-1.2	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	w
Press	Doppler KYBD Key	9502	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (TGT STR Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 38 Program Doppler [Continued]

VERB OBJECT Set DEST DISP Thumbwheel Press Doppler Data Entry Key Press Doppler KYBD Key		# SUBSYSTEM(S) C049 Navigation Control (NC) C051 Navigation Control	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH	DISCRETE/ CONTINUOUS
		Navigation Control (NC) Navigation Control					
	C051	Navigation Control	Read Symbolic Display V-5.9	Decide and Verify Correct Position (3) C-1.2	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	ıo
	9500		Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (TGT STR Data) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
		C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verity Correct Status (TGT STR Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
	0000	Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Left Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Press Doppler KYBD Key	C056	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Right Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Enter Doppler Magnetic Variation	C057	Navigation Control (NC)	Visually Locate Keys and Read Symbolic Display V-5.9	Encode and Verify Correct Entry (Magnetic Variation) C-5.3	Type Entry P-7	Springloaded Press - Alphanumeric Functions (SP-AN)	0
Press Doppler Data Entry Key	C051	Navigation Control (NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (TGT STR Data) G-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Set Doppler Display Selector Switch		C055 Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position (DEST/TGT) C-1.2	Turn Switch P-5.8	Rotary - 7 Positions (R-7)	N

FUNCTION 38 Program Doppler [Continued]

	TASKS			WORKLOAD	LOAD COMPONENTS	1.8		DURATION
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Set	DEST DISP Thumbwheel	C049	Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (2) C-1.2	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions	ın
Press	Doppler KYBD Key	2056	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (TGT STR Blank) C-1.2	Press Kay P-2.2	Springloaded Press (SP)	-
Set	DEST DISP Thumbwheel	C049	C049 Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (3) C-1.2	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	ശ
Press	Doppler Data Entry Key	C051	Navigation Control (NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (UTM Coordinates) C-3.7	Press Key P-2.2	Springloaded Press (SP)	-
Press	Doppler KYBD Key	C056	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (TGT STR Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Press	Doppler KYBD Key	9500	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Center Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Press	Doppler KYBD Key	C056	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Left and Right Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Enter	UTM Coordinates	C151	Navigation Control (NC)	Visually Locate Keys and Read Symbolic Display V-5.9	Encode and Verity Correct Entry (Coordinates) C-5.3	Type Entry P-7	Springloaded Press - Abhanumeric Functions (SP-AN)	25

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 38 Program Doppler [Continued]

	TASKS			WORKLOAD	OAD COMPONENTS	1.8		DURATION (SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Press	Doppler Data Entry Key	C051	Navigation Control (NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (UTM Coordinates) C-3.7	Press Key P-2.2	Springloaded Press (SP)	-
Set	Doppler Display Selector Switch	C055	C055 Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position (SPH/VAR) C-1.2	Tum Switch P-5.8	Rotary - 7 Positions (R-7)	0
Set	DEST DISP Thumbwheel	C049	C049 Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (3) (3-1.2	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	w
Press	Doppler KYBD Key	C056	Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (TGT STR Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Set	DEST DISP Thumbwheel	C049	C049 Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (4) C-1.2	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	ဟ
Press	Doppler Data Entry Key	C051	Navigation Control (NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (TGT STR Data) C-1.2	Press Key P-2.2	Springloaded Press (SP)	•
Press	Doppler KYBD Key	9502	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (TGT STR Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Press	Doppler KYBD Key	0056	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Venity Correct Status (Left Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-

FUNCTION 38 Program Doppler [Continued]

	TASKS			WORKLOA	LOAD COMPONENTS	7.S		DURATION (SECONDS)
VERB	OBJECT	TASK *	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWTCH DESCRIPTION	DISCRETE/ CONTINUOUS
Press	Doppler KYBD Key	9500	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Right Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Enter	Doppler Magnetic Variation	C057	Navigation Control (NC)	Visually Locate Keys and Read Symbolic Display V-5.9	Encode and Verify Correct Entry (Magnetic Variation) (C-5.3	Type Entry P-7	Springloaded Press - Alphanumeric Functions	0
Press	Doppler Data Entry Key	C051	C051 Navigation Control (NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (TGT STR Data) C-1.2	Press Kay P-2.2	Springloaded Press (SP)	-
Set	Doppler Display Selector Switch	C055	Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position (DEST/TGT) C-1.2	Turn Switch P-5.8	Rotary - 7 Positions (R-7)	~
te S	DEST DISP Thumbwheel	C049	C049 Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (3) C-1.2	P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	v
Press	Doppler KYBD Key	9500	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (TGT STR Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Set	DEST DISP Thumbwheel	C049	C049 Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (4) C-1.2	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions	ıo
Press	Doppler Data Entry Key	C051	C051 Navigation Control (NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (UTM Coordinates) C-3.7	Press Key P-2.2	Springloaded Press (SP)	-

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 38 Program Doppler [Continued]

	TASKS			WORKLOAD	LOAD COMPONENTS	18		DURATION (SECONDS)	
VERB	ОВЛЕСТ	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWTCH DESCRIPTION	DISCRETE/ CONTINUOUS	. S
Press	Doppler KYBD Key	9500	Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (TGT STR Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-	
Press	Doppler KYBD Key	9500	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Center Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	Ψ-	
Press	Doppler KYBD Key	2056	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Left and Right Display I Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	_	
Enter	UTM Coordinates	C151	C151 Navigation Control (NC)	Visually Locate Keys and Read Symbolic Display V-5.9	Encode and Verify Correct Entry (Coordinates) C-5.3	Type Entry p.7	Springloaded Press - Alphanumeric Functions (SP-AN)	22	
Press	Doppler Data Entry Key	C051	C051 Navigation Control (NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (UTM Coordinates) C-3.7	Press Key P-2.2	Springloaded Press (SP)	-	
Set	FLY-TO-DEST Switch	C072	C072 Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (H)	Tum Switch P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	LO .	
Set	Doppler Display Selector Switch	C055	C055 Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch	Decide Correct Position (DIST/BRG/TIME) C-1.2	Tum Switch P-5.8	Rotary - 7 Positions (R-7)	N	
Press	Doppler KYBD Key	0056	C056 Navigation Control (NC)	Visually Locate Key and inspect Display Status V-5	Venify Correct Status (Left and Right Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-	

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 38 Program Doppler [Continued]

TASKS		1404		WORKLOAD	LOAD COMPONENTS	81.8	T L HWAS	DURATION (SECONDS)
OBJECT # SUBSYSTEM(S)	SUBSYSTEM(S)	SUBSYSTEM(S)		SENSORY	COGNITIVE	PSYCHOMOTOR	DESCRIPTION	CONTINUOUS
Doppler Data Entry Key C051 Navigation Control (NC)				Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (UTM Coordinates) C-3.7	Press Key P-2.2	Springloaded Press (SP)	-
FLY-TO-DEST Switch CO72 Navigation Control F (NC)			<u> </u>	Read Symbolic Display V-5.9	Decide and Verify Correct Position (1) C-1.2	Tum Switch	Vertical Thumbwheel - 9 Positions (VT-9)	vo
						,		

FUNCTION 39 Program Transponder

85 Seconds

	TASKS			WORKLOA	DCOMPONEN	1.8		DURATION	N (S)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS	TE/ IOUS
Set	Master Switch (Transponder)	C106	Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (STBY) C-1.2	Tum Switch P-5.8	Rotary - 4 Positions (R-4)	8	
Set .	Mode 1 Code	C111	C111 Survivability (US)	Visually Locate Switch and Read Symbolic Display V-5.9	Encode Current Entry (Current Code) C-5.3	Press Switches P-2.2	Springloaded Press (SP)	w	
Set	Mode 3A Code	C112	C112 Survivability (US)	Visually Locate Switch and Read Symbolic Display V-5.9	Encode Current Entry (Current Code) C-5.3	Press Switches P-2.2	Springloaded Press (SP)	0	
Check	Test Light	C139	Survivability (US)	Visually Register Light V-1	Verify Correct Status (Illuminated) C-1.2	Press Light P-2.2	Springloaded Press (SP)	ιņ	
Check	TestMON Light	C140	C140 Survivability (US)	Visuall, Register Light V-1	Verify Correct Status (Illuminated) C-1.2	Press Light P-2.2	Springloaded Press (SP)	ιν̈́	
Check	Reply Light	C133	C133 Survivability (US)	Visually Register Light V-1	Verify Correct Status (Illuminated) C-1.2	Press Light P-2.2	Springloaded Press (SP)	ις	
Set S	ANT Switch	C024	C024 Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (BOT) C-1.2	Move Switch P-2.2	Toggle - 3 Positions (T-3)	-	
Set	Master Switch (Transponder)	C106	C106 Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (NORM) C-1.2	Tum Switch P-5.8	Rotary - 4 Positions (R-4)	N	
Set	M-1 Test Switch	C097	Survivability (US)	Visually Register Light V-1	Verify Correct Status (Go Illuminated) C-1.2	Move and Hold Switch P-2.2	Toggle - 3 Positions (T-3)	2	

FUNCTION 39 Program Transponder [Continued]

							<u> </u>	
	TASKS			WORKLOAD	LOAD COMPONENTS	13	•	DURATION (SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Set	M-1 Switch	9600	Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Evaluate Position Options (and Decide Correct Position (ON) C-1.2	Move Switch P-2.2	Toggle - 3 Positions (T-3)	-
Set	M-2 Test Switch	6600	Survivability (US)	Visually Register Light V-1	Verify Correct Status (Go Illuminated) C-1.2	Move and Hold Switch P-2.2	Toggle - 3 Positions (T-3)	8
Set	M-2 Switch	8600	Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (ON)	Move Switch P-2.2	Toggle - 3 Positions (T-3)	-
Set	M-3 Test Switch	C101	Survivability (US)	Visually Register Light V-1	Verify Correct Status (Go Illuminated) C-1.2	Move and Hold Switch P-2.2	Toggle - 3 Positions (T-3)	8
Set	M-3 Switch	C100	C100 Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (ON) C-1.2	Move Switch P-2.2	Toggle - 3 Positions (T-3)	-
Set	M-C Test Switch	C103	C103 Survivability (US)	Visually Register Light V-1	Verify Correct Status (Go Illuminated) C-1.2	Move and Hold Switch P-2.2	Toggle - 3 Positions (T-3)	8
Set	M-C Switch	C102	C102 Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (CN) C-1.2	Move Switch P-2.2	Toggle - 3 Positions (T-3)	-
Set	ANT Switch	C024	C024 Survivability (US)	Visually Check Switch Position and Placement of Switch	Decide Correct Position (TOP) C-1.2	Move Switch P-2.2	Toggle - 3 Positions (T-3)	-
Set	M-1 Test Switch	C097	C097 Survivability (US)	Visually Register Light V-1	Verify Correct Status (Go Illuminated) C-1.2	Move and Hold Switch P-2.2	Toggle - 3 Positions (T-3)	2

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 39 Program Transponder [Continued]

	TASKS			WORKLOAD	LOAD COMPONENTS	1.5		DURATION (SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Set	M-1 Switch	9600	C096 Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (ON) C-1.2	Move Switch P-2.2	Toggle - 3 Positions (T-3)	-
S ət	M-2 Test Switch	6600	C099 Survivability (US)	Visually Register Light V-1	Verify Correct Status (Go Illuminated) C-1.2	Move and Hold Switch P-2.2	Toggle - 3 Positions (T-3)	8
Set	M-2 Switch	8600	Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (ON) C-1.2	Move Switch P-2.2	Toggle - 3 Positions (T-3)	*
Set	M-3 Test Switch	C101	C101 Survivability (US)	Visually Register Light V-1	Verify Correct Status (Go Illuminated) C-1.2	Move and Hold Switch P-2.2	Toggle - 3 Positions (T-3)	N
Set	M-3 Switch	C100	C100 Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (ON) C-1.2	Move Switch P-2.2	Toggle - 3 Positions (T-3)	-
Set S	M-C Test Switch	C103	C103 Survivability (US)	Visually Register Light V-1	Verify Correct Status (Go Illuminated) C-1.2	Move and Hold Switch P-2.2	Toggle - 3 Positions (T-3)	N N
Set.	M-C Switch	C102	C102 Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (ON) C-1.2	Move Switch P-2.2	Toggle - 3 Positions (T-3)	-
Set	ANT Switch	C024	C024 Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (DIV) C-1.2	Move Switch P-2.2	Toggle - 3 Positions (T-3)	-
Set	M-1 Test Switch	C097	C097 Survivability (US)	Visually Register Light V-1	Venify Correct Status (Go Illuminated) C-1.2	Move and Hold Switch P-2.2	Toggle - 3 Positions (T-3)	N

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 39 Program Transponder [Continued]

	TASKS			WORKLO	LOAD COMPONENTS	1.8		DURATION (SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Set	M-1 Switch	9600	Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (ON) C-1.2	Move Switch P-2.2	Toggle - 3 Positions (T-3)	_
S _{et}	M-2 Test Switch	6600	Survivability (US)	Visually Register Light V-1	Verify Correct Status (Go Illuminated) C-1.2	Move and Hold Switch P-2.2	Toggle - 3 Positions (T-3)	N.
Set	M-2 Switch	8600	C098 Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (ON) C-1.2	Move Switch P-2.2	Toggle - 3 Positions (T-3)	-
Set	M-3 Test Switch	C101	C101 Survivability (US)	Visually Register Light V-1	Verify Correct Status (Go Illuminated) C-1.2	Move and Hold Switch P-2.2	Toggle - 3 Positions (T-3)	8
Set	M-3 Switch	C100	C100 Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (ON)	Move Switch P-2.2	Toggle - 3 Positions (T-3)	-
Set	M-C Test Switch	C103	C103 Survivability (US)	Visually Register Light V-1	Verify Correct Status (Go Illuminated) C-1.2	Move and Hold Switch P-2.2	Toggle - 3 Positions (T-3)	ο.
Set	M-C Switch	C102	C102 Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (ON) C-1.2	Move Switch P-2.2	Toggle - 3 Positions (T-3)	-
Sec	Mode 4 Switch	C113	C113 Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Desired Position C-1.2	Tum Switch P-2	Rotary - 4 Positions	N

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 39 Program Transponder [Continued]

	TASKS			WORKLOAD	LOAD COMPONENTS	113		DURATION (SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Set	M-1 Switch	9600	C096 Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (ON) C-1.2	Move Switch P-2.2	Toggle - 3 Positions (T-3)	-
Set	M-2 Switch	8600	C098 Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (ON) C-1.2	Move Switch P-2.2	Toggle - 3 Positions (T-3)	-
Set	M-3 Switch	S 28	C100 Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (ON) C-1.2	Move Switch P-2.2	Toggle - 3 Positions (T-3)	-
5	M-C Switch	C102	Survivability (US)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (ON) C-1.2	P-2.2	Toggle - 3 Positions (T-3)	-

308 Seconds*

FUNCTION 40 Refuel Alteraft

	TASKS			WORKLOA	LOAD COMPONENTS	118		DURATION
VERB	OBJECT	TASK #	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH	DISCRETE/ CONTINUOUS
ē.	Park Brake	P120	P120 Brakes (FB)	Visually Inspect Handle Position/Feel Brake Position V-4/K-1	Verify Current Position Correct (Locked) C-2	Push Toe Brakes P-2.6	Push-Pull Handle (PPH)	8
Se	Park Brake Lever	P121	Brakes (FB)	Visually Locate Handle V-5	Decide and Verily Correct Position (Locked) C-1.2	Pull Handle P-5.8	Push-Puil Handle (PPH)	-
Check	Fuel Quantity Indicator	B076 Fuel (EF)		Visually Check Instrument Indication V-4	Interpret Symbolic Readout (Quantity) and Make Judgment (Enough Fuel) C-4.6			м
y E-63	Refueling Complete	P132 Fuel (EF)		Receive Auditory Message A-4.9	Verify Correct Status C-1.2			ო
		<u>-</u>						
·								

*Since some of the tasks are performed randomly, the total time for the function is greater than the sum of the length of the individual tasks.

36 Seconds

	TASKS			WORKLOAD	OAD COMPONENTS	, , ,		DURATION (SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWTCH DESCRIPTION	DISCRETE/ CONTINUOUS
Detect	Threat	B141	B141 Survivability (US)	Detect Visual Image V-1	Recognize Visual Signal (Threat Present) C-3.7			ю
Press	Flare Dispenser Switch	9900	C066 Survivability (US)	Feel Switch Movement K-2	Verify Correct Position (Flare Activated) C-1.2	Press Switch P-2.2	Springloaded Press (SP)	ru.
Sec.	Target Storage Switch	C138	C138 Navigation Control (NC)	Visually Locate Switch V-5	Verify Correct Position C-1.2	Press Switch P-2.2	Springloaded Press (SP)	-
Perform	Hard Tums	P078	Flight Control/ External Visual Field ((FC/VEX)	Flight Control/ Feel Control Movements/ External Visual Field Visually Orient Aircraft (FC/VEX)	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P.2.6		ю.
Change	Altitude Sharply	P020	Flight Control External Visual Field (FC/VEX)	P020 Flight Control Feel Control Movements/ External Visual Field Visually Detect Aircraft (FC/VEX) Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		e e
Change	Airspeed Quickly	4 104	P014 Flight Control (FC)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		m

*Since some of the tasks are performed randomly, the total time for the function is greater than the sum of the length of the individual tasks.

46 Seconds*

2	2
CONTRACTOR OF THE PARTY OF THE	
	2
0	
3	

	TASKS			WORKLOAD	DAD COMPONENTS	မာ		DURATION (SECONDS)	NOT NOW
VERB	овлест	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/	ETE/ UOUS
Detect	Threat	B141	B141 Survivability (US)	Detect Visual Image V-1	Recognize Visual Signal (Threat Present) C-3.7			60	
Press	Flare Dispenser Switch	9900	C066 Survivability (US)	Feel Switch Movement K-2	Verify Correct Position (Flare Activated) C-1.2	Press Switch P-2.2	Springloaded Press (SP)	ιν̈́	
Set	Target Storage Switch	C138	C138 Navigation Control (NC)	Visually Locate Switch V-5	Verify Correct Position C-1.2	Press Switch P-2.2	Springloaded Press (SP)	-	
E-65	Hard Tums [NVG]	P079	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Orient Aircraft K-4/G-5	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P.2.6		₹	
Change	Altitude Sharply [NVG]	P021	P021 Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		₹	
Change	Airspeed Quickly [NVG]	P015	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		4	

*Since some of the tasks are performed randomly, the total time for the function is greater than the sum of the length of the individual tasks.

FUNCTION 43 Unload Ahrraft (Internat)

21 Seconds

	TASKS			WORKLOAD	DAD COMPONENTS	w		DURATION (SECONDS)
VERB	ОВЈЕСТ	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Monitor	Unloading	C149 Cargo (UCA)	Cargo (UCA)	Visually Scan Cargo Compartment V-7	Verify Correct Procedure C-1.2	Move Head P-2.6		10
Verify	Unloading Complete	C150	C150 Communication (UC)	Receive Auditory Message A-4.9	Decode Message C-5.3			Ø
Transmit	Communication (Crewchief)	B038	B038 Communication (UC)	Receive Speech Feedback Encode Message (Ramp/ A-4.3 C-5.3 C-5.3		Press Switch and Speak P-2.2		m
Receive	Communication (Crewchief)	B037	B037 Communication (UC)	Receive Auditory Message A-4.9	Decode Message C-5.3			м

FUNCTION	44 Unload Cargo (External)	•				TOTAL TII	TOTAL TIME (Approximate)	9.5	9.5 Seconds
	TASKS			WORKLOAD	OAD COMPONENTS	S		DUR (SEC	DURATION (SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS	RETE/
Verify	Load on Ground	P091	P091 Communication (UC)	Receive Auditory Message A-4.9	Decode Message C-5.3			ဇ	
Press	Cargo Release Button	P034	P034 Cargo (UCA)	Feel Switch Movement K-4	Verify Correct Position (Button Pressed) C-1.2	Press Button P-2.2	Springloaded Press (SP)	-	
Check	Hook Open Light	P088	P088 Cargo (UCA)	Visually Register Light V-1	Verify Correct Status (Illuminated) C-4.6			.v.	
Verify	Load Released	P092	P092 Communication (UC)	Receive Auditory Message A-4.9	Decode Message C-5.3			е	
								·	

FUNCTION	45 Update Doppler (Landmark)	mert)				TOTAL TIN	TOTAL TIME (Approximate)	85.5 8	85.5 Seconds
	TASKS			WORKLOAD	SAD COMPONENTS			DURATION	NON (SQN
VERB	OBJECT	TASK #	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE	ETE/ Jous
Set	DEST DISP Thumbwheel	C049	Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (P)	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	v.	
Set	Doppler Display Selector Switch	C055	Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position (DEST/TGT)	Tum Switch P-5.8	Rotary - 7 Positions (R-7)	α	· · · · · · · · · · · · · · · · · · ·
Press	Doppler KYBD Key	9500	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Veniy Correct Status (Display Frozen) C-1.2	Press Key P-2.2	Springloaded Press (SP)	+	
Read	Марс	C104	C104 Navigation Control (NC)	Read Map Symbols V-5.9	Interpret Map Symbols 1-6.8	Handle Maps P-4.6		0	
Enter	UTM Coordinates	C151	Navigation Control (NC)	Visually Locate Keys and Read Symbolic Display V-5.9	Encode and Verify Correct TECT (Coordinates)	Type Entry P.7	Springloaded Press - Alphanumeric Function	12	
Read	Maps	C104	Navigation Control (NC)	Read Map Symbols V-5.9	Interpret Map Symbols (C-6.8	Handle Maps P-4.6	(SP-AN)	0	
Verify	Aircraft Location	C010	External Visual Field (VEX)	Visually Search External Field of View V-7	Interpret Sensory Feedback and Make Judgment (Correct Landmark) C-6.8			0	
Press	Doppier Data Entry Key	C051	(NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (UTM Coordinates) C-3.7	Press Key P-2.2	Springloaded Press (SP)	-	

FUNCTION 45 Update Doppier (Landmark) [Continued]

	TASKS			WORKLOAD	OAD COMPONENTS	S		DURATION (SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Sec	Doppler Display Selector Switch	9900	(NC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position (DIST/BRG/TIME) C-1.2	Turn Switch P-5.8	Rotary - 7 Positions (R-7)	8

46 Update Doppler (Landmark) [NVG]	marto (NVG	<u> </u>		3			TOTAL TIME (Approximate)	85.5 S	85.5 Seconds
TASKS				WORKLOAD	SAD COMPONENTS			(SECONDS)	TION SINDS)
OBJECT		IASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/	ETE/ NOUS
DEST DISP Thumbwheel	100	C049	Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position (P)	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	ဟ	
Doppler Display Selector Switch	5	C055	Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position (DEST/GT)	Tum Switch P-5.8	Rotary - 7 Positions (R-7)	~	
Doppler KYBD Key		C056	Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Display Frozen) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-	<u> </u>
Maps		C104	C104 Navigation Control (NC)	Read Map Symbols V-5.9	Interpret Map Symbols C-6.8	Handle Maps P-4,6		0	
UTM Coordinates		C151	Navigation Control (NC)	Visually Locate Keys and Read Symbolic Display V-5.9	Encode and Verify Correct Entry (Coordinates)	Type Entry P-7	Springloaded Press - Alphanumeric Function	12	
Maps		C104	C104 Navigation Control (NC)	Read Map Symbols V-5.9	Interpret Map Symbols C-6.8	Handle Maps P-4.6	(SP-AN)	0	
Aircraft Location [NVG]		C011	Night Vision Goggles (VG)	Visually Search External Field of View G-7	Interpret Sensory Feedback and Make Judgment (Correct Landmark) C-6.8			04	
Doppler Data Entry Key	>	C051	C051 Navigation Control (NC)	Visually Locate Key and Read Symbolic Display V-5.9	Verify Entry Correct (UTM Coordinates) C-3.7	Press Key P-2.2	Springloaded Press (SP)	-	

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 46 Update Doppler (Landmark) [NVG] [Continued]

	TASKS			WORKLOAD	OAD COMPONENTS	Ø		DURATION (SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH	DISCRETE/ CONTINUOUS
S.	Doppler Display Selector Switch)))	Navigation Control (NC)	Visually Check Switch Positions and Placement of Switch V-4	Decide Correct Position (DIST/BRG/TIME) C-1.2	Tum Switch P-5.8	Rotary - 7 Positions (R-7)	8

85 Seconds

TOTAL TIME (Approximate)

FUNCTION 47 Update Doppler (Mission Change)

	TASKS			WORKLOAD	OAD COMPONENTS	S S		DUR	DURATION (SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS	RETE/ NOUS
Set	Doppler Mode Switch	C058	Navigation Control (NC)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (UTM) C-1.2	Tum Switch P-5.8	Safety Rotary - 6 Positions (SR-6)	-	
Set	Doppler Display Selector Switch	C055	Navigation Control (NC)	Visually Check Switch Position and Placement of Switch V-4	Decide Correct Position (DEST/TGT) C-1.2	Tum Switch P-5.8	Rotary - 7 Positions (R-7)	N	
Set	DEST DISP Thumbwheel	C049	C049 Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position C-1.2	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	w	
Press	Doppler KYBD Key	C056	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (TGT STR Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-	
Press	Doppler KYBD Key	C056	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Center Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-	
Enter	Doppler Zone Data	C061	C061 Navigation Control (NC)	Visually Locate Keys and Read Symbolic Display V-5.9	Encode and Verify Correct Entry (Zone Data) C-5.3	Type Entry P.7	Springloaded Press - Alphanumeric Function (SP-AN)	&	
Press	Doppler KYBD Key	C056	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Left and Right Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-	
Enter	UTM Coordinates	C151	C151 Navigation Control (NC)	Visually Locate Keys and Read Symbolic Display V-5.9	Encode and Verity Correct Entry (Coordinates) C-5.3	Type Entry p-7	Springloaded Press - Pubhanumeric Function (SP-AN)	2	

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 47 Update Doppler (Mission Change) [Continued]

	TASKS			WORKLOAD	DAD COMPONENTS	so.		DURATION (SECONDS)
VERB	OBJECT	TASK #	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE
Press	Doppler Data Entry Key	C051	Navigation Control (NC)	Visually Locate Keys and Read Symbolic Display V-5.9	Verify Entry Correct (UTM Coordinates) (C-3.7)	Press Kay P-2.2	Springloaded Press (SP)	-
Set	FLY-TO-DEST Switch	C072	C072 Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position C-1.2	Tum Switch P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	ഗ
Set	Doppler Display Selector Switch	C055	Navigation Control (NC)	Visually Check Switch Position and Placement of Switch	Decide Correct Position (DEST/TGT) C-1.2	Tum Switch P-5.8	Rotary - 7 Positions (R-7)	8
Set	DEST DISP Thumbwheel	C049	Navigation Control (NC)	Read Symbolic Display V-5.9	Decide and Verify Correct Position C-1.2	Tum Thumbwheel P-5.8	Vertical Thumbwheel - 9 Positions (VT-9)	ĸ
Press	Doppler KYBD Key	9500	C056 Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (TGT STR Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Press	Doppler KYBD Key	9500	Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Center Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-
Enter	Doppler Spheroid Data	0900	C060 Navigation Control (NC)	Visually Locate Keys and Head Symbolic Display V-5.9	Encode and Verify Correct Entry (Spheroid Data) C-5.3	Type Entry P-7	Springloaded Press - Alphanumeric Functions (SP-AN)	0
Press	Doppler KYBD Key	9500	Navigation Control (NC)	Visually Locate Key and Inspect Display Status V-5	Verify Correct Status (Center Display Blank) C-1.2	Press Key P-2.2	Springloaded Press (SP)	-

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 47 Update Doppler (Mission Change) [Continued]

DURATION SECONDS)	DISCRETE/ CONTINUOUS				
JG 88	žă §	<u></u>	18	~	vo
	SWITCH DESCRIPTION	Springloaded Press - Alphanumeric Functions (SP-AN)		Rotary - 7 Positions (R-7)	Vertical Thumbwheel - 9 Positions (VT-9)
Ø	PSYCHOMOTOR	Туре Entry P-7		Turn Switch P-5.8	Turn Switch
SAD COMPONENTS	COGNITIVE	Encode and Verify Correct Enty (Magnetic Variation) C-5.3	Interpret Symbolic Readout and Verify No Malfunctions C-3.7	Decide Correct Position (DEST/TGT) C-1.2	Decide and Verify Correct Position (H) C-1.2
WORKLOAD	SENSORY	Visually Locate Keys and Read Symbolic Display V-5.9	Read Symbolic Display V-5.9	Visually Check Switch Position and Placement of Switch V-4	Read Symbolic Display V-5.9
	SUBSYSTEM(S)	Navigation Control (NC)	C053 Navigation Control (NC)	C055 Navigation Control (NC)	(NC)
	TASK	C057	C053	C055	C072
TASKS	OBJECT	Doppler Magnetic Variation	Doppler Display	Doppler Display Selector Switch	FLY-TO-DEST Switch
	VERB	Enter	Check	S et	e o

CH-47 FUNCTION ANALYSIS WORKSHEET

8.5 Seconds	TION NDS)	ETE			
6.5	DURATION (SECONDS)	DISCRETE/ CONTINUOUS	-	_	v
TOTAL TIME (Approximate)		SWITCH DESCRIPTION	Springloaded Press (SP)	Springloaded Press (SP)	Vertical Thumbwheel - 9 Positions (VT-9)
TOTAL TI	8	PSYCHOMOTOR	Press Key P-2.2	Press Key P-2.2	Tum Switch P-5.8
	SAD COMPONENTS	COGNITIVE	Verity Correct Status (Display Frozen) C-1.2	Verify Entry Correct (UTM Coordinates) C-3.7	Decide and Verify Correct Position C-1.2
	WORKLOAD	SENSORY	Visually Locate Key and Inspect Display Status V-5	Visually Locate Key and Read Symbolic Display V-5.9	Read Symbolic Display V-5.9
		SUBSYSTEM(S)	Navigation Control (NC)	Navigation Control (NC)	C072 Navigation Control
		TASK	2026	C051	C072
48 Update Doppler (PZ)	TASKS	OBJECT	Doppler KYBD Key	Doppler Data Entry Key	FLY-TO-DEST Switch
FUNCTION		VERB	Press	Press	ũ Ø

e) 62 Seconds		<u> </u>	ns 2					
TOTAL TIME (Approximate)		SWITCH	Rotary - 7 Positions (R-7)				Springloaded Press (SP)	Springloaded Press (SP) Springloaded Press (SP)
TOTAL TIME (PSYCHOMOTOR			Handle Maps P-4.6	Maps	8	9
1	TS	PSYCI	Tum Switch P-5.8	_	Handle P-4.6			
	SAD COMPONENTS	COGNITIVE	Decide Correct Position (DIST/BRG TIME) C-1.2	Interpret Map Symbols	C-6.8	C-6.8 Identity Objects and Make Judgment (Location Correct)	C-6.8 Identify Objects and Make Judgment (Location Correct) C-6.8 Verify Correct Status (Display Frozen) C-1.2	C-6.8 Identify Objects and Make Judgment (Location Correct) C-6.8 Verify Correct Status (Display Frozen) C-1.2 Verify Entry Correct (UTM Coordinates) C-3.7
	WORKLOAD	SENSORY	Visually Check Switch Positions and Placement of Switch V-4	Read Map Symbols V-5.9				Visually Search External Field of View and Read Map Symbols V-7 Visually Locate Key and Inspect Display Status V-5 Visually Locate Key and Head Symbolic Display
nation)		SUBSYSTEM(S)	Navigation Control (NC)	C104 Navigation Control (NC)		C010 External Visual Field (VEX)	External Visual Field (VEX) Navigation Control (NC)	External Visual Field (VEX) Navigation Control (NC) Navigation Control (NC)
red Desti		TASK	C055	C104	_	C010	CO 10 CO 56	C010 C056 C051
49 Update Doppler (Stored Destination)	TASKS	OBJECT	Doppler Display Selector Switch	Maps		Aircraft Location	Aircraft Location Doppler KYBD Key	Aircraft Location Doppler KYBD Key Doppler Data Entry Key
FUNCTION	l	VERB	Set	Read		Verify		

62 Seconds

TOTAL TIME (Approximate)

FUNCTION 50 Update Doppler (Stored Destination) [NVG]

DURATION (SECONDS)	DISCRETE/ CONTINUOUS						
DUR (SEC	DISCI	2	10	40	-	-	w
	SWITCH DESCRIPTION	Rotary - 7 Positions (R-7)			Springloaded Press (SP)	Springloaded Press (SP)	Vertical Thumbwheel - 9 Positions (VT-9)
•	PSYCHOMOTOR	Tum Switch P-5.8	Handle Maps P-4.6		Press Key P-2.2	Press Key P-2.2	Tum Switch P-5.8
AD COMPONENTS	COGNITIVE	Decide Correct Position (DIST/BRG TIME)	Interpret Map Symbols C-6.8	Identify Objects and Make Judgment (Location Correct) C-6.8	Verify Correct Status (Display Frozen) C-1.2	Verify Entry Correct (UTM Coordinates) C-3.7	Decide and Verify Correct C-1.2
WORKLOAD	SENSORY	Visually Check Switch Positions and Placement of Switch V-4	Read Map Symbols V-5.9	Visually Search External Field of View G-7	Visually Locate Key and Inspect Display Status V-5	Visually Locate Key and Read Symbolic Display V-5.9	Read Symbolic Display V-5.9
	SUBSYSTEM(S)	Navigation Control (NC)	C104 Navigation Control (NC)	C011 Night Vision Goggles (VG)	C056 Navigation Control (NC)	C051 Navigation Control (NC)	C072 Navigation Control (NC)
	TASK	C055	C104	C011	C056	C051	C072
TASKS	OBJECT	Doppler Display Selector Switch	Maps	Aircraft Location [NVG]	Doppler KYBD Key	Doppler Data Entry Key	FLY-TO-DEST Switch
	VERB	Set	Read	Verify	Press	Press	ë e

240 Seconds*

Parameters
djust Approach
51 /
FUNCTION

TABKS TABK										
Control Cont		TASKS			WORKLO		ø		SECON (SECON	N (SQ
Control Aftitude PD26 Fight Control Feel Control Movements Association (Adjustment Peasure External Visual Peach Wasual) Deach Aircraft Association (Adjustment Peach Peasure Association (Adjustment Peach Peasure Activity Aircraft A	VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRE	TE/ OUS
Control Airspeed Fight Control (Foet Control Movements) Make Conditioned Control Pressure (FC/VEX) (Stauly Deet Aircraft Association (Adjustment P.2.6 (FC/VEX)) (FLIPM Control Movement Airspeed P.2.6 (Control Pressure Fether Make Conditioned Control Pressure (FC/VEX) (Flight Control Movement Association (Adjustment P.2.6 (Control Pressure Fether Movement (FC/VEX)) (Flight Control Movement Association (Adjustment P.2.6 (Control Pressure Fether Movement (FC/VEX)) (Flight Control Movement Association (Adjustment P.2.6 (Control Pressure Fether Movement (FC/VEX)) (Flight Control Movement Association (Adjustment P.2.6 (Control Pressure Fethermal Visual Field Visually Deet Aircraft (Association (Adjustment FEC/VEX)) (Flight Control Movement Association (Adjustment P.2.6 (Control Pressure Fethermal Visual Field Visually Deet Aircraft (Association (Adjustment P.2.6 (Control Pressure Fethermal Visual Field Visually Deet Aircraft (Association (Adjustment P.2.6 (Control Pressure Fethermal Visual Field Visually Deet Aircraft (Control Movement Association (Adjustment P.2.6 (Control Pressure Fethermal Visual Field Visually Deet Aircraft (Control Movement Association (Adjustment P.2.6 (Control Pressure Fethermal Visual Field Visually Deet Aircraft (Control Pressure Fethermal Visual Field Visually Deethermal Control Pressure Fethermal Visually Deethermal Control Pressure Fethermal Visually Deethermal Control Pressure (Control Pressure Fethermal Visually Dee	Control	Attitude	P026	Flight Control/ External Visual Field (FC/VEX)	ts/	nditioned on (Adjustment	Control Pressure P-2.6		10.	
Control Airspeed P012 Fight Control Wovements Association (Adjustment P-2.6 External Visual Field Visually Detect Aircraft Association (Adjustment P-2.6 External Visual Field Visually Detect Aircraft Association (Adjustment P-2.6 External Visual Field Visually Detect Aircraft Association (Adjustment P-2.6 External Visual Field Visually Detect Aircraft Association (Adjustment P-2.6 External Visual Field Visually Detect Aircraft Association (Adjustment P-2.6 External Visually Detect Aircraft Aircraft Aircraft P-2.6 External Visually Detect Aircraft Aircraft Aircraft Aircraft (ECAVEX)	Control	Rate of Descent	P130	Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	e Conditioned ociation (Adjustment ded)	Control Pressure P-2.6		ĸċ	
Control Heading P080 Fight Control Movements Make Conditioned Control Pressure External Visual Field Visually Detect Aircraft Association (Adjustment Pose Fight Control Movement Control Movement Association (Adjustment Pose External Visual Field Visually Detect Aircraft Association (Adjustment Pose (FC/VEX) Movement Control Movement Control Movement Control Movement Association (Adjustment Pose (FC/VEX) Movement Control Moveme	Control	Airspeed	P012	Flight Control/ External Visual Field (FC/VEX)	S		Control Pressure P-2.6		ĸú	
Drift P062 Flight Control Feel Control Movements Make Conditioned Control Pressure External Visuality Detect Aircraft Association (Adjustment P-2.6 Movement K-4/V-1 C-1	Control	Heading	P080	Flight Control/ External Visual Field (FC/VEX)		Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		ro.	
	Control	#E	P062	Flight Control/ External Visual Field (FC/VEX)		(e Conditioned ociation (Adjustment oded)	Control Pressure P-2.6		rů.	

*Since some of the tasks are performed randomly, the total time for the function is greater than the sum of the length of the individual tasks.

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION	52 Adjust Approach Parameters (NVG)	Moders [NVG			TOTAL TIN	TOTAL TIME (Approximate)	340 Seconds*
	TASKS			WORKLOAD	OAD COMPONENTS	S		DURATION (SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Control	Attitude (NVG)	P028	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-
Control	Rate of Descent [NVG]	P131	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-
Control	Airspeed [NVG]	P016	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-
Journal E - 7 9	Heading [NVG]	P086	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P.2.6		-
Control	Drift (NVG)	P063	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-

*Since some of the tasks are performed randomly, the total time for the function is greater than the sum of the length of the individual tasks.

FUNCTION 53 Adjust Climb Parameters

20 Seconds*

SUBSYSTEM(S) SENSORY COCNITIVE PSYCHOMOTOR DESCRIPTION Fight Control Feel Control Movements (FC/VEX) K-4/V-1 K-4/V-1 K-4/V-1 K-4/V-1 K-4/V-1 Control Pressure Fight Control Feel Control Movements (FC/VEX) Movement (FC/VEX) Feel Control Movements (FC/VEX) Movement (TASKS			WORKLO	LOAD COMPONENTS	118		DURATION (SECONDS)
Control Attitude PD28 Fight Control Movements Make Conditioned Control Pressure Exemal Visual Fall Visually Describtoral Association (Adjustment P.2.6 Movement Movements Make Conditioned Control Pressure For Control Movements Movements Make Conditioned Control Pressure For Control Movements	VERB		TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWTCH DESCRIPTION	DISCRETE/ CONTINUOUS
Control Rais of Clamb P 128 Flight Control Movements Make Conditioned Control Pressure Exernal Visual Field National Detect Aircraft National Movements (CVEX) (Control Heading P012 Flight Control Movements (CVEX) (Control Heading P000 Flight Control Movement (CVEX) (Control Heading P000 Flight Control Movement (CVEX) (Control Movement (CVEX)	Control	Attitude		Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1		Control Pressure P-2.6		ĸ.
Control Alispeed Bright Control Movements Association (Adjustment Post External Visual Field Vessily Detect Aurorath Association (Adjustment Fight Control Fight Control Movements External Visual Field Control Movements (FCVEX) Fight Control Movements (FCVEX) Read (Adjustment Association (Adjustment P.2.6 Control Movements (FCVEX) Read (Adjustment Association (Adjustment P.2.6 Control Movements (FCVEX) Read (Adjustment Association (Adjustment P.2.6 Control Movements (FCVEX) Read (Adjustment Association (Adjustment Association (Adjustment P.2.6 Control Movements (FCVEX) Read (Adjustment Association (Adjustment Association (Adjustment P.2.6 Control Movements (FCVEX) Read (Adjustment Association (Adjustment P.2.6 Control Movements (FCVEX) Read (Adjustment Association (Adjustment Association (Adjustment P.2.6 Control Movements (FCVEX) Read (Adjustment Association (Adjustment Associat	Control	Rate of Climb		Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		ru.
Control Heading Poss Eight Control Movements Make Conditioned Control Pressure Eight Control Need of Movement (Adjustment P.2.6 Feel Control Movement (Adjustment Association (Adjustment P.2.6 Feel Control Pressure Association (Adjustment Association (Adjustment P.2.6 Feel Control Pressure Pressure Association (Adjustment P.2.6 Feel Control Pressure Pre		Airspeed	P012	Flight Control/ External Visual Field (FC/VEX)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1	tment	Control Pressure P-2.6		ιν _.
		Heading	080		3	ditioned n (Adjustment	Control Pressure		ιņ

*Since some of the tasks are performed randomly, the total time for the function is greater than the sum of the length of the individual tasks.

FUNCTION 54 Adjust Climb Parameters [INVG]

30 Seconds*

	TASKS			WORKLO	LOAD COMPONENTS	118		DURATION (SECONDS)	76
VERB	овлест	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS	S
Control	Attitude [NVG]	P028	Fight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	
Control	Rate of Climb [NVG]	P129	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		+-	
Control	Airspeed [NVG]	P016	Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Acjustment Needed) C-1	Control Pressure P-2.6		-	
Tool 1	Heading [NVG]	P086	P086 Flight Control/Night Vision Goggles (FC/VG)	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-	
									
-1-8-2 ·									

*Since some of the tasks are performed randomly, the total time for the function is greater than the sum of the length of the individual tasks.

CH-47 FUNCTION ANALYSIS WORKSHEET

oximate) 30 Seconds*	DURATION	<u> </u>		ю. -	ro ro	ທ _ີ ທີ
TOTAL TIME (Approximate)		SWTCH				
	ENTS	PSYCHOMOTOR	Control Pressure P-2.6	•	Control Pressure P-2.6	Control Pressure P-2.6 Control Pressure P-2.6
	LOAD COMPONENTS	COGNITIVE	Make Conditioned Association (Adjustment Needed) C-1		Make Conditioned Association (Adjustment Needed) C-1	Make Conditioned Association (Adjustment Needed) C-1 Make Conditioned Association (Adjustment Needed)
	WORKLOAD	SENSORY	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1		Flight Control Feel Control Movements/ External Visual Field Visually Detect Aircraft (FC/VEX) Movement K-4/V-1	Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1 Feel Control Movements/ Visually Detect Aircraft Movement K-4/V-1
es.		SUBSYSTEM(S)	Flight Control/ External Visual Field (FC/VEX)	 Eliaht Control/	External Visual Field (FC/VEX)	External Visual Field (FC/VEX) P012 Flight Control (FC)
ht Paramet		TASK	P026	P019		P012
55 Adjust Level of Flight Parameters	TASKS	овлест	Attitude	Altitude		Airspeed
FUNCTION		VERB	Control	Control		Control

"Since some of the tasks are performed randomly, the total time for the function is greater than the sum of the length of the individual tasks.

CH-47 FUNCTION ANALYSIS WORKSHEET

30 Seconds

[MG]
ramotera
Flight Per
Level of
Adjust
26
FUNCTION

TION NDS)	TETE/ IUOUS				
DURATION (SECONDS)	DISCRETE/ CONTINUOUS	1	-	-	-
	SWITCH DESCRIPTION				
ENTS	PSYCHOMOTOR	Control Pressure P-2.6	Control Pressure P-2.6	Control Pressure P-2.6	P-2.6
OAD COMPON	COGNITIVE	Make Conditioned Association (Adjustment Needed) C-1	Make Conditioned Association (Adjustment Needed) C-1	Make Conditioned Association (Adjustment Needed)	Make Conditioned Association (Adjustment Needed) C-1
WORKL	SENSORY	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Feel Control Movements/Visually Detect Aircraft Movement K-4/G-1
	SUBSYSTEM(S)	Fight Control/Night Vision Goggles (FC/VG)	Flight Control/Night Vision Goggles (FC/VG)	Flight Control/Night Vision Goggles (FC/VG)	Flight Control/Night Vision Goggles (FC/VG)
	TASK	P028	P023	P016	P086
TASKS	OBJECT	Attitude [NVG]	Altitude [NVG]	Airspeed [NVG]	Heading [NVG]
	VERB	Control	Control	Control	Control

FUNCTION 57 Check Alread Systems (Copilot)

10.5 Seconds

NOIF	NDS) TETE/			
DURATION	(SECONDS) DISCRETE/ CONTINUOUS	ဟ	-	ტ
	SWITCH DESCRIPTION			
8	PSYCHOMOTOR			
SAD COMPONENTS	COGNITIVE	Interpret Sensory and Symbolic Readouts and Verify Correct Status (Readouts Within Limits) C-3.7	Verify Correct Status (No Lights Illuminated) C-1.2	Interpret Symbolic Readout (Quantity) and Make Judgment (Enough Fuel) C-4.6
WORKLOAD	SENSORY	Visually Inspect Instrument Indications V-4	Visually Inspect and Register Lights V-1	Visually Inspect Instrument Indication V-4
	SUBSYSTEM(S)	B064 Engine Instruments (EIN)	B105 Advisory (UAD)	
	TASK	B064	B105	B076 Fuel
TASKS	OBJECT	Engine Instruments	Master CAUTION/WARNING Panel	Fuel Quantity Indicator
	VERB	Check	Check	Chack

1 Second*

k Approach Parameters
2
28 28
FUNCTION

	TASKS			WORKLOA	O O O O O O O O O O O O O O O O O O O	ď		DURATION	3
					- 1			(SECONDS)	(8)
VERB	OBJECT	*	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/	Snc
Check	Vertical Situation Indicator (Inflight)	P152	Flight Instruments (Fl)	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verify Correct Status (Readout Within Limits) C-3.7	Control Pressure P-2.6		-	
Check	Airspeed Indicator (Inflight)	P013	P013 Flight Instruments (FI)	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verify Correct Status (Readout Within Limits) C-3.7	Control Pressure P-2.6		▼	
Check	Heading Indicator (Inflight)	P084	P084 Flight Instruments (FI)	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verify Correct Status (Readout Within Limits) C-3.7	Control Pressure P-2.6		-	
									<u></u>
									

*Since the function is performed randomly and only one task is performed each time the function is selected, the total time is less than the sum of the individual tasks.

FUNCTION 59 Check Climb Parameters

1 Second*

NOIT (SQN)	ETE/ UOUS			
DURATION (SECONDS)	DISCRETE/ CONTINUOUS	-	-	-
	CH PTION			
	SWITCH DESCRIPTION			
17.8	PSYCHOMOTOR	Control Pressure P-2.6	Control Pressure P-2.6	Control Pressure
OAD COMPONENTS	COGNITIVE	Interpret Readout and Verify Correct Status (Readout Within Limits) C-3.7	Interpret Readout and Verify Correct Status (Readout Within Limits) C-3.7	Interpret Readout and Verify Correct Status (Readout Within Limits) C-3.7
WORKLOA	SENSORY	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4
	SUBSYSTEM(S)	Flight Instruments (FI)	P013 Flight Instruments (FI)	Fight Instruments (FI)
	TASK	P152	P013	7 800
TASKS	OBJECT	Vertical Situation Indicator (Inflight)	Airspeed Indicator (Inflight)	Heading Indicator (Inflight)
	VERB	Check	Check	E-86

*Since the function is performed randomly and only one task is performed each time the function is selected, the total time is less than the sum of the individual tasks.

1 second*

TOTAL TIME (Approximate)

CH-47 FUNCTION ANALYSIS WORKSHEET

FUNCTION 60 Check Flight Parameters

	T A S K S			WORKLOAD	OAD COMPONENTS			DUBATION
					- 1			(SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS
Check	Abimeter (Inflight)	P017	Fight Instruments (FI)	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verify Correct Status (Readout Within Limits) C-3.7	Control Pressure P-2.6		-
Check	Airspeed Indicator (Inflight)	P013	Flight Instruments (Fl)	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verify Correct Status (Readout Within Limits) C-3.7	Control Pressure P-2.6		-
Check	% TRQ Indicator (Inflight)	P153	Engine Instruments (EIN)	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verify Correct Status (Readout Within Limits) C-3.7	Control Pressure P-2.6		-
5 E-87	Heading Indicator (Inflight)	P084	Flight Instruments (Fl)	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verify Correct Status (Readout Within Limits) C-3.7	Control Pressure P-2.6		-
Check	Trim Ball (Inflight)	P147	P147 Flight Instruments (FI)	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verify Correct Status (Readout Within Limits) C-3.7	Control Pressure P-2.6		-
		-						
				,				

*Since the function is performed randomly and only one task is performed each time the function is selected, the total time is less than the sum of the individual tasks.

11 Seconds

TOTAL TIME (Approximate)

FUNCTION 61 Check Fuel Consumption Parameters

	TASKS			WORKLOAD	OAD COMPONENTS	တ		DURA (SECC	TION
VERB	ОВЈЕСТ	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	РЅУСНОМОТОВ	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS	ETE/ IUOUS
Check	Fuel Quantity Indicator	C076 Fuel (EF)		Visually inspect instrument indication V-4	Interpret Symbolic Readout (Quantity) and Make Judgment (Enough Fuel) C-4.6			8	
Note	Time	C142 Fuel (EF)		Visually Check Instrument Indication V-4	Interpret Readout C-3.7	Write Information P-6.5		٨	
		<u></u> -							
									

Check Level of Flight Parameters

FUNCTION 62

TOTAL TIME (Approximate)

1 Second*

	TASKS			WORKLOAD	LOAD COMPONENTS	418		DURATION (SECONDS)	zŵ
VERB	OBJECT	TASK #	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE/ CONTINUOUS	ČE,
Check	Attmeter (Inflight)	P017	P017 Flight Instruments (F)	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verity Correct Status (Readout Within Limits) C-3.7	Control Pressure P-2.6		-	
Check	Airspeed Indicator (Inflight)	P013	P013 Flight Instruments (FI)	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verify Correct Status (Readout Within Limits) C-3.7	Control Pressure P-2.6		-	
Check	Heading Indicator (Inflight)	P084	Flight Instruments (FI)	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verify Correct Status (Readout Within Limits) C-3.7	Control Pressure P-2.6		-	
E-89								-	
					-				<u>. </u>
· · · · · · · · · · · · · · · · · · ·									

*Since the function is performed randomly and only one task is performed each time the function is selected, the total time is less than the sum of the individual tasks.

Establish Hover

FUNCTION 63

3 Seconds

	TASKS			WORKLOAD	LOAD COMPONENTS	118		DURATION (SECONDS)
VERB	OBJECT	TASK	SUBSYSTEM(S)	SENSORY	COGNITIVE	PSYCHOMOTOR	SWITCH DESCRIPTION	DISCRETE
Adjust	Ромег	P123	Flight Control/ External Visual Field (FC/VEX)	-eel Control Movements/ /isually Detect Aircraft Wovement <-4/V-1	Make Conditioned Association (Adjustment Needed) C-1	Control Pressure P-2.6		-
Check	% TRQ Indicator (Inflight)	P153	Engine Instruments (EIN)	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4	Interpret Readout and Verify Correct Status (Readout Within Limits) C-3.7	Control Pressure P-2.6		-
				~~				
				-				

FUNCTION 64 Establish Hover [NVG]

4 Seconds

NOI	ETE/ UOUS		
DURATION	DISCRETE/ CONTINUOUS	8	-
	SWITCH		
18	PSYCHOMOTOR	Control Pressure P-2.6	P-2.6
OAD COMPONENTS	COGNITIVE	Make Conditioned Association (Adjustment Needed) C-1	Unterpret Readout and Verify Correct Status (Readout Within Limits) C-3.7
WORKLOAD	SENSORY	Feel Control Movements/ Visually Detect Aircraft Movement K-4/G-1	Feel Control Movements/ Visually Check Instrument Indications K-4/V-4
	SUBSYSTEM(S)	Flight Control/Night Vision Goggles (FC/VG)	(EIN)
	TASK #	P126	P153
TASKS	OBJECT	Power [NVG]	% TRQ indicator (Inflight)
	VERB	Adjust	Check

FUNCTION 65 Monthor Threat (Copilot)

3.5 Seconds

Į.	NDS) ETE/ UOUS	
DUR.	(SECONDS) DISCRETE/ CONTINUOUS	es .
	SWITCH DESCRIPTION	
S	PSYCHOMOTOR	
OAD COMPONENTS	COGNITIVE	Recognize Visual Signal (Threat Present) C-3.7
WORKLOAD	SENSORY	V-1
	SUBSYSTEM(S)	B050 Survivability (US)
	TASK	B050
TASKS	OBJECT	Direction Display
	VERB	Check

*snon	DURATION (SECONDS) DISCRETE/ CONTINUOUS		€
Continuous*			
	F		
TOTAL TIME (Approximate)		₹ 5 5 5 7 7 7	
Approx	SWITCH		
TIME (/			
JTAL 1			
۲		TOR	Bannes.
		PSYCHOMOTOR	Control Pressure
	ည	PSY	P-2.6
	N E N		
	WORKLOAD COMPONENTS		Make Conditioned Association C-1
		COGNITIVE	Condi
		8	Make C-1
			benoting the state of the state
		SENSORY	Make Conditioned Association K-1
		SEN	Make Asso K-1
	K SUBSYSTEM(S)		7
			Fight Control (FC)
			Fight (FC)
	TASK		154
Control			
Monthor Plight Controls	TASKS		
		5	Flight Controls
99		OBJECT	Fight
FUNCTION		VERB	Monitor
_			E-93

*The total time for the function will vary depending on the length of the segment.